

Bailcast Steering Rack Boots

Make	Model	Mark	Litre	Fuel	SubModel	bhp	FrmM	FrmY	ToM	ToY	PartNo
ALFA ROMEO	33	Mk1	1.2	P Inj			01	1983	12	1989	DBSR100
ALFA ROMEO	33	Mk1	1.35	P			06	1983	05	1987	DBSR100
ALFA ROMEO	33	Mk1	1.5	P			01	1985	12	1987	DBSR100
ALFA ROMEO	75		1.8	P			06	1986	09	1989	DBSR200
ALFA ROMEO	90		1.8	P Inj			01	1985	12	1988	DBSR200
ALFA ROMEO	90		2.0	P Inj			01	1985	12	1988	DBSR200
ALFA ROMEO	90		2.4	D Turbo			01	1985	12	1988	DBSR200
ALFA ROMEO	90		2.5	P	V6		01	1985	10	1987	DBSR200
ALFA ROMEO	145		1.6	P Inj			10	1994	03	1997	DBSR300
ALFA ROMEO	145		1.6	P Inj	Twin Spark		03	1997	01	2001	DBSR300
ALFA ROMEO	145		1.7	P Inj			10	1994	03	1997	DBSR300
ALFA ROMEO	145		1.8	P Inj			03	1997	01	2001	DBSR300
ALFA ROMEO	145		2.0	P Inj			02	1996	01	2001	DBSR300
ALFA ROMEO	146		1.6	P Inj			06	1995	03	1997	DBSR300
ALFA ROMEO	146		1.6	P Inj	Twin Spark		03	1997	01	2001	DBSR300
ALFA ROMEO	146		1.7	P Inj			06	1995	09	1996	DBSR300
ALFA ROMEO	146		1.8	P Inj			03	1997	01	2001	DBSR300
ALFA ROMEO	146		2.0	P Inj			02	1996	01	2001	DBSR300
ALFA ROMEO	147		1.6	P Inj			02	2001	12	2001	DBSR300
ALFA ROMEO	147		2.0	P Inj			02	2001	12	2001	DBSR300
ALFA ROMEO	147		3.2	P Inj			06	2003			DBSR300
ALFA ROMEO	155		1.8	P Inj	Twin Spark		07	1992	03	1998	DBSR300
ALFA ROMEO	155		2.0	P Inj	Twin Spark Fwd		07	1992	03	1998	DBSR300
ALFA ROMEO	155		2.0	P Turbo	Cloverleaf 4wd	Front, Inner without metal flange	10	1992	09	1994	DBSR300
ALFA ROMEO	155		2.0	P Turbo	Cloverleaf 4wd	Front, Inner with metal flange	10	1992	09	1994	DBSR300
ALFA ROMEO	155		2.5	P Inj	V6	Inner boot without metal flange	04	1992	09	1996	DBSR300
ALFA ROMEO	155		2.5	P Inj	V6	Inner boot with metal flange	04	1992	09	1996	DBSR300
ALFA ROMEO	156		1.6	P Inj	Twin Spark		07	2000	12	2001	DBSR300
ALFA ROMEO	156		1.8	P Inj	Twin Spark		05	1998	12	2001	DBSR300
ALFA ROMEO	156		1.9	t turbo	JTD	Inner boot without metal flange	03	2003	12	2001	DBSR300
ALFA ROMEO	156		1.9	D turbo	JTD	Inner boot with metal flange	03	2003	12	2001	DBSR300

Sheet1

ALFA ROMEO	156		2.0	P Inj	Twin Spark		05	1998	12	2001	DBSR300
ALFA ROMEO	156		2.4	D turbo	JTD	Inner boot without metal flange	06	1999	12	2001	DBSR300
ALFA ROMEO	156		2.4	D turbo	JTD	Inner boot with metal flange	06	1999	12	2001	DBSR300
ALFA ROMEO	156		2.5	P Inj	V6	Inner boot without metal flange	05	1998	12	2001	DBSR300
ALFA ROMEO	156		2.5	P Inj	V6	Inner boot with metal flange	05	1998	12	2001	DBSR300
ALFA ROMEO	164		2.0	P Inj	Twin Spark		07	1990	03	1998	DBSR400
ALFA ROMEO	Alfasud		1.3	P			08	1977	12	1984	DBSR100
ALFA ROMEO	Alfasud		1.3	P	Ti, Sprint		07	1979	12	1984	DBSR100
ALFA ROMEO	Alfasud		1.5	P			09	1978	04	1984	DBSR100
ALFA ROMEO	Alfasud		1.5	P inj	Sprint		09	1978	12	1984	DBSR100
ALFA ROMEO	Alfasud		1.5	P inj	Ti		09	1978	12	1984	DBSR100
ALFA ROMEO	Alfetta		1.6	P			12	1978	12	1978	DBSR100
ALFA ROMEO	Alfetta		1.8	P			12	1978	08	1977	DBSR100
ALFA ROMEO	Alfetta		2.0	P			12	1978	10	1983	DBSR100
ALFA ROMEO	Giulietta		1.3	P Inj			01	1978	12	1982	DBSR200
ALFA ROMEO	Giulietta		1.6	P			01	1982	03	1986	DBSR200
ALFA ROMEO	Giulietta		1.8	P			08	1979	03	1986	DBSR200
ALFA ROMEO	Giulietta		2.0	P			07	1980	03	1986	DBSR200
AUDI	50		1.1	P Inj			01	1974	08	1979	DBSR100
AUDI	50		1.3	P Inj			01	1974	08	1979	DBSR100
AUDI	80	Mk1	1.3	P			01	1977	07	1977	DBSR200
AUDI	80	Mk1	1.6	P			01	1976	08	1978	DBSR200
AUDI	80	Mk2	1.6	P			01	1985	07	1986	DBSR200
AUDI	80	Mk2	1.6	P			03	1979	12	1984	DBSR200
AUDI	80	Mk2	1.8	P Inj	Quattro		01	1983	07	1986	DBSR200
AUDI	80	Mk2	1.8	P	Fwd		01	1985	07	1986	DBSR200
AUDI	80	Mk2	1.8	P	Fwd		02	1983	12	1984	DBSR200
AUDI	80	Mk2	1.8	P	Quattro	Front	07	1985	12	1984	DBSR200
AUDI	80	Mk2	1.8	P	Quattro	Front	01	1985	07	1986	DBSR200
AUDI	80	Mk2	1.8	P	Quattro	Rear	07	1985	12	1984	DBSR200
AUDI	80	Mk2	1.8	P	Quattro	Rear	01	1985	07	1986	DBSR200
AUDI	80	Mk2	1.8	P Inj	GTE		01	1985	07	1986	DBSR200
AUDI	80	Mk2	1.9	P			08	1981	11	1982	DBSR200
AUDI	80	Mk2	1.9	P			12	1982	07	1983	DBSR200
AUDI	80	Mk2	2.0	P			10	1983	05	1984	DBSR200
AUDI	80	Mk3	1.6	P			11	1986	10	1987	DBSR200

Sheet1

AUDI	80	Mk3	1.6	D Turbo			11	1986	04	1988	DBSR200
AUDI	80	Mk3	1.6	D Turbo		81mm outer joint	04	1988	12	1991	DBSR200
AUDI	80	Mk3	1.6	D Turbo		90mm outer joint	04	1988	12	1991	DBSR200
AUDI	80	Mk3	1.8	P	Fwd		01	1988	11	1991	DBSR200
AUDI	80	Mk3	1.8	P	Fwd		04	1988	12	1988	DBSR200
AUDI	80	Mk3	1.8	P	Fwd		01	1988	11	1991	DBSR200
AUDI	80	Mk3	1.8	P	Fwd		04	1988	12	1988	DBSR200
AUDI	80	Mk3	1.8	P	Fwd		01	1988	04	1988	DBSR200
AUDI	80	Mk3	1.8	P	Fwd		10	1986	12	1988	DBSR200
AUDI	80	Mk3	1.8	P	Quattro 4wd	Front	04	1985	12	1988	DBSR200
AUDI	80	Mk3	1.8	P	Quattro 4wd	Front	01	1988	03	1988	DBSR200
AUDI	80	Mk3	1.8	P	Quattro 4wd	Rear	04	1985	12	1988	DBSR200
AUDI	80	Mk3	1.8	P	Quattro 4wd	Rear	01	1988	03	1988	DBSR200
AUDI	80	Mk3	1.8	P Inj	Quattro		03	1988	12	1991	DBSR200
AUDI	80	Mk3	2.2	P Inj			01	1985	12	1989	DBSR200
AUDI	80	Mk4	1.6	P			09	1993	07	1994	DBSR200
AUDI	80	Mk4	1.6	P			09	1993	07	1994	DBSR200
AUDI	80	Mk4	1.9	D turbo	TDi Automatic		09	1993	07	1994	DBSR200
AUDI	80	Mk4	1.9	D turbo	TDi Manual		01	1992	07	1994	DBSR200
AUDI	80	Mk4	2.0	P Inj	Automatic		01	1991	07	1994	DBSR200
AUDI	80	Mk4	2.0	P Inj	Manual		01	1991	07	1994	DBSR200
AUDI	80	Mk4	2.0	P Inj	Manual	Inner boot without metal flange	01	1991	07	1994	DBSR200
AUDI	80	Mk4	2.0	P Inj	Manual	Inner boot with metal flange	01	1991	07	1994	DBSR200
AUDI	80	Mk4	2.0	D Turbo			01	1991			DBSR200
AUDI	80	Mk4	2.0	P Inj	4wd	Front	11	1991	06	1995	DBSR200
AUDI	80	Mk4	2.0	P Inj	4wd	Rear	11	1991	06	1995	DBSR200
AUDI	80	Mk4	2.0	P Inj	4wd	Rear, Inner without metal flange	11	1991	06	1995	DBSR200
AUDI	80	Mk4	2.0	P Inj	4wd	Rear, Inner with metal flange	11	1991	06	1995	DBSR200
AUDI	80	Mk4	2.0	P Inj	Quattro 4wd	Front	11	1991	06	1992	DBSR200
AUDI	80	Mk4	2.0	P Inj	Quattro 4wd	Rear	11	1991	06	1992	DBSR200
AUDI	80	Mk4	2.2	P Turbo	4wd	Front & Rear, Inner without metal flange	01	1993	06	1995	DBSR200
AUDI	80	Mk4	2.2	P Turbo	4wd	Front & Rear, Inner with metal flange	01	1993	06	1995	DBSR200
AUDI	80	Mk4	2.3	P Inj		Inner boot without metal flange	11	1991	06	1992	DBSR200
AUDI	80	Mk4	2.3	P Inj		Inner boot with metal flange	11	1991	06	1992	DBSR200
AUDI	80	Mk4	2.6	P Inj	Fwd		01	1993	06	1995	DBSR200
AUDI	80	Mk4	2.6	P Inj	Quattro 4wd	Front	01	1993	06	1995	DBSR200

Sheet1

AUDI	80	Mk4	2.6	P Inj	Quattro 4wd	Rear	01	1993	06	1995	DBSR200
AUDI	80	Mk4	2.6	P Inj	Quattro 4wd	Rear	01	1993	06	1995	DBSR200
AUDI	80	Mk4	2.8	P Inj	Fwd		01	1993	06	1992	DBSR200
AUDI	80	Mk4	2.8	P Inj	Quattro 4wd	Front	01	1993	08	1993	DBSR200
AUDI	80	Mk4	2.8	P Inj	Quattro 4wd	Rear	01	1993	08	1993	DBSR200
AUDI	90	Mk1	1.8	P Inj			01	1985	12	1987	DBSR200
AUDI	90	Mk1	2.0	P			01	1985	08	1986	DBSR200
AUDI	90	Mk1	2.2	P	Quattro		01	1985	08	1986	DBSR200
AUDI	90	Mk1	2.2	P	Quattro 4wd	Front	01	1985	08	1986	DBSR200
AUDI	90	Mk1	2.2	P	Quattro 4wd	Rear	01	1985	08	1986	DBSR200
AUDI	90	Mk1	2.2	P	Quattro 4wd	Rear, Inner without metal flange	01	1985	03	1985	DBSR200
AUDI	90	Mk1	2.2	P	Quattro 4wd	Rear, Inner with metal flange	01	1985	03	1985	DBSR200
AUDI	90	Mk2	2.0	P			07	1987	04	1988	DBSR200
AUDI	90	Mk2	2.0	P			05	1988	08	1989	DBSR200
AUDI	90	Mk2	2.2	P	Fwd		07	1987	08	1989	DBSR200
AUDI	90	Mk2	2.2	P	Fwd		07	1987	08	1989	DBSR200
AUDI	90	Mk2	2.2	P	Quattro 4wd	Front	07	1987	08	1989	DBSR200
AUDI	90	Mk2	2.2	P	Quattro 4wd	Rear	07	1987	08	1989	DBSR200
AUDI	90	Mk2	2.2	P Inj			09	1989	12	1991	DBSR200
AUDI	90	Mk2	2.3	P	Fwd	Inner boot without metal flange	01	1990	11	1991	DBSR200
AUDI	90	Mk2	2.3	P	Fwd	Inner boot with metal flange	01	1990	11	1991	DBSR200
AUDI	90	Mk2	2.3	P	Fwd	Inner boot without metal flange	01	1990	11	1991	DBSR200
AUDI	90	Mk2	2.3	P	Fwd	Inner boot with metal flange	01	1990	11	1991	DBSR200
AUDI	90	Mk2	2.3	P	Quattro 4wd	Front	01	1990	11	1991	DBSR200
AUDI	90	Mk2	2.3	P	Quattro 4wd	Rear	01	1990	11	1991	DBSR200
AUDI	90	Mk2	2.3	P	Quattro 4wd	Front	01	1990	11	1991	DBSR200
AUDI	90	Mk2	2.3	P	Quattro 4wd	Rear	01	1990	11	1991	DBSR200
AUDI	A2		1.4	P Inj			09	2000			DBSR100
AUDI	A2		1.4	D Turbo			03	2001			DBSR200
AUDI	A4	Mk1	1.6	P Inj	Auto		03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.6	P Inj	Manual	Inner boot without metal flange	03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.6	P Inj	Manual	Inner boot with metal flange	03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.8	P Inj	Fwd, Auto		03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.8	P Inj	Fwd, Manual	Inner boot without metal flange	03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.8	P Inj	Fwd, Manual	Inner boot with metal flange	03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.8	P Inj	Quattro, 4wd	Front, Inner without metal flange	03	1995	09	2001	DBSR300

Sheet1

AUDI	A4	Mk1	1.8	P Inj	Quattro, 4wd	Front, Inner with metal flange	03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.8	P Inj	Quattro, 4wd	Rear	03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.8	P Turbo	Fwd, Auto		03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.8	P Turbo	Fwd, Manual	Inner boot without metal flange	03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.8	P Turbo	Fwd, Manual	Inner boot with metal flange	03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.8	P Turbo	Quattro, 4wd	Front, Inner without metal flange	03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.8	P Turbo	Quattro, 4wd	Front, Inner with metal flange	03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.8	P Turbo	Quattro, 4wd	Rear	03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.9	D turbo	TDi Fwd		01	2000	09	2001	DBSR300
AUDI	A4	Mk1	1.9	D turbo	TDi Fwd		12	1995	01	2000	DBSR300
AUDI	A4	Mk1	1.9	D turbo	TDi Fwd		03	1995	09	2001	DBSR300
AUDI	A4	Mk1	1.9	D turbo	TDi Quattro, 4wd	Front	09	1996	05	1998	DBSR300
AUDI	A4	Mk1	1.9	D turbo	TDi Quattro, 4wd	Rear	09	1996	05	1998	DBSR300
AUDI	A4	Mk1	2.0	P Inj			03	1995	09	2001	DBSR300
AUDI	A4	Mk2	1.6	P Inj			10	2001	12	2003	DBSR300
AUDI	A4	Mk2	1.8	P Inj			10	2001	12	2003	DBSR300
AUDI	A4	Mk2	1.9	D Turbo			10	2001	12	2003	DBSR300
AUDI	A4	Mk2	2.0	P Inj			10	2001	12	2003	DBSR300
AUDI	A6	Mk2	1.8	P Turbo	Auto, Fwd		05	1997			DBSR300
AUDI	A6	Mk2	1.8	P Turbo	Manual, Fwd	Inner boot without metal flange	05	1997			DBSR300
AUDI	A6	Mk2	1.8	P Turbo	Manual, Fwd	Inner boot with metal flange	05	1997			DBSR300
AUDI	A6	Mk2	1.9	D Turbo	Manual, Auto		05	1997			DBSR300
AUDI	Cabriolet		1.8	P Inj			03	1997	12	1999	DBSR200
AUDI	Cabriolet		2.0	P			07	1993	12	1996	DBSR200
AUDI	Cabriolet		2.3	P Inj	Auto		07	1992	05	1994	DBSR200
AUDI	Cabriolet		2.3	P Inj	Manual		07	1992	05	1994	DBSR200
AUDI	Cabriolet		2.6	P Inj	Manual Auto		05	1994	12	1999	DBSR200
AUDI	Cabriolet		2.8	P Inj	Manual Auto		05	1996	12	1999	DBSR200
AUDI	Coupe	Mk1	1.8	P	Manual Auto		10	1984	07	1986	DBSR200
AUDI	Coupe	Mk1	1.8	P	GT	Inner boot without metal flange	08	1986	01	1988	DBSR200
AUDI	Coupe	Mk1	1.8	P	GT	Inner boot with metal flange	08	1986	01	1988	DBSR200
AUDI	Coupe	Mk1	1.9	P	GT Manual, Auto		03	1981	08	1983	DBSR200
AUDI	Coupe	Mk1	2.0	P	Manual Auto	Inner boot without metal flange	08	1983	07	1986	DBSR200
AUDI	Coupe	Mk1	2.0	P	Manual Auto	Inner boot with metal flange	08	1983	07	1986	DBSR200
AUDI	Coupe	Mk1	2.0	P	Quattro Manual Aul	Inner boot without metal flange	08	1983	07	1986	DBSR200
AUDI	Coupe	Mk1	2.0	P	Quattro Manual Aul	Inner boot with metal flange	08	1983	07	1986	DBSR200

Sheet1

AUDI	Coupe	Mk1	2.1	P		Inner boot without metal flange	07	1982	08	1984	DBSR200
AUDI	Coupe	Mk1	2.1	P		Inner boot with metal flange	07	1982	08	1984	DBSR200
AUDI	Coupe	Mk1	2.1	P	Quattro	Inner boot without metal flange	07	1982	08	1984	DBSR200
AUDI	Coupe	Mk1	2.1	P	Quattro	Inner boot with metal flange	07	1982	08	1984	DBSR200
AUDI	Coupe	Mk1	2.2	P Inj	Gti Manual, Auto	Inner boot without metal flange	04	1986	09	1987	DBSR200
AUDI	Coupe	Mk1	2.2	P Inj	Gti Manual, Auto	Inner boot with metal flange	04	1986	09	1987	DBSR200
AUDI	Coupe	Mk1	2.2	P Inj	Gti, Quattro Manua	Inner boot without metal flange	04	1986	09	1987	DBSR200
AUDI	Coupe	Mk1	2.2	P Inj	Gti, Quattro Manua	Inner boot with metal flange	04	1986	09	1987	DBSR200
AUDI	Coupe	Mk2	2.0	P Inj		Inner boot without metal flange	09	1989	09	1996	DBSR200
AUDI	Coupe	Mk2	2.0	P Inj		Inner boot with metal flange	09	1989	09	1996	DBSR200
AUDI	Coupe	Mk2	2.0	P Inj	Quattro	Inner boot without metal flange	09	1989	09	1996	DBSR200
AUDI	Coupe	Mk2	2.0	P Inj	Quattro	Inner boot with metal flange	09	1989	09	1996	DBSR200
AUDI	Coupe	Mk2	2.0	P Inj		Inner boot without metal flange	10	1992	12	1995	DBSR200
AUDI	Coupe	Mk2	2.0	P Inj		Inner boot with metal flange	10	1992	12	1995	DBSR200
AUDI	Coupe	Mk2	2.0	P Inj	Quattro	Inner boot without metal flange	10	1992	12	1995	DBSR200
AUDI	Coupe	Mk2	2.0	P Inj	Quattro	Inner boot with metal flange	10	1992	12	1995	DBSR200
AUDI	Coupe	Mk2	2.2	P		Inner boot without metal flange	10	1988	08	1989	DBSR200
AUDI	Coupe	Mk2	2.2	P		Inner boot with metal flange	10	1988	08	1989	DBSR200
AUDI	Coupe	Mk2	2.2	P	Quattro	Inner boot without metal flange	10	1988	08	1989	DBSR200
AUDI	Coupe	Mk2	2.2	P	Quattro	Inner boot with metal flange	10	1988	08	1989	DBSR200
AUDI	Coupe	Mk2	2.3	P	Manual Auto	Inner boot without metal flange	10	1988	08	1989	DBSR200
AUDI	Coupe	Mk2	2.3	P	Manual Auto	Inner boot with metal flange	10	1988	08	1989	DBSR200
AUDI	Coupe	Mk2	2.3	P	Quattro Manual Aut	Inner boot without metal flange	10	1988	08	1989	DBSR200
AUDI	Coupe	Mk2	2.3	P	Quattro Manual Aut	Inner boot with metal flange	10	1988	08	1989	DBSR200
AUDI	Coupe	Mk2	2.6	P Inj	Manual Auto		09	1992	09	1996	DBSR200
AUDI	Coupe	Mk2	2.6	P Inj	Quattro Manual Auto		09	1992	09	1996	DBSR200
AUDI	Coupe	Mk2	2.8	P Inj	Manual Auto		11	1991	07	1992	DBSR200
AUDI	Coupe	Mk2	2.8	P Inj	Quattro Manual Auto		11	1991	07	1992	DBSR200
AUDI	TT		1.8	P Inj	Fwd		03	2003			DBSR200
AUDI	TT		1.8	P Inj	Quattro, 4wd	Front	06	1999			DBSR200
AUDI	TT		1.8	P Inj	Quattro, 4wd	Rear	06	1999			DBSR200
AUTOBIANCHI	A112			P			11	1969	07	1985	DBSR100
AUTOBIANCHI	Y10			P			03	1985	12	1994	DBSR100
BMW	3 Series	E21		P Inj	320i		06	1975	08	1978	DBSR200
BMW	3 Series	E21		P Inj	320i		01	1977	08	1978	DBSR200
BMW	3 Series	E21		P Inj	320i		08	1978	09	1983	DBSR200

Sheet1

BMW	3 Series	E21	P Inj	320i		01	1977	09	1983	DBSR200
BMW	3 Series	E21	P	316		06	1975	08	1978	DBSR200
BMW	3 Series	E21	P	316		01	1977	08	1978	DBSR200
BMW	3 Series	E21	P	316		08	1978	09	1983	DBSR200
BMW	3 Series	E21	P	316		01	1977	09	1983	DBSR200
BMW	3 Series	E21	P	320		06	1975	08	1978	DBSR200
BMW	3 Series	E21	P	320		01	1977	08	1978	DBSR200
BMW	3 Series	E21	P	320		08	1978	09	1983	DBSR200
BMW	3 Series	E21	P	320		01	1977	09	1983	DBSR200
BMW	3 Series	E21	P Inj	323i		06	1975	08	1978	DBSR200
BMW	3 Series	E21	P Inj	323i		01	1977	08	1978	DBSR200
BMW	3 Series	E21	P Inj	323i		08	1978	09	1983	DBSR200
BMW	3 Series	E21	P Inj	323i		01	1977	09	1983	DBSR200
BMW	3 Series	E36	P Inj	316		04	1991	01	2001	DBSR300
BMW	3 Series	E36	P Inj	318		04	1991	01	2001	DBSR300
BMW	3 Series	E36	P Inj	320		04	1991	01	2001	DBSR300
BMW	3 Series	E36	P Inj	325		04	1991	01	2001	DBSR300
BMW	3 Series	E36	P Inj	328		04	1991	01	2001	DBSR300
BMW	3 Series	E36	P	M3		05	1993	10	1999	DBSR300
BMW	5 Series	E39	P Inj	523		04	1996	09	2000	DBSR300
BMW	5 Series	E39	P Inj	528		04	1996	09	2000	DBSR300
BMW	5 Series	E39	P Inj	520		04	1996	04	2004	DBSR300
BMW	5 Series	E39	P Inj	530		09	1998	04	2004	DBSR300
BMW	5 Series	E39	D	525		09	2000	04	2004	DBSR300
BMW	5 Series	E39	P Inj	525		09	2000	04	2004	DBSR300
BMW	Z3		1.9 P Inj			09	1996	06	2003	DBSR300
BMW	Z3		2.0 P Inj			06	1999	08	2000	DBSR300
BMW	Z3		2.2 P Inj			10	2000	06	2003	DBSR300
BMW	Z3		2.8 P Inj			06	1997	06	2000	DBSR300
BMW	Z3		3.0 P Inj			06	2000	06	2003	DBSR300
BMW	Z3		3.2 P Inj			01	1998	06	2003	DBSR300
CITROEN	BX		P	14	Inner boot with tin case	08	1988	10	1991	DBSR300
CITROEN	BX		P	14	Inner boot with tin case	08	1983	07	1988	DBSR300
CITROEN	BX		P	14	Inner boot without tin case	08	1988	10	1991	DBSR300
CITROEN	BX		P	14	Inner boot without tin case	08	1983	07	1988	DBSR300
CITROEN	BX		P Inj	16		08	1983	12	1993	DBSR300

Sheet1

CITROEN	BX		P Inj	16		04	1984	12	1993	DBSR300
CITROEN	BX		D	19		03	1984	12	1993	DBSR300
CITROEN	BX		P Inj	19 4wd	Front	01	1990	12	1993	DBSR300
CITROEN	BX		P Inj	19 4wd	Rear	01	1990	12	1993	DBSR300
CITROEN	BX		P Inj	19 Fwd		03	1984	12	1993	DBSR300
CITROEN	BX		D	17		09	1985	05	1993	DBSR300
CITROEN	BX		D Turbo	17		09	1985	05	1993	DBSR300
CITROEN	CX	2.0	P			01	1978	02	1991	DBSR300
CITROEN	CX	2.2	P			01	1978	02	1991	DBSR300
CITROEN	CX	2.4	P			01	1978	02	1991	DBSR300
CITROEN	CX	2.5	D Turbo			01	1978	02	1991	DBSR300
CITROEN	CX	2.5	P			01	1978	02	1991	DBSR300
CITROEN	GS	1.0	P		Trilobal inner joint	01	1976	12	1985	DBSR200
CITROEN	GS	1.1	P		Trilobal inner joint	01	1976	12	1985	DBSR200
CITROEN	GS	1.2	P		Trilobal inner joint	01	1976	12	1985	DBSR200
CITROEN	GSA	1.0	P		Trilobal inner joint	01	1976	12	1985	DBSR200
CITROEN	GSA	1.1	P		Trilobal inner joint	01	1976	12	1985	DBSR200
CITROEN	GSA	1.2	P		Trilobal inner joint	01	1976	12	1985	DBSR200
CITROEN	LNA					01	1976	12	1978	DBSR100
CITROEN	LNA					01	1978	12	1985	DBSR200
CITROEN	LNA	1.1	P			07	1982	12	1985	DBSR200
CITROEN	Synergie	1.9	D Turbo			10	1995	05	2000	DBSR300
CITROEN	Synergie	2.0	P Inj	Manual		10	1995	07	2002	DBSR300
CITROEN	Synergie	2.0	P Inj	Semi Auto		07	2000	06	2002	DBSR300
CITROEN	Synergie	2.0	D Turbo			10	1999	06	2002	DBSR300
CITROEN	Visa	0.65	P		Trilobal inner joint	11	1979	08	1985	DBSR200
CITROEN	Visa	1.0	P		Ball bearing type outer joint	01	1979	05	1987	DBSR200
CITROEN	Visa	1.0	P		Trilobal/claw type outer joint	01	1979	05	1987	DBSR200
CITROEN	Visa	1.0	P		Inner boot with tin case	01	1979	05	1987	DBSR200
CITROEN	Visa	1.0	P		Inner boot without tin case	01	1979	05	1987	DBSR200
CITROEN	Visa	1.1	P		Ball bearing type outer joint	01	1979	05	1987	DBSR200
CITROEN	Visa	1.1	P		Trilobal/claw type outer joint	01	1979	05	1987	DBSR200
CITROEN	Visa	1.1	P		Inner boot with tin case	01	1979	05	1987	DBSR200
CITROEN	Visa	1.1	P		Inner boot without tin case	01	1979	05	1987	DBSR200
CITROEN	Visa	1.4	P		Ball bearing type outer joint	01	1979	05	1987	DBSR200
CITROEN	Visa	1.4	P		Trilobal/claw type outer joint	01	1979	05	1987	DBSR200

Sheet1

CITROEN	Visa	1.4	P		Inner boot with tin case	01	1979	05	1987	DBSR200
CITROEN	Visa	1.4	P		Inner boot without tin case	01	1979	05	1987	DBSR200
CITROEN	Visa	1.6	P Inj	Gti	Ball bearing type outer joint	04	1985	12	1987	DBSR200
CITROEN	Visa	1.6	P Inj	Gti	Trilobal/claw type outer joint	04	1985	12	1987	DBSR200
CITROEN	Visa	1.8	D		Ball bearing type outer joint	04	1985	10	1988	DBSR200
CITROEN	Visa	1.8	D		Trilobal/claw type outer joint	04	1985	10	1988	DBSR200
CITROEN	Xantia	1.6	P		Inner boot for 77mm joint	07	1993	04	2001	DBSR300
CITROEN	Xantia	1.6	P		Inner boot for 88mm joint	07	1993	04	2001	DBSR300
CITROEN	Xantia	1.6	P		Outer boot for 83mm joint	07	1993	04	2001	DBSR300
CITROEN	Xantia	1.6	P		Outer boot for 90mm joint	07	1993	04	2001	DBSR300
CITROEN	Xantia	1.8	P		Inner boot for 77mm joint	07	1993	04	2001	DBSR300
CITROEN	Xantia	1.8	P		Inner boot for 88mm joint	07	1993	04	2001	DBSR300
CITROEN	Xantia	1.8	P		Outer boot for 83mm joint	07	1993	04	2001	DBSR300
CITROEN	Xantia	1.8	P		Outer boot for 90mm joint	07	1993	04	2001	DBSR300
CITROEN	Xantia	1.9	D Turbo		Inner boot for 76mm joint	07	1993	10	2000	DBSR300
CITROEN	Xantia	1.9	D Turbo		Inner boot for 88mm joint	07	1993	10	2000	DBSR300
CITROEN	Xantia	1.9	D Turbo		Outer boot for 25mm shaft	07	1993	10	2000	DBSR300
CITROEN	Xantia	1.9	D Turbo		Outer boot for 38mm shaft	07	1993	10	2000	DBSR300
CITROEN	Xantia	1.9	D		Inner boot for 77mm joint	07	1993	04	2001	DBSR300
CITROEN	Xantia	1.9	D		Inner boot for 88mm joint	07	1993	04	2001	DBSR300
CITROEN	Xantia	1.9	D		Outer boot for 83mm joint	07	1993	04	2001	DBSR300
CITROEN	Xantia	1.9	D		Outer boot for 90mm joint	07	1993	04	2001	DBSR300
CITROEN	Xantia	2.0	D turbo		Inner boot for 76mm joint	05	1993	04	2001	DBSR300
CITROEN	Xantia	2.0	D turbo		Inner boot for 88mm joint	05	1993	04	2001	DBSR300
CITROEN	Xantia	2.0	D turbo		Outer boot for 100mm joint	05	1993	04	2001	DBSR300
CITROEN	Xantia	2.0	D turbo		Outer boot for 90mm joint	05	1993	04	2001	DBSR300
CITROEN	Xantia	2.0	P		Inner boot for 76mm joint	05	1993	04	2001	DBSR300
CITROEN	Xantia	2.0	P		Inner boot for 88mm joint	05	1993	04	2001	DBSR300
CITROEN	Xantia	2.0	P		Outer boot for 100mm joint	05	1993	04	2001	DBSR300
CITROEN	Xantia	2.0	P		Outer boot for 90mm joint	05	1993	04	2001	DBSR300
CITROEN	Xantia	2.1	D Turbo			06	1997	01	1999	DBSR300
CITROEN	Xantia	3.0	P Inj	V6		06	1997	10	2000	DBSR300
CITROEN	XM	2.0	P Inj		Inner boot for 76mm joint	05	1991	12	1994	DBSR600
CITROEN	XM	2.0	P Inj		Inner boot for 85mm joint	05	1991	12	1994	DBSR600
CITROEN	XM	2.0	P Inj		Inner boot for 90mm joint	05	1991	12	1994	DBSR600
CITROEN	XM	2.0	P		Inner boot for 85mm joint	01	1993			DBSR600

Sheet1

CITROEN	XM	2.0	P		Inner boot for 90mm joint	01	1993			DBSR600
CITROEN	XM	2.0	P		Outer boot for 100mm joint	01	1993			DBSR600
CITROEN	XM	2.0	P		Outer boot for 90mm joint	01	1993			DBSR600
CITROEN	XM	2.0	P Turbo		Inner boot for 85mm joint	01	1993			DBSR600
CITROEN	XM	2.0	P Turbo		Inner boot for 90mm joint	01	1993			DBSR600
CITROEN	XM	2.0	P Turbo		Outer boot for 100mm joint	01	1993			DBSR600
CITROEN	XM	2.0	P Turbo		Outer boot for 90mm joint	01	1993			DBSR600
CITROEN	XM	2.1	D		Inner boot for 76mm joint	05	1991			DBSR600
CITROEN	XM	2.1	D		Inner boot for 85mm joint	05	1991			DBSR600
CITROEN	XM	2.1	D		Inner boot for 90mm joint	05	1991			DBSR600
CITROEN	XM	2.1	D		Outer boot for 100mm joint	05	1991			DBSR600
CITROEN	XM	2.1	D		Outer boot for 90mm joint	05	1991			DBSR600
CITROEN	XM	2.1	D		Outer boot for 95mm joint	05	1991			DBSR600
CITROEN	XM	2.5	D Turbo		Inner boot for 76mm joint	05	1991			DBSR600
CITROEN	XM	2.5	D Turbo		Inner boot for 85mm joint	05	1991			DBSR600
CITROEN	XM	2.5	D Turbo		Inner boot for 90mm joint	05	1991			DBSR600
CITROEN	XM	2.5	D Turbo		Outer boot for 100mm joint	05	1991			DBSR600
CITROEN	XM	2.5	D Turbo		Outer boot for 90mm joint	05	1991			DBSR600
CITROEN	XM	2.5	D Turbo		Outer boot for 95mm joint	05	1991			DBSR600
CITROEN	XM	3.0	P Inj	V6	Inner boot for 76mm joint	05	1991			DBSR600
CITROEN	XM	3.0	P Inj	V6	Inner boot for 85mm joint	05	1991			DBSR600
CITROEN	XM	3.0	P Inj	V6	Inner boot for 90mm joint	05	1991			DBSR600
CITROEN	XM	3.0	P Inj	V6	Outer boot for 100mm joint	05	1991			DBSR600
CITROEN	XM	3.0	P Inj	V6	Outer boot for 95mm joint	05	1991			DBSR600
CITROEN	Xsara	1.4	P Inj		Inner boot with tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.4	P Inj		Inner boot without tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.4	P Inj	ABS	Trilobal inner joint	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj		Inner boot with tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj		Inner boot without tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj		Outer boot for 81mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj		Outer boot for 86mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj		Inner boot with tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj		Inner boot without tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj		Outer boot for 81mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj		Outer boot for 86mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj	Auto	Inner boot with tin case	11	1997	12	2000	DBSR100

Sheet1

CITROEN	Xsara	1.6	P Inj	Auto	Inner boot without tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj	Auto	Outer boot for 81mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj	Auto	Outer boot for 86mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj	Auto	Inner boot with tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj	Auto	Inner boot without tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj	Auto	Outer boot for 81mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj	Auto	Outer boot for 86mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj	Manual	Trilobal inner joint	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.6	P Inj	Manual	Trilobal inner joint	11	1997	12	2000	DBSR100
CITROEN	Xsara	1.8	P Inj			11	1997	12	2000	DBSR100
CITROEN	Xsara	1.9	D			11	1997	12	2000	DBSR100
CITROEN	Xsara	1.9	D Turbo			11	1997	12	2000	DBSR100
CITROEN	Xsara	2.0	P Inj			03	1998	12	2000	DBSR100
CITROEN	Xsara Picasso	1.4	P Inj		Inner boot with tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.4	P Inj		Inner boot without tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.4	P Inj	ABS	Trilobal inner joint	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj		Inner boot with tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj		Inner boot without tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj		Outer boot for 81mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj		Outer boot for 86mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj		Inner boot with tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj		Inner boot without tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj		Outer boot for 81mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj		Outer boot for 86mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj	Auto	Inner boot with tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj	Auto	Inner boot without tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj	Auto	Outer boot for 81mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj	Auto	Outer boot for 86mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj	Auto	Inner boot with tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj	Auto	Inner boot without tin case	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj	Auto	Outer boot for 81mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj	Auto	Outer boot for 86mm joint	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj	Manual	Trilobal inner joint	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.6	P Inj	Manual	Trilobal inner joint	11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.8	P Inj			11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	1.9	D			11	1997	12	2000	DBSR100

Sheet1

CITROEN	Xsara Picasso	1.9	D Turbo		11	1997	12	2000	DBSR100
CITROEN	Xsara Picasso	2.0	P Inj		03	1998	12	2000	DBSR100
CITROEN	ZX	1.1	P Inj		06	1991	02	1998	DBSR200
CITROEN	ZX	1.4	P Inj	Inner boot with tin case	06	1991	02	1998	DBSR200
CITROEN	ZX	1.4	P Inj	Inner boot without tin case	06	1991	02	1998	DBSR200
CITROEN	ZX	1.6	P Inj		06	1991	11	1997	DBSR200
CITROEN	ZX	1.8	D		06	1991	02	1998	DBSR200
CITROEN	ZX	1.9	D		11	1991	02	1998	DBSR200
CITROEN	ZX	1.9	D Turbo		07	1992	02	1998	DBSR200
CITROEN LCV	Berlingo Van	1.4	P Inj		10	1998			DBSR500
CITROEN LCV	Berlingo Van	1.4	P Inj		10	1998			DBSR500
CITROEN LCV	Berlingo Van	1.8	D		10	1996	07	1998	DBSR500
CITROEN LCV	Berlingo Van	1.8	D		10	1996	07	1998	DBSR500
CITROEN LCV	Berlingo Van	1.9	D		10	1996			DBSR500
CITROEN LCV	Berlingo Van	1.9	D		10	1996			DBSR500
CITROEN LCV	C15	1.1	P Inj		01	1985	03	1994	DBSR200
CITROEN LCV	C15	1.1	P Inj	Ball bearing type outer joint	01	1985	06	1987	DBSR200
CITROEN LCV	C15	1.1	P Inj	Trilobal/claw type outer joint	01	1985	06	1987	DBSR200
CITROEN LCV	C15	1.1	P Inj	Inner boot with tin case	01	1985	06	1987	DBSR200
CITROEN LCV	C15	1.1	P Inj	Inner boot with tin case	01	1985	06	1987	DBSR200
CITROEN LCV	C15	1.1	P Inj	Inner boot without tin case	01	1985	03	1994	DBSR200
CITROEN LCV	C15	1.1	P Inj	Outer boot with 1 locating lip	01	1985	03	1994	DBSR200
CITROEN LCV	C15	1.1	P Inj	Outer boot with 2 locating lips	01	1985	03	1994	DBSR200
CITROEN LCV	C15	1.4	P Inj		01	1985	03	1994	DBSR200
CITROEN LCV	C15	1.4	P Inj	Ball bearing type outer joint	01	1985	06	1987	DBSR200
CITROEN LCV	C15	1.4	P Inj	Trilobal/claw type outer joint	01	1985	06	1987	DBSR200
CITROEN LCV	C15	1.4	P Inj	Inner boot with tin case	01	1985	06	1987	DBSR200
CITROEN LCV	C15	1.4	P Inj	Inner boot with tin case	01	1985	06	1987	DBSR200
CITROEN LCV	C15	1.4	P Inj	Inner boot without tin case	01	1985	03	1994	DBSR200
CITROEN LCV	C15	1.4	P Inj	Outer boot with 1 locating lip	01	1985	03	1994	DBSR200
CITROEN LCV	C15	1.4	P Inj	Outer boot with 2 locating lips	01	1985	03	1994	DBSR200
CITROEN LCV	C15	1.8	D		06	1985	10	2001	DBSR200
CITROEN LCV	C15	1.8	D	Ball bearing type outer joint	06	1985	10	2001	DBSR200
CITROEN LCV	C15	1.8	D	Trilobal/claw type outer joint	06	1985	10	2001	DBSR200
CITROEN LCV	C25	1.8	P Inj		01	1982	06	1994	DBSR200
CITROEN LCV	C25	1.9	D		01	1982	06	1994	DBSR200

Sheet1

CITROEN LCV	C25		2.0	P Inj		01	1982	06	1994	DBSR200
CITROEN LCV	C25		2.5	D Turbo		01	1982	06	1984	DBSR200
CITROEN LCV	C25		2.5	D		01	1982	06	1994	DBSR200
CITROEN LCV	Dispatch		1.9	D Turbo		09	1996	06	2000	DBSR300
CITROEN LCV	Dispatch		1.9	D		09	1996			DBSR300
CITROEN LCV	Dispatch		2.0	D Turbo		03	2000			DBSR300
CITROEN LCV	Relay		1.9	D		06	1994			DBSR300
CITROEN LCV	Relay		2.5	D		06	1994			DBSR300
CITROEN LCV	Relay		2.5	D		06	1994			DBSR300
CITROEN LCV	Relay		2.5	D Turbo		06	1994			DBSR300
CITROEN LCV	Relay		2.5	D Turbo		06	1994			DBSR300
CITROEN LCV	Relay		2.8	P Inj		10	2000			DBSR300
CITROEN LCV	Relay		2.8	P Inj		10	2000			DBSR300
DAEWOO	Leganza		2.0	P Inj		09	1997	06	2002	DBSR200
DAEWOO	Nubira	Mk1	1.6	P Inj		09	1997	06	2002	DBSR200
DAEWOO	Nubira	Mk1	2.0	P Inj		09	1997	02	2006	DBSR200
DAIHATSU	Applause		1.6	P Inj	Trilobal inner joint	01	1990	12	1995	DBSR200
DAIHATSU	Charade	Mk2	1.0	P	G11	04	1983	04	1987	DBSR100
DAIHATSU	Charade	Mk2	1.0	P Turbo	G11	04	1983	04	1987	DBSR100
DAIHATSU	Charade	Mk2	1.0	D	G30	10	1983	04	1987	DBSR100
DAIHATSU	Charade	Mk2	1.0	D Turbo	G30	10	1983	04	1987	DBSR100
DAIHATSU	Charade	Mk3	1.0	P Inj	G100	05	1987	02	1993	DBSR200
DAIHATSU	Charade	Mk3	1.0	D Turbo	G101	05	1987	06	1993	DBSR200
DAIHATSU	Charade	Mk3	1.0	P Turbo	G100	02	1989	02	1993	DBSR200
DAIHATSU	Charade	Mk3	1.0	P Turbo	Gti G100	02	1989	02	1993	DBSR200
DAIHATSU	Charade	Mk3	1.3	P Inj	G102	04	1989	06	1993	DBSR200
DAIHATSU	Charade	Mk3	1.3	P Inj	G102	04	1989	06	1993	DBSR200
DAIHATSU	Charade	Mk4	1.3	P	G200	06	1993	10	2000	DBSR200
DAIHATSU	Charade	Mk4	1.5	P Inj	G201	10	1994	04	2000	DBSR200
DAIHATSU	Charade	Mk4	1.6	P	G203	07	1993	03	1996	DBSR200
DAIHATSU	Cuore		0.85	P Inj	L501	05	1997	12	1998	DBSR200
DAIHATSU	Cuore		1.0	P Inj	L501	12	1998	01	2002	DBSR200
FIAT	126		0.6	P		01	1972	12	1977	DBSR100
FIAT	126		0.65	P	Inner boot with metal bush	01	1977	12	1987	DBSR100
FIAT	126		0.65	P	Inner boot with nylon bush	01	1977	12	1987	DBSR100
FIAT	127		0.9	P	Inner boot secured by clip (metal bush)	10	1971	10	1977	DBSR100

Sheet1

FIAT	127	0.9	P		Inner boot secured by clip (nylon bush)	10	1971	10	1977	DBSR100
FIAT	127	0.9	P		Inner boot secured by plate (metal bush)	10	1971	10	1977	DBSR100
FIAT	127	0.9	P		Inner boot secured by plate (nylon bush)	10	1971	10	1977	DBSR100
FIAT	127	0.9	P		Inner boot with metal bush	11	1977	05	1983	DBSR100
FIAT	127	0.9	P		Inner boot with nylon bush	11	1977	05	1983	DBSR100
FIAT	127	1.05	P		Inner boot with metal bush	07	1977	05	1983	DBSR100
FIAT	127	1.05	P		Inner boot with metal bush	01	1982	05	1983	DBSR100
FIAT	127	1.05	P		Inner boot with metal bush	01	1978	09	1980	DBSR100
FIAT	127	1.05	P		Inner boot with nylon bush	01	1982	05	1983	DBSR100
FIAT	127	1.05	P		Inner boot with nylon bush	01	1978	09	1980	DBSR100
FIAT	127	1.05	P		Inner boot with nylon bush	07	1977	05	1983	DBSR100
FIAT	127	1.3	P	GT		04	1982	10	1983	DBSR100
FIAT	128	1.1	P		Inner boot secured by clip (metal bush)	03	1969	12	1981	DBSR100
FIAT	128	1.1	P		Inner boot secured by clip (nylon bush)	03	1969	12	1981	DBSR100
FIAT	128	1.1	P		Inner boot secured by plate (metal bush)	03	1969	12	1981	DBSR100
FIAT	128	1.1	P		Inner boot secured by plate (nylon bush)	03	1969	12	1981	DBSR100
FIAT	128	1.1	P		Inner boot with metal bush	03	1980	12	1981	DBSR100
FIAT	128	1.1	P		Inner boot with nylon bush	03	1980	12	1981	DBSR100
FIAT	128	1.3	P		Inner boot secured by clip (metal bush)	01	1974	12	1979	DBSR100
FIAT	128	1.3	P		Inner boot secured by clip (nylon bush)	01	1974	12	1979	DBSR100
FIAT	128	1.3	P		Inner boot secured by plate (metal bush)	01	1974	12	1979	DBSR100
FIAT	128	1.3	P		Inner boot secured by plate (nylon bush)	01	1974	12	1979	DBSR100
FIAT	128	1.3	P		Inner boot with metal bush	01	1974	12	1979	DBSR100
FIAT	128	1.3	P		Inner boot with nylon bush	01	1974	12	1979	DBSR100
FIAT	131	1.3	P			01	1978	12	1982	DBSR200
FIAT	131	1.3	P			01	1978	12	1982	DBSR200
FIAT	131	1.4	P			01	1982	12	1984	DBSR200
FIAT	131	1.6	P			01	1978	12	1982	DBSR200
FIAT	131	2.0	P			01	1982	12	1984	DBSR200
FIAT	Brava	1.2	P Inj			02	1999	12	2001	DBSR300
FIAT	Brava	1.4	P Inj			01	1996	02	1999	DBSR300
FIAT	Brava	1.6	P Inj	Auto		01	1996	03	2001	DBSR300
FIAT	Brava	1.6	P Inj	Manual		01	1996	12	2001	DBSR300
FIAT	Brava	1.6	P Inj	Manual	Inner boot with bush	01	1996	03	1999	DBSR300
FIAT	Brava	1.6	P Inj	Manual	Inner boot without bush	01	1996	03	1999	DBSR300
FIAT	Brava	1.8	P Inj			01	1996	03	2001	DBSR300

Sheet1

FIAT	Brava	1.9	D Turbo			10	1996	12	2001	DBSR300
FIAT	Bravo	1.2	P Inj			02	1999	12	2001	DBSR300
FIAT	Bravo	1.4	P Inj			01	1996	02	1999	DBSR300
FIAT	Bravo	1.6	P Inj			01	1996	12	2001	DBSR300
FIAT	Bravo	1.6	P Inj		Inner boot with bush	01	1996	03	1999	DBSR300
FIAT	Bravo	1.6	P Inj		Inner boot without bush	01	1996	03	1999	DBSR300
FIAT	Bravo	1.8	P Inj			01	1996	03	2001	DBSR300
FIAT	Bravo	1.9	D Turbo			10	1996	12	2001	DBSR300
FIAT	Bravo	2.0	P Inj	HGT		03	1997	10	2000	DBSR300
FIAT	Cinquecento	0.9	P		LHS, Inner boot with bush	05	1993	05	1998	DBSR100
FIAT	Cinquecento	0.9	P		LHS, Inner boot without bush	05	1993	05	1998	DBSR100
FIAT	Cinquecento	0.9	P		RHS, Inner boot with bush	05	1993	05	1998	DBSR100
FIAT	Cinquecento	0.9	P		RHS, Inner boot without bush	05	1993	05	1998	DBSR100
FIAT	Cinquecento	1.1	P		LHS, Inner boot with bush	05	1993	05	1998	DBSR100
FIAT	Cinquecento	1.1	P		LHS, Inner boot without bush	05	1993	05	1998	DBSR100
FIAT	Cinquecento	1.1	P		RHS, Inner boot with bush	05	1993	05	1998	DBSR100
FIAT	Cinquecento	1.1	P		RHS, Inner boot without bush	05	1993	05	1998	DBSR100
FIAT	Croma	1.6	P			05	1986	12	1990	DBSR300
FIAT	Croma	2.0	P Inj			05	1986	01	1994	DBSR300
FIAT	Croma	2.0	P Turbo			10	1986	01	1994	DBSR400
FIAT	Panda	Mk1	0.8	P		01	1984	04	1986	DBSR100
FIAT	Panda	Mk1	0.9	P	45	10	1982	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	06	1981	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	06	1981	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	10	1982	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	06	1981	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	06	1981	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	12	1984	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	12	1984	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	12	1984	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	12	1984	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	12	1984	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	12	1984	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	12	1984	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	12	1984	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	12	1984	12	1984	DBSR100
FIAT	Panda	Mk1	0.9	P	45	12	1984	12	1984	DBSR100
FIAT	Panda	Mk1	1.0	P	4wd	09	1984	04	1986	DBSR100

Sheet1

FIAT	Panda	Mk1	1.0	P	4wd	Rear	09	1984	04	1986	DBSR100
FIAT	Panda	Mk2	0.75	P		LHS, Inner boot with 23mm metal bush	04	1986	09	1987	DBSR100
FIAT	Panda	Mk2	0.75	P		LHS, Inner boot with 23mm metal bush	04	1986	09	1987	DBSR100
FIAT	Panda	Mk2	0.75	P		LHS, Inner boot with 23mm nylon bush	04	1986	09	1987	DBSR100
FIAT	Panda	Mk2	0.75	P		LHS, Inner boot with 23mm nylon bush	04	1986	09	1987	DBSR100
FIAT	Panda	Mk2	0.75	P		LHS, Inner boot with 25mm metal bush	04	1986	09	1987	DBSR100
FIAT	Panda	Mk2	0.75	P		LHS, Inner boot with 25mm metal bush	04	1986	09	1987	DBSR100
FIAT	Panda	Mk2	0.75	P		LHS, Inner boot with 25mm nylon bush	04	1986	09	1987	DBSR100
FIAT	Panda	Mk2	0.75	P		LHS, Inner boot with 25mm nylon bush	04	1986	09	1987	DBSR100
FIAT	Panda	Mk2	0.75	P		LHS, Inner boot with bush	10	1987	06	1992	DBSR100
FIAT	Panda	Mk2	0.75	P		LHS, Inner boot without bush	10	1987	06	1992	DBSR100
FIAT	Panda	Mk2	0.75	P		RHS, Inner boot with bush	10	1987	06	1992	DBSR100
FIAT	Panda	Mk2	0.75	P		RHS, Inner boot with metal bush	04	1986	09	1987	DBSR100
FIAT	Panda	Mk2	0.75	P		RHS, Inner boot with metal bush	04	1986	09	1987	DBSR100
FIAT	Panda	Mk2	0.75	P		RHS, Inner boot with nylon bush	04	1986	09	1987	DBSR100
FIAT	Panda	Mk2	0.75	P		RHS, Inner boot with nylon bush	04	1986	09	1987	DBSR100
FIAT	Panda	Mk2	0.75	P		RHS, Inner boot without bush	10	1987	06	1992	DBSR100
FIAT	Panda	Mk2	0.9	P		LHS, Inner boot with metal bush	01	1990	11	1990	DBSR100
FIAT	Panda	Mk2	0.9	P		LHS, Inner boot with metal bush	10	1991	06	1992	DBSR100
FIAT	Panda	Mk2	0.9	P		LHS, Inner boot with metal bush	01	1990	11	1990	DBSR100
FIAT	Panda	Mk2	0.9	P		LHS, Inner boot with metal bush	10	1991	06	1992	DBSR100
FIAT	Panda	Mk2	0.9	P		LHS, Inner boot with nylon bush	10	1991	06	1992	DBSR100
FIAT	Panda	Mk2	0.9	P		LHS, Inner boot with nylon bush	01	1990	11	1990	DBSR100
FIAT	Panda	Mk2	0.9	P		LHS, Inner boot with nylon bush	01	1990	11	1990	DBSR100
FIAT	Panda	Mk2	0.9	P		LHS, Inner boot with nylon bush	10	1991	06	1992	DBSR100
FIAT	Panda	Mk2	0.9	P		RHS, Inner boot with metal bush	01	1990	11	1990	DBSR100
FIAT	Panda	Mk2	0.9	P		RHS, Inner boot with metal bush	10	1991	06	1992	DBSR100
FIAT	Panda	Mk2	0.9	P		RHS, Inner boot with metal bush	10	1991	06	1992	DBSR100
FIAT	Panda	Mk2	0.9	P		RHS, Inner boot with metal bush	01	1990	11	1990	DBSR100
FIAT	Panda	Mk2	0.9	P		RHS, Inner boot with nylon bush	10	1991	06	1992	DBSR100
FIAT	Panda	Mk2	0.9	P		RHS, Inner boot with nylon bush	01	1990	11	1990	DBSR100
FIAT	Panda	Mk2	0.9	P		RHS, Inner boot with nylon bush	01	1990	11	1990	DBSR100
FIAT	Panda	Mk2	0.9	P		RHS, Inner boot with nylon bush	10	1991	06	1992	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	4wd	Front	01	1987	12	1991	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	4wd	Rear	01	1987	12	1991	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	LHS, Inner boot with 23mm metal bush	01	1987	09	1987	DBSR100

Sheet1

FIAT	Panda	Mk2	1.0	P Inj	Fwd	LHS, Inner boot with 23mm metal bush	01	1987	09	1987	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	LHS, Inner boot with 23mm nylon bush	01	1987	09	1987	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	LHS, Inner boot with 23mm nylon bush	01	1987	09	1987	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	LHS, Inner boot with 25mm metal bush	01	1987	09	1987	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	LHS, Inner boot with 25mm metal bush	01	1987	09	1987	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	LHS, Inner boot with 25mm nylon bush	01	1987	09	1987	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	LHS, Inner boot with 25mm nylon bush	01	1987	09	1987	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	LHS, Inner boot with bush	01	1987	07	1995	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	LHS, Inner boot without bush	01	1987	07	1995	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	RHS, Inner boot with bush	01	1987	07	1995	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	RHS, Inner boot with metal bush	01	1987	09	1987	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	RHS, Inner boot with metal bush	01	1987	09	1987	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	RHS, Inner boot with nylon bush	01	1987	09	1987	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	RHS, Inner boot with nylon bush	01	1987	09	1987	DBSR100
FIAT	Panda	Mk2	1.0	P Inj	Fwd	RHS, Inner boot without bush	01	1987	07	1995	DBSR100
FIAT	Panda	Mk2	1.1	P Inj			03	1993	07	1995	DBSR100
FIAT	Punto	Mk1	1.1	P Inj			03	1994	05	1997	DBSR300
FIAT	Punto	Mk1	1.2	P Inj	Auto		03	1994	09	1999	DBSR300
FIAT	Punto	Mk1	1.2	P Inj	Manual		03	1994	09	1999	DBSR300
FIAT	Punto	Mk1	1.4	P Turbo	GT		03	1994	09	1999	DBSR300
FIAT	Punto	Mk1	1.6	P Inj			08	1994	05	1997	DBSR300
FIAT	Punto	Mk1	1.7	D Turbo			10	1996	09	1999	DBSR300
FIAT	Punto	Mk1	1.7	D Turbo			06	1994	09	1996	DBSR300
FIAT	Punto	Mk1	1.7	D			06	1995	11	1996	DBSR300
FIAT	Punto	Mk2	1.2	P Inj	Auto		10	1999			DBSR300
FIAT	Punto	Mk2	1.2	P Inj	Manual		10	1999			DBSR300
FIAT	Punto	Mk2	1.8	P Inj			10	1999			DBSR300
FIAT	Punto	Mk2	1.9	D			10	1999			DBSR300
FIAT	Punto	Mk2	1.9	D Turbo			10	1999			DBSR300
FIAT	Regata		1.3	P	70		01	1984	09	1990	DBSR400
FIAT	Regata		1.3	P	70		01	1984	09	1990	DBSR100
FIAT	Regata		1.3	P	70	Inner boot with metal bush	01	1984	03	1985	DBSR400
FIAT	Regata		1.3	P	70	Inner boot with metal bush	01	1984	03	1985	DBSR100
FIAT	Regata		1.3	P	70	Inner boot with nylon bush	01	1984	03	1985	DBSR400
FIAT	Regata		1.3	P	70	Inner boot with nylon bush	01	1984	03	1985	DBSR100
FIAT	Regata		1.3	P	70	LHS, Inner boot with 23mm metal bush	04	1985	09	1987	DBSR400

Sheet1

FIAT	Regata	1.3	P	70	LHS, Inner boot with 23mm metal bush	04	1985	09	1987	DBSR100
FIAT	Regata	1.3	P	70	LHS, Inner boot with 23mm metal bush	04	1985	09	1987	DBSR400
FIAT	Regata	1.3	P	70	LHS, Inner boot with 23mm metal bush	04	1985	09	1987	DBSR100
FIAT	Regata	1.3	P	70	LHS, Inner boot with 23mm nylon bush	04	1985	09	1987	DBSR400
FIAT	Regata	1.3	P	70	LHS, Inner boot with 23mm nylon bush	04	1985	09	1987	DBSR100
FIAT	Regata	1.3	P	70	LHS, Inner boot with 23mm nylon bush	04	1985	09	1987	DBSR400
FIAT	Regata	1.3	P	70	LHS, Inner boot with 23mm nylon bush	04	1985	09	1987	DBSR100
FIAT	Regata	1.3	P	70	LHS, Inner boot with 25mm metal bush	04	1985	09	1987	DBSR400
FIAT	Regata	1.3	P	70	LHS, Inner boot with 25mm metal bush	04	1985	09	1987	DBSR100
FIAT	Regata	1.3	P	70	LHS, Inner boot with 25mm metal bush	04	1985	09	1987	DBSR400
FIAT	Regata	1.3	P	70	LHS, Inner boot with 25mm metal bush	04	1985	09	1987	DBSR100
FIAT	Regata	1.3	P	70	LHS, Inner boot with 25mm nylon bush	04	1985	09	1987	DBSR400
FIAT	Regata	1.3	P	70	LHS, Inner boot with 25mm nylon bush	04	1985	09	1987	DBSR100
FIAT	Regata	1.3	P	70	LHS, Inner boot with 25mm nylon bush	04	1985	09	1987	DBSR400
FIAT	Regata	1.3	P	70	LHS, Inner boot with 25mm nylon bush	04	1985	09	1987	DBSR100
FIAT	Regata	1.3	P	70	LHS, Inner boot with bush	10	1987	09	1990	DBSR400
FIAT	Regata	1.3	P	70	LHS, Inner boot with bush	10	1987	09	1990	DBSR100
FIAT	Regata	1.3	P	70	LHS, Inner boot without bush	10	1987	09	1990	DBSR400
FIAT	Regata	1.3	P	70	LHS, Inner boot without bush	10	1987	09	1990	DBSR100
FIAT	Regata	1.3	P	70	RHS, Inner boot with 23mm metal bush	04	1985	09	1987	DBSR400
FIAT	Regata	1.3	P	70	RHS, Inner boot with 23mm metal bush	04	1985	09	1987	DBSR100
FIAT	Regata	1.3	P	70	RHS, Inner boot with 23mm nylon bush	04	1985	09	1987	DBSR400
FIAT	Regata	1.3	P	70	RHS, Inner boot with 23mm nylon bush	04	1985	09	1987	DBSR100
FIAT	Regata	1.3	P	70	RHS, Inner boot with 25mm metal bush	04	1985	09	1987	DBSR400
FIAT	Regata	1.3	P	70	RHS, Inner boot with 25mm metal bush	04	1985	09	1987	DBSR100
FIAT	Regata	1.3	P	70	RHS, Inner boot with 25mm nylon bush	04	1985	09	1987	DBSR400
FIAT	Regata	1.3	P	70	RHS, Inner boot with 25mm nylon bush	04	1985	09	1987	DBSR100
FIAT	Regata	1.3	P	70	RHS, Inner boot with bush	10	1987	09	1990	DBSR400
FIAT	Regata	1.3	P	70	RHS, Inner boot with bush	10	1987	09	1990	DBSR100
FIAT	Regata	1.3	P	70	RHS, Inner boot without bush	10	1987	09	1990	DBSR400
FIAT	Regata	1.3	P	70	RHS, Inner boot without bush	10	1987	09	1990	DBSR100
FIAT	Regata	1.5	P	85 Automatic		01	1984	02	1989	DBSR400
FIAT	Regata	1.5	P	85 Automatic		01	1984	02	1989	DBSR100
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 23mm metal bush	01	1984	09	1987	DBSR400
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 23mm metal bush	01	1984	09	1987	DBSR100
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 23mm metal bush	01	1984	09	1987	DBSR400

Sheet1

FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 23mm metal bush	01	1984	09	1987	DBSR100
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 23mm nylon bush	01	1984	09	1987	DBSR400
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 23mm nylon bush	01	1984	09	1987	DBSR100
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 23mm nylon bush	01	1984	09	1987	DBSR400
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 23mm nylon bush	01	1984	09	1987	DBSR100
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 25mm metal bush	01	1984	09	1987	DBSR400
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 25mm metal bush	01	1984	09	1987	DBSR100
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 25mm metal bush	01	1984	09	1987	DBSR400
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 25mm metal bush	01	1984	09	1987	DBSR100
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 25mm nylon bush	01	1984	09	1987	DBSR400
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 25mm nylon bush	01	1984	09	1987	DBSR100
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 25mm nylon bush	01	1984	09	1987	DBSR400
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with 25mm nylon bush	01	1984	09	1987	DBSR100
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with bush	01	1984	09	1990	DBSR400
FIAT	Regata	1.6	P	85/100	LHS, Inner boot with bush	01	1984	09	1990	DBSR100
FIAT	Regata	1.6	P	85/100	LHS, Inner boot without bush	01	1984	09	1990	DBSR400
FIAT	Regata	1.6	P	85/100	LHS, Inner boot without bush	01	1984	09	1990	DBSR100
FIAT	Regata	1.6	P	85/100	RHS, Inner boot with 23mm metal bush	01	1984	09	1987	DBSR400
FIAT	Regata	1.6	P	85/100	RHS, Inner boot with 23mm metal bush	01	1984	09	1987	DBSR100
FIAT	Regata	1.6	P	85/100	RHS, Inner boot with 23mm nylon bush	01	1984	09	1987	DBSR400
FIAT	Regata	1.6	P	85/100	RHS, Inner boot with 23mm nylon bush	01	1984	09	1987	DBSR100
FIAT	Regata	1.6	P	85/100	RHS, Inner boot with bush	01	1984	09	1990	DBSR400
FIAT	Regata	1.6	P	85/100	RHS, Inner boot with bush	01	1984	09	1990	DBSR100
FIAT	Regata	1.6	P	85/100	RHS, Inner boot without bush	01	1984	09	1990	DBSR400
FIAT	Regata	1.6	P	85/100	RHS, Inner boot without bush	01	1984	09	1990	DBSR100
FIAT	Regata	1.9	D Turbo			03	1986	09	1987	DBSR400
FIAT	Regata	1.9	D Turbo			10	1987	09	1990	DBSR400
FIAT	Seicento	0.9	P Inj		Inner boot with bush	06	1998	10	1998	DBSR100
FIAT	Seicento	0.9	P Inj		Inner boot without bush	06	1998	10	1998	DBSR100
FIAT	Seicento	1.1	P Inj			06	1998	01	2004	DBSR100
FIAT	Strada	Mk1	1.1	P		01	1978	05	1983	DBSR100
FIAT	Strada	Mk1	1.3	P	Manual 65,75,85	01	1981	05	1983	DBSR100
FIAT	Strada	Mk1	1.3	P	Manual 65,75,85	05	1979	12	1982	DBSR100
FIAT	Strada	Mk1	1.3	P	Manual 65,75,85	05	1979	12	1981	DBSR100
FIAT	Strada	Mk1	1.3	P	Manual 65,75,85	05	1979	12	1982	DBSR100
FIAT	Strada	Mk1	1.3	P	Manual 65,75,85	05	1979	12	1981	DBSR100

Sheet1

FIAT	Strada	Mk3	1.5	P	60,70,85	LHS, Inner boot with 25mm nylon bush	11	1985	01	1988	DBSR100
FIAT	Strada	Mk3	1.5	P	60,70,85	RHS, Inner boot with 23mm metal bush	11	1985	01	1988	DBSR100
FIAT	Strada	Mk3	1.5	P	60,70,85	RHS, Inner boot with 23mm metal bush	05	1983	04	1986	DBSR100
FIAT	Strada	Mk3	1.5	P	60,70,85	RHS, Inner boot with 23mm metal bush	05	1983	11	1985	DBSR100
FIAT	Strada	Mk3	1.5	P	60,70,85	RHS, Inner boot with 23mm nylon bush	05	1983	11	1985	DBSR100
FIAT	Strada	Mk3	1.5	P	60,70,85	RHS, Inner boot with 23mm nylon bush	11	1985	01	1988	DBSR100
FIAT	Strada	Mk3	1.5	P	60,70,85	RHS, Inner boot with 23mm nylon bush	05	1983	04	1986	DBSR100
FIAT	Strada	Mk3	1.5	P	60,70,85	RHS, Inner boot with 25mm metal bush	11	1985	01	1988	DBSR100
FIAT	Strada	Mk3	1.5	P	60,70,85	RHS, Inner boot with 25mm metal bush	05	1983	11	1985	DBSR100
FIAT	Strada	Mk3	1.5	P	60,70,85	RHS, Inner boot with 25mm metal bush	05	1983	04	1986	DBSR100
FIAT	Strada	Mk3	1.5	P	60,70,85	RHS, Inner boot with 25mm nylon bush	11	1985	01	1988	DBSR100
FIAT	Strada	Mk3	1.5	P	60,70,85	RHS, Inner boot with 25mm nylon bush	05	1983	11	1985	DBSR100
FIAT	Strada	Mk3	1.5	P	60,70,85	RHS, Inner boot with 25mm nylon bush	05	1983	04	1986	DBSR100
FIAT	Strada	Mk3	1.6	P	105TC		06	1983	07	1985	DBSR100
FIAT	Strada	Mk3	2.0	P	130 Arbarth		06	1984	06	1987	DBSR100
FIAT	Tempra	Mk1	1.4	P Inj		Inner boot with bush	09	1990	12	1995	DBSR100
FIAT	Tempra	Mk1	1.4	P Inj		Inner boot with bush	09	1990	12	1995	DBSR300
FIAT	Tempra	Mk1	1.4	P Inj		Inner boot without bush	09	1990	12	1995	DBSR100
FIAT	Tempra	Mk1	1.4	P Inj		Inner boot without bush	09	1990	12	1995	DBSR300
FIAT	Tempra	Mk1	1.6	P Inj		Inner boot with bush	09	1990	12	1995	DBSR300
FIAT	Tempra	Mk1	1.6	P Inj		Inner boot without bush	09	1990	12	1995	DBSR300
FIAT	Tempra	Mk1	1.8	P Inj			09	1990	05	1992	DBSR300
FIAT	Tempra	Mk1	1.9	D		Inner boot with bush	09	1990	12	1995	DBSR300
FIAT	Tempra	Mk1	1.9	D		Inner boot without bush	09	1990	12	1995	DBSR300
FIAT	Tempra	Mk1	1.9	D Turbo			09	1990	12	1995	DBSR300
FIAT	Tempra	Mk1	2.0	P Inj			09	1990	12	1995	DBSR300
FIAT	Tempra	Mk2	1.4	P Inj		Inner boot with bush	09	1990	12	1995	DBSR100
FIAT	Tempra	Mk2	1.4	P Inj		Inner boot with bush	09	1990	12	1995	DBSR300
FIAT	Tempra	Mk2	1.4	P Inj		Inner boot without bush	09	1990	12	1995	DBSR100
FIAT	Tempra	Mk2	1.4	P Inj		Inner boot without bush	09	1990	12	1995	DBSR300
FIAT	Tempra	Mk2	1.6	P Inj		Inner boot with bush	09	1990	12	1995	DBSR300
FIAT	Tempra	Mk2	1.6	P Inj		Inner boot without bush	09	1990	12	1995	DBSR300
FIAT	Tempra	Mk2	1.8	P Inj			09	1990	05	1992	DBSR300
FIAT	Tempra	Mk2	1.9	D		Inner boot with bush	09	1990	12	1995	DBSR300
FIAT	Tempra	Mk2	1.9	D		Inner boot without bush	09	1990	12	1995	DBSR300
FIAT	Tempra	Mk2	1.9	D Turbo			09	1990	12	1995	DBSR300

Sheet1

FIAT	Tempra	Mk2	2.0	P Inj		09	1990	12	1995	DBSR300	
FIAT	Tipo	Mk1	1.4	P Inj	Inner boot with bush	06	1988	10	1995	DBSR300	
FIAT	Tipo	Mk1	1.4	P Inj	Inner boot with bush	06	1988	10	1995	DBSR100	
FIAT	Tipo	Mk1	1.4	P Inj	Inner boot without bush	06	1988	10	1995	DBSR300	
FIAT	Tipo	Mk1	1.4	P Inj	Inner boot without bush	06	1988	10	1995	DBSR100	
FIAT	Tipo	Mk1	1.6	P Inj	Inner boot with bush	06	1988	10	1995	DBSR300	
FIAT	Tipo	Mk1	1.6	P Inj	Inner boot with bush	06	1988	10	1995	DBSR100	
FIAT	Tipo	Mk1	1.6	P Inj	Inner boot without bush	06	1988	10	1995	DBSR300	
FIAT	Tipo	Mk1	1.6	P Inj	Inner boot without bush	06	1988	10	1995	DBSR100	
FIAT	Tipo	Mk1	1.7	D	Inner boot with bush	06	1988	12	1992	DBSR300	
FIAT	Tipo	Mk1	1.7	D	Inner boot without bush	06	1988	12	1992	DBSR300	
FIAT	Tipo	Mk1	1.9	D Turbo		06	1988	10	1995	DBSR300	
FIAT	Tipo	Mk2	1.4	P Inj	Inner boot with bush	06	1988	10	1995	DBSR300	
FIAT	Tipo	Mk2	1.4	P Inj	Inner boot with bush	06	1988	10	1995	DBSR100	
FIAT	Tipo	Mk2	1.4	P Inj	Inner boot without bush	06	1988	10	1995	DBSR300	
FIAT	Tipo	Mk2	1.4	P Inj	Inner boot without bush	06	1988	10	1995	DBSR100	
FIAT	Tipo	Mk2	1.6	P Inj	Inner boot with bush	06	1988	10	1995	DBSR300	
FIAT	Tipo	Mk2	1.6	P Inj	Inner boot with bush	06	1988	10	1995	DBSR100	
FIAT	Tipo	Mk2	1.6	P Inj	Inner boot without bush	06	1988	10	1995	DBSR300	
FIAT	Tipo	Mk2	1.6	P Inj	Inner boot without bush	06	1988	10	1995	DBSR100	
FIAT	Tipo	Mk2	1.7	D	Inner boot with bush	06	1988	12	1992	DBSR300	
FIAT	Tipo	Mk2	1.7	D	Inner boot without bush	06	1988	12	1992	DBSR300	
FIAT	Tipo	Mk2	1.9	D Turbo		06	1988	10	1995	DBSR300	
FIAT	Uno		0.9	P Inj	45	Inner boot with 23mm metal bush	04	1983	11	1984	DBSR100
FIAT	Uno		0.9	P Inj	45	Inner boot with 23mm nylon bush	04	1983	11	1984	DBSR100
FIAT	Uno		0.9	P Inj	45	Inner boot with 25mm metal bush	04	1983	11	1984	DBSR100
FIAT	Uno		0.9	P Inj	45	Inner boot with 25mm nylon bush	04	1983	11	1984	DBSR100
FIAT	Uno		0.9	P Inj	45	LHS, Inner boot with metal bush	12	1984	07	1995	DBSR100
FIAT	Uno		0.9	P Inj	45	LHS, Inner boot with metal bush	12	1984	07	1995	DBSR100
FIAT	Uno		0.9	P Inj	45	LHS, Inner boot with nylon bush	12	1984	07	1995	DBSR100
FIAT	Uno		0.9	P Inj	45	LHS, Inner boot with nylon bush	12	1984	07	1995	DBSR100
FIAT	Uno		0.9	P Inj	45	RHS, Inner boot with metal bush	12	1984	07	1995	DBSR100
FIAT	Uno		0.9	P Inj	45	RHS, Inner boot with nylon bush	12	1984	07	1995	DBSR100
FIAT	Uno		1.0	P Inj	Fire	LHS, Inner boot with bush	06	1985	12	1984	DBSR100
FIAT	Uno		1.0	P Inj	Fire	LHS, Inner boot with bush	06	1985	07	1995	DBSR100
FIAT	Uno		1.0	P Inj	Fire	LHS, Inner boot without bush	06	1985	07	1995	DBSR100

Sheet1

FIAT	Uno	1.0	P Inj	Fire	LHS, Inner boot without bush	06	1985	12	1984	DBSR100
FIAT	Uno	1.0	P Inj	Fire	RHS, Inner boot with bush	06	1985	12	1984	DBSR100
FIAT	Uno	1.0	P Inj	Fire	RHS, Inner boot with bush	06	1985	07	1995	DBSR100
FIAT	Uno	1.0	P Inj	Fire	RHS, Inner boot without bush	06	1985	12	1984	DBSR100
FIAT	Uno	1.0	P Inj	Fire	RHS, Inner boot without bush	06	1985	07	1995	DBSR100
FIAT	Uno	1.1	P Inj	60	Inner boot with metal bush	11	1983	11	1984	DBSR100
FIAT	Uno	1.1	P Inj	60	Inner boot with nylon bush	11	1983	11	1984	DBSR100
FIAT	Uno	1.1	P Inj	60	LHS, Inner boot with metal bush	12	1984	02	1994	DBSR100
FIAT	Uno	1.1	P Inj	60	LHS, Inner boot with nylon bush	12	1984	02	1994	DBSR100
FIAT	Uno	1.1	P Inj	60	RHS, Inner boot with bush	12	1984	02	1994	DBSR100
FIAT	Uno	1.1	P Inj	60	RHS, Inner boot without bush	12	1984	02	1994	DBSR100
FIAT	Uno	1.3	P Carb	70	LHS, Inner boot with bush	05	1983	01	1990	DBSR100
FIAT	Uno	1.3	P Carb	70	LHS, Inner boot without bush	05	1983	01	1990	DBSR100
FIAT	Uno	1.3	P Carb	70	RHS, Inner boot with bush	05	1983	01	1990	DBSR100
FIAT	Uno	1.3	P Carb	70	RHS, Inner boot without bush	05	1983	01	1990	DBSR100
FIAT	Uno	1.3	P Turbo			07	1985	01	1990	DBSR100
FIAT	Uno	1.4	P Inj	70	LHS, Inner boot with bush	01	1990	09	1994	DBSR100
FIAT	Uno	1.4	P Inj	70	LHS, Inner boot without bush	01	1990	09	1994	DBSR100
FIAT	Uno	1.4	P Inj	70	RHS, Inner boot with bush	01	1990	09	1994	DBSR100
FIAT	Uno	1.4	P Inj	70	RHS, Inner boot without bush	01	1990	09	1994	DBSR100
FIAT	Uno	1.7	D		LHS, Inner boot with bush	10	1987	07	1995	DBSR100
FIAT	Uno	1.7	D		LHS, Inner boot with metal bush	09	1986	09	1987	DBSR100
FIAT	Uno	1.7	D		LHS, Inner boot with nylon bush	09	1986	09	1987	DBSR100
FIAT	Uno	1.7	D		LHS, Inner boot without bush	10	1987	07	1995	DBSR100
FIAT	Uno	1.7	D		RHS, Inner boot with bush	10	1987	07	1995	DBSR100
FIAT	Uno	1.7	D		RHS, Inner boot with metal bush	09	1986	09	1987	DBSR100
FIAT	Uno	1.7	D		RHS, Inner boot with nylon bush	09	1986	09	1987	DBSR100
FIAT	Uno	1.7	D		RHS, Inner boot without bush	10	1987	07	1995	DBSR100
FIAT	X19	1.5	P	Fwd	Inner boot with 25mm metal bush	01	1976	09	1978	DBSR100
FIAT	X19	1.5	P	Fwd	Inner boot with 25mm metal bush	01	1976	09	1978	DBSR100
FIAT	X19	1.5	P	Fwd	Inner boot with 25mm nylon bush	01	1976	09	1978	DBSR100
FIAT	X19	1.5	P	Fwd	Inner boot with 25mm nylon bush	01	1976	09	1978	DBSR100
FIAT	X19	1.5	P	Rwd	Inner boot with 25mm metal bush	01	1976	03	1989	DBSR100
FIAT	X19	1.5	P	Rwd	Inner boot with 25mm nylon bush	01	1976	03	1989	DBSR100
FIAT LCV	Ducato	Mk1	1.8	P Inj		12	1982	06	1994	DBSR200
FIAT LCV	Ducato	Mk2	2.0	D Turbo		01	1991			DBSR200

Sheet1

FIAT LCV	Ducato	Mk2	2.0	P Inj		06	1994	04	2002	DBSR200
FORD	Capri	Mk1	1.3			01	1968	12	1973	DBSR100
FORD	Capri	Mk1	1.3			01	1968	12	1973	DBSR200
FORD	Capri	Mk1	1.5			01	1968	12	1973	DBSR100
FORD	Capri	Mk1	1.5			01	1968	12	1973	DBSR200
FORD	Capri	Mk1	2.0			01	1968	12	1973	DBSR100
FORD	Capri	Mk1	2.0			01	1968	12	1973	DBSR200
FORD	Capri	Mk1	2.3			01	1968	12	1973	DBSR100
FORD	Capri	Mk1	2.3			01	1968	12	1973	DBSR200
FORD	Capri	Mk1	3.0			01	1968	12	1973	DBSR100
FORD	Capri	Mk1	3.0			01	1968	12	1973	DBSR200
FORD	Capri	Mk2	1.3			01	1973	12	1987	DBSR200
FORD	Capri	Mk2	1.6			01	1973	12	1987	DBSR200
FORD	Capri	Mk2	2.0			01	1973	12	1987	DBSR200
FORD	Capri	Mk2	3.0			01	1973	12	1987	DBSR200
FORD	Capri	Mk3	1.3			01	1973	12	1987	DBSR200
FORD	Capri	Mk3	1.6			01	1973	12	1987	DBSR200
FORD	Capri	Mk3	2.0			01	1973	12	1987	DBSR200
FORD	Capri	Mk3	3.0			01	1973	12	1987	DBSR200
FORD	Cougar		2.0	P Inj	Trilobal inner joint	10	1998	10	2000	DBSRPS300
FORD	Cougar		2.5	P Inj	Trilobal inner joint	10	1998	10	2000	DBSRPS300
FORD	Escort	Mk2	1.1	P		01	1975	12	1980	DBSR100
FORD	Escort	Mk2	1.3	P		01	1975	12	1980	DBSR100
FORD	Escort	Mk2	1.6	P		01	1975	12	1980	DBSR100
FORD	Escort	Mk3	1.1	P		08	1980	05	1983	DBSR100
FORD	Escort	Mk3	1.1	P		06	1983	02	1986	DBSR200
FORD	Escort	Mk3	1.3	P		09	1980	05	1983	DBSR100
FORD	Escort	Mk3	1.3	P		05	1983	02	1986	DBSR200
FORD	Escort	Mk3	1.6	D		01	1984	02	1986	DBSR200
FORD	Escort	Mk3	1.6	P		09	1980	05	1983	DBSR100
FORD	Escort	Mk3	1.6	P		05	1983	02	1986	DBSR200
FORD	Escort	Mk3	1.6	P		09	1980	05	1983	DBSR100
FORD	Escort	Mk3	1.6	P		05	1983	02	1986	DBSR200
FORD	Escort	Mk4	1.1	P		10	1989	10	1990	DBSR200
FORD	Escort	Mk4	1.1	P		09	1988	12	1988	DBSR100
FORD	Escort	Mk4	1.1	P		10	1989	10	1990	DBSR200

Sheet1

FORD	Escort	Mk4	1.1	P		02	1986	12	1988	DBSR100
FORD	Escort	Mk4	1.3	P		02	1986	12	1990	DBSR200
FORD	Escort	Mk4	1.3	P		01	1988	01	1991	DBSR200
FORD	Escort	Mk4	1.3	P		02	1986	12	1988	DBSR100
FORD	Escort	Mk4	1.3	P	ABS	02	1986	12	1990	DBSR200
FORD	Escort	Mk4	1.3	P	ABS	01	1988	01	1991	DBSR200
FORD	Escort	Mk4	1.3	P	ABS	02	1986	12	1988	DBSR100
FORD	Escort	Mk4	1.4	P		01	1988	10	1990	DBSR200
FORD	Escort	Mk4	1.4	P		02	1986	12	1988	DBSR100
FORD	Escort	Mk4	1.6	P	Auto	01	1988	12	1990	DBSR200
FORD	Escort	Mk4	1.6	P	Auto	02	1986	12	1988	DBSR100
FORD	Escort	Mk4	1.6	P	Manual	01	1988	12	1990	DBSR200
FORD	Escort	Mk4	1.6	P	Manual	02	1986	12	1988	DBSR100
FORD	Escort	Mk4	1.6	P	Manual	01	1988	12	1990	DBSR200
FORD	Escort	Mk4	1.6	P	Manual	02	1986	12	1988	DBSR100
FORD	Escort	Mk4	1.6	D		04	1986	08	1988	DBSR100
FORD	Escort	Mk4	1.8	D		09	1988	12	1990	DBSR200
FORD	Escort	Mk5	1.3	P Inj		01	1991	01	1995	DBSR300
FORD	Escort	Mk5	1.3	P Inj		01	1991	10	1992	DBSR300
FORD	Escort	Mk5	1.3	P Inj		10	1992	01	1995	DBSR300
FORD	Escort	Mk5	1.3	P Inj		01	1991	01	1995	DBSR300
FORD	Escort	Mk5	1.4	P		01	1991	10	1992	DBSR300
FORD	Escort	Mk5	1.4	P Inj		01	1991	01	1995	DBSR300
FORD	Escort	Mk5	1.4	P Inj		10	1992	01	1995	DBSR300
FORD	Escort	Mk5	1.4	P Inj		01	1991	01	1995	DBSR300
FORD	Escort	Mk5	1.6	P Inj	Auto	10	1992	07	1992	DBSR300
FORD	Escort	Mk5	1.6	P Inj	Auto	01	1991	07	1992	DBSR300
FORD	Escort	Mk5	1.6	P Inj	Manual	10	1992	01	1995	DBSR300
FORD	Escort	Mk5	1.6	P Inj	Manual	01	1991	01	1995	DBSR300
FORD	Escort	Mk5	1.6	P Inj		10	1992	01	1995	DBSR300
FORD	Escort	Mk5	1.6	P Inj		10	1992	01	1995	DBSR300
FORD	Escort	Mk5	1.6	P Inj		10	1992	01	1995	DBSR300
FORD	Escort	Mk5	1.6	P Inj		10	1992	01	1995	DBSR300
FORD	Escort	Mk5	1.8	D		10	1992	01	1995	DBSR300
FORD	Escort	Mk5	1.8	D		01	1991	01	1995	DBSR300
FORD	Escort	Mk5	1.8	P Inj		10	1992	01	1995	DBSR300
FORD	Escort	Mk5	1.8	P Inj		01	1991	10	1992	DBSR300

Sheet1

FORD	Escort	Mk5	1.8	P Inj			01	1991	01	1995	DBSR300
FORD	Escort	Mk5	1.8	D Turbo		Trilobal inner joint	09	1993	01	1995	DBSR300
FORD	Escort	Mk5	1.8	D Turbo		Trilobal inner joint	09	1993	01	1995	DBSR300
FORD	Escort	Mk5	2.0	P Inj	RS Fwd	Trilobal inner joint	10	1992	01	1995	DBSR300
FORD	Escort	Mk5	2.0	P Inj	RS Fwd	Trilobal inner joint	09	1991	01	1995	DBSR300
FORD	Escort	Mk5	2.0	P Turbo	Cosworth 4wd	Front	10	1992	01	1995	DBSR300
FORD	Escort	Mk5	2.0	P Turbo	Cosworth 4wd	Front	06	1992	01	1995	DBSR300
FORD	Escort	Mk5	2.0	P Turbo	Cosworth 4wd	Rear	10	1992	01	1995	DBSR300
FORD	Escort	Mk5	2.0	P Turbo	Cosworth 4wd	Rear	06	1992	01	1995	DBSR300
FORD	Escort	Mk6	1.3	P Inj			02	1995	10	1997	DBSR300
FORD	Escort	Mk6	1.3	P Inj			02	1995	01	1999	DBSR300
FORD	Escort	Mk6	1.4	P Inj			02	1995	01	1999	DBSR300
FORD	Escort	Mk6	1.4	P Inj			03	2000	01	1999	DBSR300
FORD	Escort	Mk6	1.6	P Inj	Auto		02	1995	01	1999	DBSR300
FORD	Escort	Mk6	1.6	P Inj	Manual		02	1995	01	1999	DBSR300
FORD	Escort	Mk6	1.8	D			02	1995	01	1997	DBSR300
FORD	Escort	Mk6	1.8	P Inj		Trilobal inner joint	02	1995	01	1999	DBSR300
FORD	Escort	Mk6	1.8	D Turbo		Trilobal inner joint	02	1995	01	1999	DBSR300
FORD	Escort	Mk6	2.0	P Inj	RS Fwd	Trilobal inner joint	02	1995	07	1996	DBSR300
FORD	Escort	Mk6	2.0	P Turbo	Cosworth 4wd	Front	02	1995	07	1996	DBSR300
FORD	Escort	Mk6	2.0	P Turbo	Cosworth 4wd	Rear	02	1995	07	1996	DBSR300
FORD	Fiesta Mk1		1.0	P			02	1977	09	1983	DBSR100
FORD	Fiesta Mk1		1.1	P			02	1977	09	1983	DBSR100
FORD	Fiesta Mk1		1.3	P			01	1980	09	1983	DBSR100
FORD	Fiesta Mk1		1.6	P	XR2		12	1981	07	1983	DBSR200
FORD	Fiesta Mk2		1.0	P			09	1983	03	1989	DBSR100
FORD	Fiesta Mk2		1.1	P			09	1983	03	1989	DBSR100
FORD	Fiesta Mk2		1.3	P			04	1984	02	1986	DBSR200
FORD	Fiesta Mk2		1.3	P Inj			03	1986	03	1989	DBSR200
FORD	Fiesta Mk2		1.4	P			02	1986	04	1986	DBSR200
FORD	Fiesta Mk2		1.4	P			04	1986	03	1989	DBSR200
FORD	Fiesta Mk2		1.6	D			04	1988	03	1989	DBSR100
FORD	Fiesta Mk2		1.6	D			04	1984	04	1988	DBSR100
FORD	Fiesta Mk2		1.6	P			01	1986	01	1989	DBSR200
FORD	Fiesta Mk2		1.6	P	XR2		06	1984	01	1989	DBSR200
FORD	Fiesta Mk3		1.0	P		Ball bearing type inner joint	04	1989	07	1991	DBSR100

Sheet1

FORD	Fiesta Mk3	1.0	P	Needle roller type inner joint	04	1989	07	1991	DBSR100
FORD	Fiesta Mk3	1.1	P Carb	Ball bearing type inner joint	04	1989	01	1994	DBSR100
FORD	Fiesta Mk3	1.1	P Carb	Needle roller type inner joint	04	1989	01	1994	DBSR100
FORD	Fiesta Mk3	1.1	P inj		10	1992	08	1995	DBSR100
FORD	Fiesta Mk3	1.1	P inj		10	1992	07	1996	DBSR100
FORD	Fiesta Mk3	1.1	P inj		08	1995	07	1996	DBSR100
FORD	Fiesta Mk3	1.1	P inj		10	1992	07	1996	DBSR300
FORD	Fiesta Mk3	1.3	P Inj		05	1991	01	1993	DBSR200
FORD	Fiesta Mk3	1.3	P Inj		02	1994	10	1995	DBSR200
FORD	Fiesta Mk3	1.3	P Inj		01	1992	08	1995	DBSR100
FORD	Fiesta Mk3	1.3	P Inj		05	1991	10	1995	DBSR300
FORD	Fiesta Mk3	1.3	P Inj	Ball bearing type inner joint	05	1991	01	1993	DBSR200
FORD	Fiesta Mk3	1.3	P Inj	Ball bearing type inner joint	04	1989	01	1994	DBSR200
FORD	Fiesta Mk3	1.3	P Inj	Ball bearing type inner joint	01	1992	08	1995	DBSR100
FORD	Fiesta Mk3	1.3	P Inj	Ball bearing type inner joint	05	1991	01	1994	DBSR300
FORD	Fiesta Mk3	1.3	P Inj	Needle roller type inner joint	04	1989	01	1994	DBSR200
FORD	Fiesta Mk3	1.3	P Inj	Needle roller type inner joint	05	1991	01	1993	DBSR200
FORD	Fiesta Mk3	1.3	P Inj	Needle roller type inner joint	01	1992	08	1995	DBSR100
FORD	Fiesta Mk3	1.3	P Inj	Needle roller type inner joint	05	1991	01	1994	DBSR300
FORD	Fiesta Mk3	1.4	P Inj		10	1990	05	1992	DBSR200
FORD	Fiesta Mk3	1.4	P Inj		01	1992	08	1995	DBSR200
FORD	Fiesta Mk3	1.4	P Inj		07	1990	10	1995	DBSR200
FORD	Fiesta Mk3	1.4	P Inj		02	1994	10	1995	DBSR200
FORD	Fiesta Mk3	1.4	P Inj	Ball bearing type inner joint	10	1990	05	1992	DBSR200
FORD	Fiesta Mk3	1.4	P Inj	Ball bearing type inner joint	01	1992	08	1995	DBSR200
FORD	Fiesta Mk3	1.4	P Inj	Ball bearing type inner joint	04	1989	01	1994	DBSR200
FORD	Fiesta Mk3	1.4	P Inj	Ball bearing type inner joint	07	1990	01	1994	DBSR200
FORD	Fiesta Mk3	1.4	P Inj	Needle roller type inner joint	10	1990	05	1992	DBSR200
FORD	Fiesta Mk3	1.4	P Inj	Needle roller type inner joint	01	1992	08	1995	DBSR200
FORD	Fiesta Mk3	1.4	P Inj	Needle roller type inner joint	07	1990	01	1994	DBSR200
FORD	Fiesta Mk3	1.4	P Inj	Needle roller type inner joint	04	1989	01	1994	DBSR200
FORD	Fiesta Mk3	1.6	P Inj		07	1990	02	1992	DBSR200
FORD	Fiesta Mk3	1.6	P Inj		07	1990	02	1992	DBSR200
FORD	Fiesta Mk3	1.6	P Inj	XR2i	04	1989	12	1992	DBSR200
FORD	Fiesta Mk3	1.6	P Turbo		04	1989	12	1992	DBSR200
FORD	Fiesta Mk3	1.6	P Inj		02	1994	10	1995	DBSR300

Sheet1

FORD	Fiesta Mk3	1.8	D			02	1994	10	1995	DBSR200
FORD	Fiesta Mk3	1.8	D		Ball bearing type inner joint	04	1989	01	1994	DBSR200
FORD	Fiesta Mk3	1.8	D		Needle roller type inner joint	04	1989	01	1994	DBSR200
FORD	Fiesta Mk3	1.8	P Inj			01	1992	10	1995	DBSR200
FORD	Fiesta Mk3	1.8	P Inj		Ball bearing type inner joint	01	1992	01	1994	DBSR200
FORD	Fiesta Mk3	1.8	P Inj		Needle roller type inner joint	01	1992	01	1994	DBSR200
FORD	Fiesta Mk4	1.25	P Inj		Trilobal inner joint	10	1995	02	2002	DBSR300
FORD	Fiesta Mk4	1.3	P Inj			10	1995	02	2002	DBSR100
FORD	Fiesta Mk4	1.4	P Inj		Trilobal inner joint	02	1996	10	2000	DBSR200
FORD	Fiesta Mk4	1.6	P Inj			03	2000	02	2002	DBSR300
FORD	Fiesta Mk4	1.8	D			12	1995	02	2002	DBSR200
FORD	Fiesta Mk4	1.8	D Turbo			12	1995	02	2002	DBSR200
FORD	Fiesta Mk5	1.25	P Inj		Trilobal inner joint	02	2003			DBSR300
FORD	Fiesta Mk5	1.3	P Inj		Trilobal inner joint	03	2002	07	2003	DBSR100
FORD	Fiesta Mk5	1.4	P Inj		Trilobal inner joint	03	2002			DBSR200
FORD	Fiesta Mk5	1.6	P Inj		Trilobal inner joint	03	2002			DBSR300
FORD	Focus	1.4	P Inj		Trilobal inner joint	10	1998			DBSR300
FORD	Focus	1.6	P Inj	Auto		10	1999			DBSR300
FORD	Focus	1.6	P Inj	Manual	Trilobal inner joint	10	1998			DBSR300
FORD	Focus	1.8	D Turbo		Trilobal inner joint	10	1998			DBSR300
FORD	Focus	1.8	P Inj		Trilobal inner joint	10	1998			DBSR300
FORD	Focus	2.0	P Inj	Auto		10	2001			DBSR300
FORD	Focus	2.0	P Inj	Manual	Trilobal inner joint	10	1998			DBSR300
FORD	Galaxy	Mk1	1.9	D Turbo	Auto	04	1998	07	2000	DBSR200
FORD	Galaxy	Mk1	1.9	D Turbo	Manual	06	1995	07	2000	DBSR200
FORD	Galaxy	Mk1	2.0	P Inj	Auto	06	1995	07	2000	DBSR200
FORD	Galaxy	Mk1	2.0	P Inj	Manual	06	1995	02	1999	DBSR200
FORD	Galaxy	Mk1	2.3	P Inj	Auto	06	1995	07	2000	DBSR200
FORD	Galaxy	Mk1	2.3	P Inj	Manual	06	1995	02	1999	DBSR200
FORD	Galaxy	Mk1	2.8	P Inj	Auto	06	1995	07	2000	DBSR200
FORD	Galaxy	Mk1	2.8	P Inj	Manual	06	1995	07	2000	DBSR200
FORD	Galaxy	Mk2	1.9	D Turbo	Auto	08	2000			DBSR200
FORD	Galaxy	Mk2	1.9	D Turbo	Manual	08	2000			DBSR200
FORD	Galaxy	Mk2	2.3	P Inj	Auto	08	2000			DBSR200
FORD	Galaxy	Mk2	2.3	P Inj	Manual	08	2000			DBSR200
FORD	Galaxy	Mk2	2.8	P Inj	Auto	08	2000			DBSR200

Sheet1

FORD	Mondeo	Mk1	1.8	P	Auto	Trilobal inner joint	03	1993	08	1996	DBSRPS300
FORD	Mondeo	Mk1	1.8	P	Auto	Trilobal inner joint	03	1993	12	1994	DBSRPS300
FORD	Mondeo	Mk1	1.8	P	Manual	Trilobal inner joint	03	1993	08	1996	DBSRPS300
FORD	Mondeo	Mk1	1.8	D Turbo		Trilobal inner joint	08	1993	08	1996	DBSRPS300
FORD	Mondeo	Mk1	2.0	P	Auto	Trilobal inner joint	03	1993	12	1994	DBSRPS300
FORD	Mondeo	Mk1	2.0	P	Auto	Trilobal inner joint	03	1993	08	1996	DBSRPS300
FORD	Mondeo	Mk1	2.0	P	Manual	Trilobal inner joint	03	1993	08	1996	DBSRPS300
FORD	Mondeo	Mk1	2.5	P	Auto	Trilobal inner joint	03	1993	12	1994	DBSRPS300
FORD	Mondeo	Mk1	2.5	P	Auto	Trilobal inner joint	03	1993	08	1996	DBSRPS300
FORD	Mondeo	Mk1	2.5	P	Manual	Trilobal inner joint	03	1993	08	1996	DBSRPS300
FORD	Mondeo	Mk2	1.6	P Inj		Trilobal inner joint	01	1997	09	2000	DBSR300
FORD	Mondeo	Mk2	1.8	D Turbo		Trilobal inner joint	01	1997	09	2000	DBSR300
FORD	Mondeo	Mk2	1.8	P Inj		Trilobal inner joint	01	1997	09	2000	DBSR300
FORD	Mondeo	Mk2	2.0	P Inj	Manual Auto	Trilobal inner joint	01	1997	09	2000	DBSR300
FORD	Mondeo	Mk2	2.5	P Inj	Manual Auto	Trilobal inner joint	01	1997	09	2000	DBSR300
FORD	Mondeo	Mk3	1.8	P Inj		Trilobal inner joint	10	2000			DBSR300
FORD	Mondeo	Mk3	2.0	D Turbo		Trilobal inner joint	10	2000			DBSR300
FORD	Mondeo	Mk3	2.0	P Inj	Auto		10	2000			DBSR300
FORD	Mondeo	Mk3	2.0	P Inj	Manual	Trilobal inner joint	10	2000			DBSR300
FORD	Mondeo	Mk3	2.5	P Inj		Trilobal inner joint	10	2000			DBSR300
FORD	Orion	Mk1	1.3	P			09	1983	12	1985	DBSR200
FORD	Orion	Mk1	1.6	P			09	1983	02	1986	DBSR200
FORD	Orion	Mk2	1.3	P			01	1988	10	1990	DBSR200
FORD	Orion	Mk2	1.3	P			01	1986	12	1988	DBSR100
FORD	Orion	Mk2	1.3	P	ABS		01	1988	01	1991	DBSR200
FORD	Orion	Mk2	1.3	P	ABS		02	1986	12	1988	DBSR100
FORD	Orion	Mk2	1.4	P			01	1988	10	1990	DBSR200
FORD	Orion	Mk2	1.4	P			02	1986	12	1988	DBSR100
FORD	Orion	Mk2	1.6	D	Manual		04	1986	12	1988	DBSR100
FORD	Orion	Mk2	1.6	P	Auto		01	1988	09	1990	DBSR200
FORD	Orion	Mk2	1.6	P	Auto		01	1988	09	1990	DBSR200
FORD	Orion	Mk2	1.6	P	Auto		02	1986	12	1988	DBSR100
FORD	Orion	Mk2	1.6	P	Manual		01	1988	10	1990	DBSR200
FORD	Orion	Mk2	1.6	P	Manual		01	1988	10	1990	DBSR200
FORD	Orion	Mk2	1.6	P	Manual		02	1986	12	1988	DBSR100
FORD	Orion	Mk2	1.8	D			09	1988	10	1990	DBSR200

Sheet1

FORD	Orion	Mk3	1.3	P			09	1990	09	1991	DBSR200
FORD	Orion	Mk3	1.4	P Inj			01	1991	08	1993	DBSR300
FORD	Orion	Mk3	1.4	P Inj			01	1991	08	1993	DBSR300
FORD	Orion	Mk3	1.6	P Inj	Auto		01	1991	10	1992	DBSR300
FORD	Orion	Mk3	1.6	P Inj	Manual		01	1991	10	1992	DBSR300
FORD	Orion	Mk3	1.6	P Inj			10	1992	08	1993	DBSR300
FORD	Orion	Mk3	1.8	P Inj			01	1991	08	1993	DBSR300
FORD	Scorpio		2.0	P Inj			01	1995	06	1998	DBSR300
FORD	Scorpio		2.3	P Inj			01	1995	06	1998	DBSR300
FORD	Scorpio		2.5	P Inj			01	1995	06	1998	DBSR300
FORD	Scorpio		2.9	P Inj			01	1995	06	1998	DBSR300
FORD	Sierra	Mk1	1.3	P			10	1982	12	1985	DBSR200
FORD	Sierra	Mk1	1.6	P			10	1982	03	1987	DBSR200
FORD	Sierra	Mk1	1.8	P			10	1982	03	1987	DBSR200
FORD	Sierra	Mk1	2.0	P			10	1982	03	1987	DBSR200
FORD	Sierra	Mk1	2.0	P			01	1983	12	1985	DBSR300
FORD	Sierra	Mk1	2.0	P			01	1985	03	1987	DBSR300
FORD	Sierra	Mk1	2.3	D			10	1982	12	1984	DBSR200
FORD	Sierra	Mk1	2.3	P			10	1982	12	1984	DBSR200
FORD	Sierra	Mk1	2.8	P Inj	XR4i Rwd		12	1982	12	1985	DBSR300
FORD	Sierra	Mk1	2.8	P Inj	XR4x4	Front	06	1985	03	1987	DBSR300
FORD	Sierra	Mk1	2.8	P Inj	XR4x4	Rear	06	1985	03	1987	DBSR300
FORD	Sierra	Mk2	1.6	P Inj			03	1987	10	1988	DBSR200
FORD	Sierra	Mk2	1.6	P Inj			01	1988	04	1993	DBSR300
FORD	Sierra	Mk2	1.6	P Inj	ABS		03	1987	10	1988	DBSR200
FORD	Sierra	Mk2	1.6	P Inj	ABS		01	1988	04	1993	DBSR300
FORD	Sierra	Mk2	1.8	D Turbo			01	1990	04	1993	DBSR300
FORD	Sierra	Mk2	1.8	D Turbo	ABS		01	1990	04	1993	DBSR300
FORD	Sierra	Mk2	1.8	P			03	1987	04	1993	DBSR200
FORD	Sierra	Mk2	1.8	P			01	1988	04	1993	DBSR300
FORD	Sierra	Mk2	2.0	P Inj	4wd	Front	02	1990	04	1993	DBSR300
FORD	Sierra	Mk2	2.0	P Inj	4wd	Front	01	1988	04	1993	DBSR300
FORD	Sierra	Mk2	2.0	P Inj	4wd	Rear	02	1990	04	1993	DBSR300
FORD	Sierra	Mk2	2.0	P Inj	4wd	Rear	01	1988	04	1993	DBSR300
FORD	Sierra	Mk2	2.0	P Inj	Rwd		01	1988	04	1993	DBSR300
FORD	Sierra	Mk2	2.0	P Inj	Rwd		03	1987	04	1993	DBSR300

Sheet1

FORD	Sierra	Mk2	2.0	P Inj	Rwd			03	1987	04	1993	DBSR300
FORD	Sierra	Mk2	2.0	P Inj	Rwd			01	1988	04	1993	DBSR300
FORD	Sierra	Mk2	2.3	D				03	1987	02	1990	DBSR200
FORD	Sierra	Mk2	2.3	D	ABS			03	1987	02	1990	DBSR200
FORD	Sierra	Mk2	2.8	P Inj	XR 4x4	Front		03	1987	12	1988	DBSR300
FORD	Sierra	Mk2	2.8	P Inj	XR 4x4	Rear		03	1987	12	1988	DBSR300
FORD	Sierra	Mk2	2.9	P Inj	XR 4x4	Front		01	1988	04	1993	DBSR300
FORD	Sierra	Mk2	2.9	P Inj	XR 4x4	Rear		01	1988	04	1993	DBSR300
FORD LCV	Courier	Mk1	1.3	P Inj				02	1994	10	1995	DBSR200
FORD LCV	Courier	Mk1	1.3	P Inj		Ball bearing type inner joint		10	1991	01	1994	DBSR200
FORD LCV	Courier	Mk1	1.3	P Inj		Needle roller type inner joint		10	1991	01	1994	DBSR200
FORD LCV	Courier	Mk1	1.3	P Inj	ABS			10	1991	01	1994	DBSR200
FORD LCV	Courier	Mk1	1.3	P Inj	ABS			02	1994	10	1995	DBSR200
FORD LCV	Courier	Mk1	1.8	D				02	1994	10	1995	DBSR200
FORD LCV	Courier	Mk1	1.8	D		Ball bearing type inner joint		10	1991	01	1994	DBSR200
FORD LCV	Courier	Mk1	1.8	D		Needle roller type inner joint		10	1991	01	1994	DBSR200
FORD LCV	Courier	Mk1	1.8	D	ABS			10	1991	01	1994	DBSR200
FORD LCV	Courier	Mk1	1.8	D	ABS			02	1994	10	1995	DBSR200
FORD LCV	Courier	Mk2	1.3	P Inj				01	1996			DBSR200
FORD LCV	Courier	Mk2	1.8	D				01	1996	03	2000	DBSR200
FORD LCV	Courier	Mk2	1.8	D Turbo				03	2000			DBSR200
FORD LCV	Fiesta Van	Mk1	0.95	P				01	1978	09	1983	DBSR100
FORD LCV	Fiesta Van	Mk2	0.95	P				09	1983	02	1989	DBSR100
FORD LCV	Fiesta Van	Mk2	1.6	D				04	1988	02	1989	DBSR100
FORD LCV	Fiesta Van	Mk2	1.6	D				05	1984	04	1988	DBSR100
FORD LCV	Fiesta Van	Mk3	1.0	P		Ball bearing type inner joint		04	1989	10	1991	DBSR200
FORD LCV	Fiesta Van	Mk3	1.0	P		Needle roller type inner joint		04	1989	10	1991	DBSR200
FORD LCV	Fiesta Van	Mk3	1.1	P Carb		Ball bearing type inner joint		04	1989	02	1994	DBSR200
FORD LCV	Fiesta Van	Mk3	1.1	P Carb		Needle roller type inner joint		04	1989	02	1994	DBSR200
FORD LCV	Fiesta Van	Mk3	1.1	P inj				10	1992	09	1996	DBSR200
FORD LCV	Fiesta Van	Mk3	1.3	P Inj		Ball bearing type inner joint		12	1991	08	1992	DBSR200
FORD LCV	Fiesta Van	Mk3	1.3	P Inj		Needle roller type inner joint		12	1991	08	1992	DBSR200
FORD LCV	Fiesta Van	Mk3	1.4	P				10	1990	12	1991	DBSR200
FORD LCV	Fiesta Van	Mk3	1.4	P		Ball bearing type inner joint		10	1990	12	1991	DBSR200
FORD LCV	Fiesta Van	Mk3	1.4	P		Needle roller type inner joint		10	1990	12	1991	DBSR200
FORD LCV	Fiesta Van	Mk3	1.8	D				02	1994	09	1996	DBSR200

Sheet1

FORD LCV	Fiesta Van	Mk3	1.8	D		Ball bearing type inner joint	04	1989	01	1994	DBSR200
FORD LCV	Fiesta Van	Mk3	1.8	D		Needle roller type inner joint	04	1989	01	1994	DBSR200
FORD LCV	Fiesta Van	Mk4	1.3	P Inj			10	1996	09	1998	DBSR200
FORD LCV	Fiesta Van	Mk4	1.8	D			10	1996	10	2002	DBSR200
FORD LCV	Fiesta Van	Mk4	1.8	D Turbo			10	1996	10	2002	DBSR200
FORD LCV	P100 Pick-up		1.6	P			11	1982	12	1987	DBSR200
FORD LCV	P100 Pick-up		1.6	P			01	1981	10	1982	DBSR200
FORD LCV	P100 Pick-up		2.0	P Inj			01	1988	02	1994	DBSR200
FORD LCV	Transit						10	1991	08	1994	DBSR300
FORD LCV	Transit						10	1991	08	1994	DBSR200
FORD LCV	Transit						09	1994	03	2000	DBSR300
FORD LCV	Transit						09	1994	03	2000	DBSR200
HONDA	Accord	Mk1	1.6	P	SJ,SY		01	1982	12	1983	DBSR200
HONDA	Accord	Mk1	1.6	P	SJ,SY		02	1977	12	1982	DBSR200
HONDA	Accord	Mk3	2.0	P Inj	CB		09	1989	05	1994	DBSR200
HONDA	Accord	Mk3	2.2	P Inj	CB		09	1989	05	1994	DBSR200
HONDA	Accord	Mk4	2.0	P	CC,CE		06	1994	11	1997	DBSR200
HONDA	Accord	Mk4	2.0	D Turbo	CF		03	1996	11	1997	DBSR200
HONDA	Civic	Mk1	1.2	P			04	1973	12	1978	DBSR200
HONDA	Civic	Mk1	1.5	P	SG,SH		01	1975	12	1978	DBSR200
HONDA	Civic	Mk3	1.35	P	EC,ED,EE		08	1987	11	1991	DBSR200
HONDA	Civic	Mk3	1.35	P	EC,ED,EE	LHS	08	1987	11	1991	DBSR200
HONDA	Civic	Mk3	1.35	P	EC,ED,EE	RHS	08	1987	11	1991	DBSR200
HONDA	Civic	Mk3	1.4	P	EC,ED,EE		08	1987	11	1991	DBSR200
HONDA	Civic	Mk3	1.4	P	EC,ED,EE		10	1987	11	1991	DBSR200
HONDA	Civic	Mk3	1.4	P	EC,ED,EE	LHS	10	1987	11	1991	DBSR200
HONDA	Civic	Mk3	1.4	P	EC,ED,EE	LHS	08	1987	11	1991	DBSR200
HONDA	Civic	Mk3	1.4	P	EC,ED,EE	RHS	10	1987	11	1991	DBSR200
HONDA	Civic	Mk3	1.4	P	EC,ED,EE	RHS	08	1987	11	1991	DBSR200
HONDA	Civic	Mk3	1.6	P	ED,EE	LHS	07	1990	11	1991	DBSR200
HONDA	Civic	Mk3	1.6	P	ED,EE	RHS	07	1990	11	1991	DBSR200
HONDA	Civic	Mk4	1.35	P Inj	EG	LHS	11	1991	12	1995	DBSR200
HONDA	Civic	Mk4	1.35	P Inj	EG	RHS	11	1991	12	1995	DBSR200
HONDA	Civic	Mk4	1.5	P Inj	EG	LHS	11	1991	12	1995	DBSR200
HONDA	Civic	Mk4	1.5	P Inj	EG	RHS	11	1991	12	1995	DBSR200
HONDA	Civic	Mk4	1.6	P Inj		LHS	11	1991	12	1995	DBSR200

Sheet1

HONDA	Civic	Mk4	1.6	P Inj		RHS	11	1991	12	1995	DBSR200
HONDA	Civic	Mk4	1.6	P Inj	EG,EH,EJ	LHS	11	1991	12	1995	DBSR200
HONDA	Civic	Mk4	1.6	P Inj	EG,EH,EJ	RHS	11	1991	12	1995	DBSR200
HONDA	Concerto		1.4	P Inj			10	1989	09	1994	DBSR200
HONDA	Concerto		1.5	P Inj			10	1989	09	1994	DBSR200
HONDA	Concerto		1.6	P Inj			10	1989	09	1994	DBSR200
HONDA	Legend	Mk1	2.5	P	SA		01	1987	10	1987	DBSR200
HONDA	Legend	Mk1	2.7	P	KA		10	1987	04	1991	DBSR200
HONDA	Legend	Mk1	2.7	P	SA		10	1987	04	1991	DBSR200
HONDA	Legend	Mk2	3.2	P Inj	KA		04	1991	06	1996	DBSR200
HONDA	Legend	Mk2	3.5	P Inj	KA		06	1996			DBSR200
HONDA	Prelude	Mk3	2.0	P	BA		01	1990	04	1992	DBSR200
HONDA	Prelude	Mk3	2.0	P	BA	LHS	10	1987	12	1989	DBSR200
HONDA	Prelude	Mk3	2.0	P	BA	RHS	10	1987	12	1989	DBSR200
HONDA	Prelude	Mk4	2.0	P Inj	BB		04	1992	09	1996	DBSR200
HONDA	Quintet		1.6	P	SU		01	1981	07	1983	DBSR200
HYUNDAI	Pony	Mk2	1.3	P	X1		10	1985	06	1991	DBSR200
HYUNDAI	Pony	Mk2	1.5	P	X1		10	1985	06	1991	DBSR200
IVECO	Daily		2.0				07	1979	12	1999	DBSR300
IVECO	Daily		2.4				07	1979	12	1999	DBSR300
IVECO	Daily		2.5	D Turbo			07	1979	12	1999	DBSR300
JAGUAR	Daimler Double Six		5.4	P			01	1972	12	1985	DBSR300
JAGUAR	Daimler Sovereign		2.9	P			01	1969	12	1986	DBSR300
JAGUAR	E Type		4.2	P			01	1961	12	1975	DBSR200
JAGUAR	XJ6		2.8	P			01	1968	12	1986	DBSR300
JAGUAR	XJ12		5.3	P			01	1972	12	1985	DBSR300
JAGUAR	XJS		3.6	P			01	1975	12	1985	DBSR300
LANCIA	Dedra		1.8	P Inj			03	1990	01	1994	DBSR300
LANCIA	Dedra		2.0	P Inj			03	1990	01	1994	DBSR300
LANCIA	Delta		1.3	P		Inner boot with metal bush	01	1980	12	1983	DBSR200
LANCIA	Delta		1.3	P		Inner boot with metal bush	04	1986	02	1985	DBSR100
LANCIA	Delta		1.3	P		Inner boot with metal bush	04	1986	02	1985	DBSR100
LANCIA	Delta		1.3	P		Inner boot with metal bush	01	1983	12	1986	DBSR100
LANCIA	Delta		1.3	P		Inner boot with metal bush	01	1980	12	1983	DBSR200
LANCIA	Delta		1.3	P		Inner boot with metal bush	04	1986	12	1982	DBSR100
LANCIA	Delta		1.3	P		Inner boot with metal bush	01	1983	12	1986	DBSR100

Sheet1

LANCIA	Delta	1.3	P	Inner boot with metal bush	04	1986	12	1982	DBSR100
LANCIA	Delta	1.3	P	Inner boot with nylon bush	01	1980	12	1983	DBSR200
LANCIA	Delta	1.3	P	Inner boot with nylon bush	04	1986	02	1985	DBSR100
LANCIA	Delta	1.3	P	Inner boot with nylon bush	01	1983	12	1986	DBSR100
LANCIA	Delta	1.3	P	Inner boot with nylon bush	04	1986	02	1985	DBSR100
LANCIA	Delta	1.3	P	Inner boot with nylon bush	01	1980	12	1983	DBSR200
LANCIA	Delta	1.3	P	Inner boot with nylon bush	04	1986	12	1982	DBSR100
LANCIA	Delta	1.3	P	Inner boot with nylon bush	01	1983	12	1986	DBSR100
LANCIA	Delta	1.3	P	Inner boot with nylon bush	04	1986	12	1982	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with bush	01	1980	12	1983	DBSR200
LANCIA	Delta	1.3	P	LHS, Inner boot with bush	04	1986	10	1991	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with bush	01	1983	12	1986	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with bush	04	1986	10	1991	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with metal bush	01	1980	12	1983	DBSR200
LANCIA	Delta	1.3	P	LHS, Inner boot with metal bush	04	1986	10	1987	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with metal bush	04	1986	10	1987	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with metal bush	01	1983	12	1986	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with metal bush	01	1980	12	1983	DBSR200
LANCIA	Delta	1.3	P	LHS, Inner boot with metal bush	04	1986	10	1987	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with metal bush	01	1983	12	1986	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with metal bush	04	1986	10	1987	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with nylon bush	01	1980	12	1983	DBSR200
LANCIA	Delta	1.3	P	LHS, Inner boot with nylon bush	04	1986	10	1987	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with nylon bush	01	1983	12	1986	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with nylon bush	04	1986	10	1987	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with nylon bush	04	1986	10	1987	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot with nylon bush	01	1983	12	1986	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot without bush	01	1980	12	1983	DBSR200
LANCIA	Delta	1.3	P	LHS, Inner boot without bush	04	1986	10	1991	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot without bush	04	1986	10	1991	DBSR100
LANCIA	Delta	1.3	P	LHS, Inner boot without bush	01	1983	12	1986	DBSR100
LANCIA	Delta	1.3	P	RHS, Inner boot with bush	01	1980	12	1983	DBSR200
LANCIA	Delta	1.3	P	RHS, Inner boot with bush	04	1986	10	1991	DBSR100
LANCIA	Delta	1.3	P	RHS, Inner boot with bush	04	1986	10	1991	DBSR100

Sheet1

LANCIA	Delta	1.3	P	RHS, Inner boot with bush	01	1983	12	1986	DBSR100
LANCIA	Delta	1.3	P	RHS, Inner boot with metal bush	01	1980	12	1983	DBSR200
LANCIA	Delta	1.3	P	RHS, Inner boot with metal bush	04	1986	10	1987	DBSR100
LANCIA	Delta	1.3	P	RHS, Inner boot with metal bush	01	1983	12	1986	DBSR100
LANCIA	Delta	1.3	P	RHS, Inner boot with metal bush	04	1986	10	1987	DBSR100
LANCIA	Delta	1.3	P	RHS, Inner boot with nylon bush	01	1980	12	1983	DBSR200
LANCIA	Delta	1.3	P	RHS, Inner boot with nylon bush	04	1986	10	1987	DBSR100
LANCIA	Delta	1.3	P	RHS, Inner boot with nylon bush	01	1983	12	1986	DBSR100
LANCIA	Delta	1.3	P	RHS, Inner boot with nylon bush	04	1986	10	1987	DBSR100
LANCIA	Delta	1.3	P	RHS, Inner boot without bush	01	1980	12	1983	DBSR200
LANCIA	Delta	1.3	P	RHS, Inner boot without bush	04	1986	10	1991	DBSR100
LANCIA	Delta	1.3	P	RHS, Inner boot without bush	01	1983	12	1986	DBSR100
LANCIA	Delta	1.3	P	RHS, Inner boot without bush	04	1986	10	1991	DBSR100
LANCIA	Delta	1.5	P	Inner boot with metal bush	01	1983	12	1983	DBSR200
LANCIA	Delta	1.5	P	Inner boot with metal bush	01	1983	03	1984	DBSR100
LANCIA	Delta	1.5	P	Inner boot with metal bush	07	1980	12	1983	DBSR200
LANCIA	Delta	1.5	P	Inner boot with metal bush	01	1983	12	1982	DBSR100
LANCIA	Delta	1.5	P	Inner boot with nylon bush	01	1983	12	1983	DBSR200
LANCIA	Delta	1.5	P	Inner boot with nylon bush	01	1983	03	1984	DBSR100
LANCIA	Delta	1.5	P	Inner boot with nylon bush	07	1980	12	1983	DBSR200
LANCIA	Delta	1.5	P	Inner boot with nylon bush	01	1983	12	1982	DBSR100
LANCIA	Delta	1.6	P		06	1983	12	1983	DBSR200
LANCIA	Delta	1.6	P		04	1986	10	1991	DBSR100
LANCIA	Delta	1.6	P		04	1986	10	1991	DBSR100
LANCIA	Delta	1.6	P		06	1983	12	1986	DBSR100
LANCIA	Delta	1.6	P Turbo HF		06	1984	12	1983	DBSR200
LANCIA	Delta	1.6	P Turbo HF		04	1986	10	1991	DBSR100
LANCIA	Delta	1.6	P Turbo HF		04	1986	10	1991	DBSR100
LANCIA	Delta	1.6	P Turbo HF		06	1984	12	1986	DBSR100
LANCIA	Prisma	1.6	P		05	1983	05	1984	DBSR100
LANCIA	Prisma	1.6	P		06	1984	09	1991	DBSR100
LANCIA	Thema	2.0	P Inj		10	1986	06	1988	DBSR400
LANCIA	Thema	2.0	P Inj		10	1986	06	1988	DBSR300
LANCIA	Thema	2.0	P Inj		10	1986	01	1994	DBSR400
LANCIA	Thema	2.0	P Inj		10	1986	01	1994	DBSR300
LANCIA	Thema	2.0	P Inj		10	1986	05	1992	DBSR400

Sheet1

LANCIA	Thema	2.0	P Inj				10	1986	05	1992	DBSR300
LANCIA	Thema	2.8	P				10	1986	07	1987	DBSR400
LANCIA	Thema	2.8	P				10	1986	07	1987	DBSR300
LANCIA	Thema	2.8	P				10	1986	03	1988	DBSR400
LANCIA	Thema	2.8	P				10	1986	03	1988	DBSR300
LANCIA	Y10	1.0	P				03	1987	12	1991	DBSR100
LANCIA	Y10	1.05	P				03	1987	12	1991	DBSR100
LANCIA	Y10	1.1	P				03	1987	12	1991	DBSR100
LANCIA	Y10	1.3	P				03	1987	12	1991	DBSR100
MAZDA	323	Mk2	1.1	P	BD		01	1982	09	1985	DBSR300
MAZDA	323	Mk2	1.3	P	BD		01	1982	09	1985	DBSR300
MAZDA	323	Mk2	1.5	P	Auto, BD		01	1982	09	1985	DBSR300
MAZDA	323	Mk2	1.5	P	Manual, BD		01	1982	09	1985	DBSR300
MAZDA	323	Mk3	1.1	P	BF		09	1985	01	1987	DBSR300
MAZDA	323	Mk3	1.3	P	BF		09	1985	01	1990	DBSR300
MAZDA	323	Mk3	1.5	P	BF,BW		09	1985	10	1989	DBSR300
MAZDA	323	Mk3	1.6	P	BF		11	1985	10	1989	DBSR300
MAZDA	323	Mk3	1.6	P Turbo	4wd BF	Front	10	1986	10	1989	DBSR300
MAZDA	323	Mk3	1.6	P Turbo	4wd BF	Rear	10	1986	10	1989	DBSR300
MAZDA	323	Mk4	1.3	P Inj	BG		10	1989	06	1994	DBSR200
MAZDA	323	Mk4	1.6	P Inj	BG		10	1989	06	1994	DBSR200
MAZDA	323	Mk4	1.8	P Inj	BG		10	1989	06	1994	DBSR200
MAZDA	323	Mk5	1.3	P Inj	BA		08	1994	05	1998	DBSR200
MAZDA	323	Mk5	1.5	P Inj	BA		08	1994	05	1998	DBSR200
MAZDA	323	Mk5	1.8	P Inj	BA		11	1994	10	1998	DBSR200
MAZDA	323	Mk5	2.0	P Inj	BA		08	1994	10	1998	DBSR200
MAZDA	626	Mk3	1.8	P	GD		06	1988	02	1992	DBSR200
MAZDA	626	Mk3	2.0	P Inj	GD,GV Automatic	Trilobal inner joint	06	1988	02	1992	DBSR200
MAZDA	626	Mk3	2.0	P Inj	GD,GV Manual		06	1988	01	1993	DBSR200
MAZDA	626	Mk3	2.2	P Inj	GD,GV 4wd	Front	01	1990	01	1993	DBSR200
MAZDA	626	Mk4	1.8	P Inj	GE		02	1992	06	1997	DBSR200
MAZDA	626	Mk4	2.0	P Inj	GE		02	1992	06	1997	DBSR200
MAZDA	626	Mk4	2.0	D	CXD GE		05	1994	10	1995	DBSR200
MAZDA	626	Mk4	2.5	P Inj	GE		02	1992	12	1994	DBSR200
MERCEDES	LC' Sprinter	2.3	P	208D			01	1995	12	2000	DBSR300
MERCEDES	LC' Sprinter	2.3	P	210D			01	1995	12	2000	DBSR300

Sheet1

MERCEDES	LC' Sprinter	2.3	P	212D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P	214	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P	308D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P	310D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P	312D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P	410D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P	412D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P Inj	208D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P Inj	210D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P Inj	212D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P Inj	214	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P Inj	308D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P Inj	310D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P Inj	312D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P Inj	410D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.3	P Inj	412D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D	208D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D	210D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D	212D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D	214	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D	308D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D	310D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D	312D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D	410D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D	412D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D Turbo	208D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D Turbo	210D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D Turbo	212D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D Turbo	214	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D Turbo	308D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D Turbo	310D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D Turbo	312D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D Turbo	410D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Sprinter	2.9	D Turbo	412D	01	1995	12	2000	DBSR300		
MERCEDES	LC' Vito	Mk1	2.0	P Inj	113	Auto	09	1996	03	1999	DBSR300
MERCEDES	LC' Vito	Mk1	2.0	P Inj	113	Manual	09	1996	03	1999	DBSR300

Sheet1

MERCEDES	LC' Vito	Mk1	2.3	P Inj	108D		09	1996	03	1999	DBSR300
MERCEDES	LC' Vito	Mk2	2.0	P Inj	113 Auto		03	1999			DBSR300
MERCEDES	LC' Vito	Mk2	2.0	P Inj	113 Manual		03	1999			DBSR300
MERCEDES	LC' Vito	Mk2	2.2	P Inj	108 Auto		03	1999			DBSR300
MERCEDES	LC' Vito	Mk2	2.2	P Inj	108 Manual		03	1999			DBSR300
MERCEDES	LC' Vito	Mk2	2.2	P Inj	110 Auto		03	1999			DBSR300
MERCEDES	LC' Vito	Mk2	2.2	P Inj	110 Manual		03	1999			DBSR300
MERCEDES	LC' Vito	Mk2	2.2	P Inj	112 Auto		03	1999			DBSR300
MERCEDES	LC' Vito	Mk2	2.2	P Inj	112 Manual		03	1999			DBSR300
MITSUBISHI	Carisma		1.6	P Inj			10	1995			DBSR200
MITSUBISHI	Carisma		1.8	P Inj			02	1995			DBSR200
MITSUBISHI	Carisma		1.9	D Turbo			05	1997			DBSR200
MITSUBISHI	Colt	Mk3	1.3	P	C51A		06	1988	01	1992	DBSR200
MITSUBISHI	Colt	Mk3	1.3	P	C51A		06	1988	01	1992	DBSR100
MITSUBISHI	Colt	Mk3	1.5	P	C52A	Trilobal inner joint	04	1989	01	1992	DBSR200
MITSUBISHI	Colt	Mk3	1.5	P	C52A	Trilobal inner joint	04	1989	01	1992	DBSR100
MITSUBISHI	Galant	Mk3	1.6	P	E11A		01	1985	07	1988	DBSR200
MITSUBISHI	Galant	Mk3	1.8	D Turbo	E14A		01	1985	09	1989	DBSR200
MITSUBISHI	Galant	Mk3	2.0	P	E15A		01	1985	03	1988	DBSR200
MITSUBISHI	Galant	Mk3	2.0	P Turbo	E15A		03	1985	03	1988	DBSR200
MITSUBISHI	Galant	Mk3	2.4	P	E16A		10	1987	10	1989	DBSR200
MITSUBISHI	Galant	Mk4	1.8	P Inj	E32A	Trilobal inner joint	03	1988	02	1993	DBSR200
MITSUBISHI	Galant	Mk4	1.8	D Turbo	E34A		06	1988	02	1993	DBSR200
MITSUBISHI	Galant	Mk4	2.0	P Inj	4ws, 4wd E39A	Front, Trilobal inner joint	05	1989	02	1993	DBSR200
MITSUBISHI	Galant	Mk4	2.0	P Inj	4ws, 4wd E39A	Rear	05	1989	02	1993	DBSR200
MITSUBISHI	Galant	Mk4	2.0	P Inj	E33A	Trilobal inner joint	03	1988	02	1993	DBSR200
MITSUBISHI	Galant	Mk5	1.8	P	E52A		03	1993	04	1996	DBSR200
MITSUBISHI	Galant	Mk5	2.0	P	E54A,E55A		03	1993	04	1996	DBSR200
MITSUBISHI	Galant	Mk5	2.5	P	4ws E88A		03	1993	09	1995	DBSR200
MITSUBISHI	Lancer	Mk3	1.2	P	C15A		05	1984	05	1986	DBSR200
MITSUBISHI	Lancer	Mk3	1.2	P	C15A		05	1984	05	1986	DBSR100
MITSUBISHI	Lancer	Mk3	1.5	P	C12A		05	1984	08	1986	DBSR200
MITSUBISHI	Lancer	Mk3	1.5	P	C12A		05	1984	08	1986	DBSR100
MITSUBISHI	Lancer	Mk3	1.5	P	C12A		09	1986	08	1989	DBSR200
MITSUBISHI	Lancer	Mk3	1.5	P	C12A		09	1986	08	1989	DBSR100
MITSUBISHI	Lancer	Mk3	1.5	P	C12V		10	1985	08	1989	DBSR200

Sheet1

mitsubishi	Lancer	Mk3	1.5	P	C12V		10	1985	08	1989	DBSR100
mitsubishi	Lancer	Mk3	1.8	D	C14A		05	1984	08	1986	DBSR200
mitsubishi	Lancer	Mk3	1.8	D	C14A		05	1984	08	1986	DBSR100
mitsubishi	Lancer	Mk3	1.8	D	C14A		09	1986	07	1988	DBSR200
mitsubishi	Lancer	Mk3	1.8	D	C14A		09	1986	07	1988	DBSR100
mitsubishi	Lancer	Mk3	1.8	D	C14V		10	1985	08	1989	DBSR200
mitsubishi	Lancer	Mk3	1.8	D	C14V		10	1985	08	1989	DBSR100
mitsubishi	Lancer	Mk4	1.5	P	C62A	Trilobal inner joint	07	1988	10	1992	DBSR200
mitsubishi	Lancer	Mk4	1.5	P	C62A	Trilobal inner joint	07	1988	10	1992	DBSR100
mitsubishi	Lancer	Mk4	1.6	P Inj	Gti C63A	LHS	07	1988	04	1990	DBSR200
mitsubishi	Lancer	Mk4	1.6	P Inj	Gti C63A	LHS	07	1988	04	1990	DBSR100
mitsubishi	Lancer	Mk4	1.6	P Inj	Gti C63A	RHS	07	1988	04	1990	DBSR200
mitsubishi	Lancer	Mk4	1.6	P Inj	Gti C63A	RHS	07	1988	04	1990	DBSR100
mitsubishi	Lancer	Mk4	1.8	P	4wd C77A		08	1989	10	1992	DBSR200
mitsubishi	Lancer	Mk4	1.8	P	4wd C77A		08	1989	10	1992	DBSR100
mitsubishi	Lancer	Mk4	1.8	P Inj	Gti C68A	Trilobal inner joint	04	1990	10	1992	DBSR200
mitsubishi	Lancer	Mk4	1.8	P Inj	Gti C68A	Trilobal inner joint	04	1990	10	1992	DBSR100
mitsubishi	Lancer	Mk5	1.6	P Inj	C66A		10	1992	09	1995	DBSR100
mitsubishi	Lancer	Mk5	1.8	P Inj	C69A		10	1992	09	1995	DBSR100
mitsubishi	Space Wagon	Mk1	1.8	P	DO5		01	1986	05	1987	DBSR200
mitsubishi	Space Wagon	Mk1	1.8	P	DO5		01	1986	10	1991	DBSR200
mitsubishi	Space Wagon	Mk1	1.8	D Turbo	DO9		01	1986	09	1989	DBSR200
mitsubishi	Space Wagon	Mk2	1.8	P	N31		10	1991	12	1991	DBSR200
mitsubishi	Tredia		1.4	P	A211A		10	1982	10	1985	DBSR200
mitsubishi	Tredia		1.6	P	A212A		10	1982	10	1985	DBSR200
mitsubishi	Tredia		1.6	P Turbo	A212A		10	1982	10	1985	DBSR200
NISSAN	200 SX		1.8	P Inj			01	1989	12	1994	DBSR200
NISSAN	Almera	Mk1	1.4	P Inj	N15		10	1995	02	2000	DBSR200
NISSAN	Almera	Mk1	1.6	P Inj	N15		10	1995	02	2000	DBSR200
NISSAN	Almera	Mk1	2.0	D	GXD N15		10	1995	04	1999	DBSR200
NISSAN	Almera	Mk1	2.0	P Inj	Gti N15		07	1996	02	2000	DBSR200
NISSAN	Bluebird		1.6	P			01	1979	12	1984	DBSR200
NISSAN	Bluebird		1.8	P			01	1979	12	1984	DBSR200
NISSAN	Bluebird		2.0	P			01	1979	12	1984	DBSR200
NISSAN	Bluebird	Mk4	2.0	P	T12		01	1986	07	1987	DBSR500
NISSAN	Bluebird	Mk4	2.0	P	T72		01	1986	07	1988	DBSR500

Sheet1

NISSAN	Bluebird	Mk4	2.0	P	T72		01	1986	09	1990	DBSR500
NISSAN	Bluebird	Mk4	2.0	P	U11 Auto		01	1986	01	1986	DBSR500
NISSAN	Bluebird	Mk4	2.0	P	U11 Manual		01	1986	01	1986	DBSR500
NISSAN	Cherry		1.3	P	Europe		07	1983	12	1986	DBSR200
NISSAN	Cherry		1.5	P Inj	Europe		07	1983	12	1986	DBSR200
NISSAN	Cherry	Mk3	1.0	P	N10		04	1979	09	1982	DBSR200
NISSAN	Cherry	Mk3	1.2	P	N10		04	1979	10	1981	DBSR200
NISSAN	Cherry	Mk3	1.3	P	N10		10	1981	09	1982	DBSR200
NISSAN	Cherry	Mk3	1.4	P			04	1979	09	1982	DBSR200
NISSAN	Cherry	Mk3	1.5	P			04	1979	09	1982	DBSR200
NISSAN	Cherry	Mk4	1.0	P	N12		09	1982	04	1984	DBSR100
NISSAN	Cherry	Mk4	1.3	P	N12	LHS	09	1982	09	1986	DBSR100
NISSAN	Cherry	Mk4	1.3	P	N12	RHS	09	1982	09	1986	DBSR100
NISSAN	Cherry	Mk4	1.5	P	N12	LHS	09	1982	01	1985	DBSR100
NISSAN	Cherry	Mk4	1.5	P	N12	RHS	09	1982	01	1985	DBSR100
NISSAN	Cherry	Mk4	1.5	P Turbo	N12		10	1983	09	1986	DBSR100
NISSAN	Micra	Mk1	1.0	P Inj	K10		06	1983	12	1992	DBSR100
NISSAN	Micra	Mk1	1.2	P Inj	K10		03	1989	12	1992	DBSR100
NISSAN	Micra	Mk2	1.0	P	K11		01	1993	04	1998	DBSRPS200
NISSAN	Micra	Mk2	1.3	P	K11		01	1993	04	1998	DBSRPS200
NISSAN	Micra	Mk3	1.0	P Inj	K11		04	1998	12	2002	DBSRPS200
NISSAN	Micra	Mk3	1.3	P Inj	K11		04	1998	06	2000	DBSRPS200
NISSAN	Micra	Mk3	1.4	P Inj	K11		07	2000	12	2002	DBSRPS200
NISSAN	Prairie	Mk1	1.5	P	2wd M10		07	1983	02	1985	DBSR200
NISSAN	Prairie	Mk1	1.5	P	2wd M10		02	1985	08	1988	DBSR200
NISSAN	Prairie	Mk1	1.5	P	2wd M10		01	1985	08	1988	DBSRPS100
NISSAN	Prairie	Mk1	1.5	P	2wd M10	LHS	02	1985	01	1985	DBSR200
NISSAN	Prairie	Mk1	1.5	P	2wd M10	LHS	07	1983	02	1985	DBSR200
NISSAN	Prairie	Mk1	1.5	P	2wd M10	LHS	06	1983	01	1985	DBSRPS100
NISSAN	Prairie	Mk1	1.5	P	2wd M10	RHS	07	1983	02	1985	DBSR200
NISSAN	Prairie	Mk1	1.5	P	2wd M10	RHS	02	1985	01	1985	DBSR200
NISSAN	Prairie	Mk1	1.5	P	2wd M10	RHS	06	1983	01	1985	DBSRPS100
NISSAN	Prairie	Mk1	1.8	P	2wd M10		03	1985	02	1985	DBSR200
NISSAN	Prairie	Mk1	1.8	P	2wd M10		03	1985	08	1988	DBSRPS100
NISSAN	Prairie	Mk1	1.8	P	2wd M10		09	1983	02	1985	DBSR200
NISSAN	Prairie	Mk1	1.8	P	2wd M10		09	1983	08	1988	DBSRPS100

Sheet1

NISSAN	Prairie	Mk2	2.0	P	2wd M11 Auto	LHS	04	1989	12	1991	DBSRPS200
NISSAN	Prairie	Mk2	2.0	P	2wd M11 Auto	RHS	04	1989	12	1991	DBSRPS200
NISSAN	Prairie	Mk2	2.0	P	2wd M11 Manual		04	1989	12	1991	DBSRPS200
NISSAN	Prairie	Mk2	2.0	P	4wd M11	Front	04	1989	12	1991	DBSRPS200
NISSAN	Prairie	Mk2	2.0	P	4wd M11	Rear	04	1989	12	1991	DBSRPS200
NISSAN	Primera	Mk1	1.6	P Inj	P10		09	1990	11	1996	DBSR200
NISSAN	Primera	Mk1	1.6	P Inj	W10		01	1992	11	1996	DBSR200
NISSAN	Primera	Mk1	2.0	P Inj	P10		09	1990	11	1996	DBSR200
NISSAN	Primera	Mk1	2.0	P Inj	W10		02	1991	03	1998	DBSR200
NISSAN	Primera	Mk1	2.0	D	P10 Auto		10	1991	05	1996	DBSR200
NISSAN	Primera	Mk1	2.0	D	P10 Manual		06	1992	11	1996	DBSR200
NISSAN	Primera	Mk1	2.0	D	W10		06	1995	11	1996	DBSR200
NISSAN	Primera	Mk2	1.6	P Inj	P11		10	1996	08	1999	DBSR200
NISSAN	Primera	Mk2	1.6	P Inj	WP11		04	1998	08	1999	DBSR200
NISSAN	Primera	Mk2	2.0	D Turbo	P11		10	1996	08	1999	DBSR200
NISSAN	Primera	Mk2	2.0	D Turbo	WP11		04	1998	08	1999	DBSR200
NISSAN	Primera	Mk2	2.0	P Inj	P11		10	1996	08	1999	DBSR200
NISSAN	Primera	Mk2	2.0	P Inj	WP11		04	1998	08	1999	DBSR200
NISSAN	Stanza		1.6	P	T11		01	1982	01	1985	DBSR200
NISSAN	Stanza		1.6	P	T12		01	1985	03	1986	DBSR200
NISSAN	Sunny	Mk4	1.3	P	B11	LHS	08	1983	09	1986	DBSR500
NISSAN	Sunny	Mk4	1.3	P	B11	RHS	08	1983	09	1986	DBSR500
NISSAN	Sunny	Mk4	1.5	P	B11	LHS	05	1982	09	1986	DBSR100
NISSAN	Sunny	Mk4	1.5	P	B11	RHS	05	1982	09	1986	DBSR100
NISSAN	Sunny	Mk5	1.3	P	N13	LHS	09	1986	12	1991	DBSR500
NISSAN	Sunny	Mk5	1.3	P	N13	LHS	09	1986	12	1991	DBSR500
NISSAN	Sunny	Mk5	1.3	P	N13	RHS	09	1986	12	1991	DBSR500
NISSAN	Sunny	Mk5	1.3	P	N13	RHS	09	1986	12	1991	DBSR500
NISSAN	Sunny	Mk5	1.5	P			09	1986	12	1991	DBSR500
NISSAN	Sunny	Mk5	1.5	P			09	1986	12	1989	DBSR100
NISSAN	Sunny	Mk5	1.6	P	B12, N13 Auto	LHS	09	1986	12	1991	DBSR500
NISSAN	Sunny	Mk5	1.6	P	B12, N13 Auto	RHS	09	1986	12	1991	DBSR500
NISSAN	Sunny	Mk5	1.6	P	B12, N13 Manual		09	1986	03	1989	DBSR500
NISSAN	Sunny	Mk5	1.6	P	ZX B12		08	1987	05	1989	DBSR500
NISSAN	Sunny	Mk5	1.6	P	B12, N13	LHS	03	1989	12	1991	DBSR500
NISSAN	Sunny	Mk5	1.6	P	B12, N13	RHS	03	1989	12	1991	DBSR500

Sheet1

NISSAN	Sunny	Mk5	1.8	P	ZX N13		03	1989	12	1991	DBSR500
NISSAN	Sunny	Mk5	1.8	P Inj	Gti N13		03	1989	12	1991	DBSR500
NISSAN	Sunny	Mk6	1.4	P Inj	N14 Auto		04	1991	10	1995	DBSR500
NISSAN	Sunny	Mk6	1.4	P Inj	N14 Manual	LHS	04	1991	10	1995	DBSR500
NISSAN	Sunny	Mk6	1.4	P Inj	N14 Manual	RHS	04	1991	10	1995	DBSR500
NISSAN	Sunny	Mk6	1.6	P Inj	N14,Y10		04	1991	10	1995	DBSR500
NISSAN	Sunny	Mk6	2.0	P Inj	Gti N14		01	1992	08	1994	DBSR500
NISSAN	Sunny	Mk6	2.0	D	N14	LHS	06	1992	10	1995	DBSR500
NISSAN	Sunny	Mk6	2.0	D	N14	RHS	06	1992	10	1995	DBSR500
NISSAN LCV	Sunny Van		1.3	P	B11	LHS	08	1983	07	1992	DBSR500
NISSAN LCV	Sunny Van		1.3	P	B11	RHS	08	1983	07	1992	DBSR500
NISSAN LCV	Sunny Van		1.7	D	Y10	LHS	08	1992	12	1995	DBSR500
NISSAN LCV	Sunny Van		1.7	D	Y10	RHS	08	1992	12	1995	DBSR500
OPEL	Ascona	C	1.6	P			01	1981	12	1986	DBSR300
OPEL	Ascona	C	1.6	P	Auto		01	1981	12	1986	DBSR300
OPEL	Ascona	C	1.6	P	Manual		01	1981	12	1986	DBSR300
OPEL	Ascona	C	1.6	P	Manual		01	1981	12	1986	DBSR300
OPEL	Kadett	D	1.2	P			01	1980	07	1984	DBSR300
OPEL	Kadett	D	1.3	P			01	1980	07	1984	DBSR300
OPEL	Kadett	D	1.6	P	Auto		01	1980	07	1984	DBSR300
OPEL	Kadett	D	1.6	P	Manual		01	1980	07	1984	DBSR300
PEUGEOT	104		1.0	P		Inner boot with tin case	01	1978	12	1983	DBSR200
PEUGEOT	104		1.0	P		Inner boot with tin case	05	1973	12	1978	DBSR100
PEUGEOT	104		1.0	P		Inner boot without tin case	01	1978	12	1983	DBSR200
PEUGEOT	104		1.0	P		Inner boot without tin case	05	1973	12	1978	DBSR100
PEUGEOT	104		1.0	P		Outer boot for 76mm joint	01	1978	12	1983	DBSR200
PEUGEOT	104		1.0	P		Outer boot for 76mm joint	05	1973	12	1978	DBSR100
PEUGEOT	104		1.0	P		Outer boot for 86mm joint	01	1978	12	1983	DBSR200
PEUGEOT	104		1.0	P		Outer boot for 86mm joint	05	1973	12	1978	DBSR100
PEUGEOT	104		1.1	P		Inner boot with tin case	01	1978	12	1983	DBSR200
PEUGEOT	104		1.1	P		Inner boot with tin case	01	1977	12	1978	DBSR100
PEUGEOT	104		1.1	P		Inner boot without tin case	01	1978	12	1983	DBSR200
PEUGEOT	104		1.1	P		Inner boot without tin case	01	1977	12	1978	DBSR100
PEUGEOT	104		1.1	P		Outer boot for 76mm joint	01	1978	12	1983	DBSR200
PEUGEOT	104		1.1	P		Outer boot for 76mm joint	01	1977	12	1978	DBSR100
PEUGEOT	104		1.1	P		Outer boot for 86mm joint	01	1978	12	1983	DBSR200

Sheet1

PEUGEOT	104	1.1	P	Outer boot for 86mm joint	01	1977	12	1978	DBSR100
PEUGEOT	104	1.2	P	Inner boot with tin case	01	1979	12	1983	DBSR200
PEUGEOT	104	1.2	P	Inner boot without tin case	01	1979	12	1983	DBSR200
PEUGEOT	104	1.2	P	Outer boot for 76mm joint	01	1979	12	1983	DBSR200
PEUGEOT	104	1.2	P	Outer boot for 86mm joint	01	1979	12	1983	DBSR200
PEUGEOT	104	1.4	P	Inner boot with tin case	01	1979	12	1983	DBSR200
PEUGEOT	104	1.4	P	Inner boot without tin case	01	1979	12	1983	DBSR200
PEUGEOT	104	1.4	P	Outer boot for 76mm joint	01	1979	12	1983	DBSR200
PEUGEOT	104	1.4	P	Outer boot for 86mm joint	01	1979	12	1983	DBSR200
PEUGEOT	205	1.0	P Inj	Inner boot with tin case	01	1983	12	1988	DBSR200
PEUGEOT	205	1.0	P Inj	Inner boot with tin case	01	1988	07	1987	DBSR200
PEUGEOT	205	1.0	P Inj	Inner boot with tin case	01	1983	07	1987	DBSR500
PEUGEOT	205	1.0	P Inj	Inner boot with tin case	01	1988	05	1996	DBSR200
PEUGEOT	205	1.0	P Inj	Inner boot with tin case	08	1987	12	1988	DBSR200
PEUGEOT	205	1.0	P Inj	Inner boot with tin case	08	1987	05	1996	DBSR500
PEUGEOT	205	1.0	P Inj	Inner boot without tin case	01	1988	07	1987	DBSR200
PEUGEOT	205	1.0	P Inj	Inner boot without tin case	01	1983	12	1988	DBSR200
PEUGEOT	205	1.0	P Inj	Inner boot without tin case	01	1983	07	1987	DBSR500
PEUGEOT	205	1.0	P Inj	Inner boot without tin case	01	1988	05	1996	DBSR200
PEUGEOT	205	1.0	P Inj	Inner boot without tin case	08	1987	12	1988	DBSR200
PEUGEOT	205	1.0	P Inj	Inner boot without tin case	08	1987	05	1996	DBSR500
PEUGEOT	205	1.0	P Inj	Outer boot for 76mm joint	01	1988	07	1987	DBSR200
PEUGEOT	205	1.0	P Inj	Outer boot for 76mm joint	01	1983	12	1988	DBSR200
PEUGEOT	205	1.0	P Inj	Outer boot for 76mm joint	01	1983	07	1987	DBSR500
PEUGEOT	205	1.0	P Inj	Outer boot for 86mm joint	01	1983	12	1988	DBSR200
PEUGEOT	205	1.0	P Inj	Outer boot for 86mm joint	01	1988	07	1987	DBSR200
PEUGEOT	205	1.0	P Inj	Outer boot for 86mm joint	01	1983	07	1987	DBSR500
PEUGEOT	205	1.1	P Inj	Inner boot with tin case	01	1988	07	1987	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot with tin case	01	1987	07	1987	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot with tin case	01	1988	12	1991	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot with tin case	01	1983	12	1988	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot with tin case	01	1983	07	1987	DBSR500
PEUGEOT	205	1.1	P Inj	Inner boot with tin case	01	1988	05	1996	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot with tin case	08	1987	12	1988	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot with tin case	01	1988	12	1991	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot with tin case	01	1987	05	1996	DBSR200

Sheet1

PEUGEOT	205	1.1	P Inj	Inner boot with tin case	08	1987	05	1996	DBSR500
PEUGEOT	205	1.1	P Inj	Inner boot without tin case	01	1988	12	1991	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot without tin case	01	1988	07	1987	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot without tin case	01	1987	07	1987	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot without tin case	01	1983	12	1988	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot without tin case	01	1983	07	1987	DBSR500
PEUGEOT	205	1.1	P Inj	Inner boot without tin case	08	1987	12	1988	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot without tin case	01	1987	05	1996	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot without tin case	01	1988	05	1996	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot without tin case	01	1988	12	1991	DBSR200
PEUGEOT	205	1.1	P Inj	Inner boot without tin case	08	1987	05	1996	DBSR500
PEUGEOT	205	1.1	P Inj	Outer boot for 76mm joint	01	1988	07	1987	DBSR200
PEUGEOT	205	1.1	P Inj	Outer boot for 76mm joint	01	1987	07	1987	DBSR200
PEUGEOT	205	1.1	P Inj	Outer boot for 76mm joint	01	1988	12	1991	DBSR200
PEUGEOT	205	1.1	P Inj	Outer boot for 76mm joint	01	1983	12	1988	DBSR200
PEUGEOT	205	1.1	P Inj	Outer boot for 76mm joint	01	1983	07	1987	DBSR500
PEUGEOT	205	1.1	P Inj	Outer boot for 86mm joint	01	1983	12	1988	DBSR200
PEUGEOT	205	1.1	P Inj	Outer boot for 86mm joint	01	1988	12	1991	DBSR200
PEUGEOT	205	1.1	P Inj	Outer boot for 86mm joint	01	1988	07	1987	DBSR200
PEUGEOT	205	1.1	P Inj	Outer boot for 86mm joint	01	1987	07	1987	DBSR200
PEUGEOT	205	1.1	P Inj	Outer boot for 86mm joint	01	1983	07	1987	DBSR500
PEUGEOT	205	1.3	P Inj		01	1988	12	1991	DBSR200
PEUGEOT	205	1.3	P Inj		01	1983	05	1996	DBSR500
PEUGEOT	205	1.4	P Inj	Inner boot with tin case	08	1987	12	1988	DBSR200
PEUGEOT	205	1.4	P Inj	Inner boot with tin case	01	1988	07	1994	DBSR200
PEUGEOT	205	1.4	P Inj	Inner boot with tin case	01	1990	07	1994	DBSR200
PEUGEOT	205	1.4	P Inj	Inner boot with tin case	08	1987	07	1994	DBSR500
PEUGEOT	205	1.4	P Inj	Inner boot with tin case	10	1983	12	1988	DBSR200
PEUGEOT	205	1.4	P Inj	Inner boot with tin case	01	1988	07	1987	DBSR200
PEUGEOT	205	1.4	P Inj	Inner boot with tin case	01	1990	07	1987	DBSR200
PEUGEOT	205	1.4	P Inj	Inner boot with tin case	10	1983	07	1987	DBSR500
PEUGEOT	205	1.4	P Inj	Inner boot without tin case	01	1990	07	1994	DBSR200
PEUGEOT	205	1.4	P Inj	Inner boot without tin case	08	1987	12	1988	DBSR200
PEUGEOT	205	1.4	P Inj	Inner boot without tin case	01	1988	07	1994	DBSR200
PEUGEOT	205	1.4	P Inj	Inner boot without tin case	08	1987	07	1994	DBSR500
PEUGEOT	205	1.4	P Inj	Inner boot without tin case	01	1990	07	1987	DBSR200

Sheet1

PEUGEOT	205	1.4	P Inj		Inner boot without tin case	10	1983	12	1988	DBSR200
PEUGEOT	205	1.4	P Inj		Inner boot without tin case	01	1988	07	1987	DBSR200
PEUGEOT	205	1.4	P Inj		Inner boot without tin case	10	1983	07	1987	DBSR500
PEUGEOT	205	1.6	P Inj		Inner boot for clover leaf shape joint	01	1984	05	1996	DBSR200
PEUGEOT	205	1.6	P Inj		Inner boot for clover leaf shape joint	10	1983	05	1996	DBSR500
PEUGEOT	205	1.6	P Inj		Inner boot with tin case	01	1984	05	1996	DBSR200
PEUGEOT	205	1.6	P Inj		Inner boot with tin case	10	1983	05	1996	DBSR500
PEUGEOT	205	1.6	P Inj		Inner boot without tin case	01	1984	05	1996	DBSR200
PEUGEOT	205	1.6	P Inj		Inner boot without tin case	10	1983	05	1996	DBSR500
PEUGEOT	205	1.8	D		Inner boot for clover leaf shape joint	10	1983	05	1996	DBSR200
PEUGEOT	205	1.8	D		Inner boot with tin case	10	1983	05	1996	DBSR200
PEUGEOT	205	1.8	D		Inner boot without tin case	10	1983	05	1996	DBSR200
PEUGEOT	205	1.8	D Turbo		Inner boot for clover leaf shape joint	10	1983	05	1996	DBSR200
PEUGEOT	205	1.8	D Turbo		Inner boot for clover leaf shape joint	10	1983	05	1996	DBSR500
PEUGEOT	205	1.8	D Turbo		Inner boot with tin case	10	1983	05	1996	DBSR200
PEUGEOT	205	1.8	D Turbo		Inner boot with tin case	10	1983	05	1996	DBSR500
PEUGEOT	205	1.8	D Turbo		Inner boot without tin case	10	1983	05	1996	DBSR200
PEUGEOT	205	1.8	D Turbo		Inner boot without tin case	10	1983	05	1996	DBSR500
PEUGEOT	205	1.9	P Inj			01	1987	01	1994	DBSR200
PEUGEOT	205	1.9	P Inj			01	1987	01	1994	DBSR500
PEUGEOT	206	1.1	P Inj		Trilobal inner joint	10	1998			DBSR300
PEUGEOT	206	1.4	P Inj	Auto		01	1999			DBSR300
PEUGEOT	206	1.4	P Inj	Manual	Trilobal inner joint	10	1998			DBSR300
PEUGEOT	206	1.6	P Inj	Auto		05	1999			DBSR300
PEUGEOT	206	1.6	P Inj	Manual	Trilobal inner joint	10	1998			DBSR300
PEUGEOT	206	1.9	D			10	1998			DBSR300
PEUGEOT	206	2.0	D Turbo			06	1999			DBSR300
PEUGEOT	304	1.3	P		Inner boot with tin case	01	1979	12	1980	DBSR200
PEUGEOT	304	1.3	P		Inner boot without tin case	01	1979	12	1980	DBSR200
PEUGEOT	305	1.3	P		Inner boot with tin case	05	1978	12	1983	DBSR200
PEUGEOT	305	1.3	P		Inner boot with tin case	01	1983	07	1988	DBSR200
PEUGEOT	305	1.3	P		Inner boot without tin case	01	1983	07	1988	DBSR200
PEUGEOT	305	1.3	P		Inner boot without tin case	05	1978	12	1983	DBSR200
PEUGEOT	305	1.5	P		Inner boot with tin case	05	1978	12	1983	DBSR200
PEUGEOT	305	1.5	P		Inner boot with tin case	01	1983	07	1988	DBSR200
PEUGEOT	305	1.5	P		Inner boot without tin case	01	1983	07	1988	DBSR200

Sheet1

PEUGEOT	305		1.5	P		Inner boot without tin case	05	1978	12	1983	DBSR200
PEUGEOT	305		1.6	P	Manual	Inner boot for 76mm joint	08	1983	07	1988	DBSR200
PEUGEOT	305		1.6	P	Manual	Inner boot for 88mm joint	08	1983	07	1988	DBSR200
PEUGEOT	305		1.9	D		Inner boot for 76mm joint	01	1983	08	1989	DBSR500
PEUGEOT	305		1.9	D		Inner boot for 88mm joint	01	1983	08	1989	DBSR500
PEUGEOT	305		1.9	P Inj			01	1983	12	1985	DBSR200
PEUGEOT	305		1.9	P Inj			01	1983	08	1989	DBSR200
PEUGEOT	305		1.9	P Inj			01	1983	08	1989	DBSR500
PEUGEOT	305		1.9	P Inj			01	1983	12	1985	DBSR500
PEUGEOT	306	Mk1	1.4	P			04	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.4	P			10	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.4	P		Inner boot with tin case	04	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.4	P		Inner boot with tin case	10	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.4	P		Inner boot without tin case	04	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.4	P		Inner boot without tin case	10	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.6	P		Inner boot with tin case	04	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.6	P		Inner boot with tin case	10	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.6	P		Inner boot with tin case	04	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.6	P		Inner boot with tin case	10	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.6	P		Inner boot without tin case	04	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.6	P		Inner boot without tin case	10	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.6	P		Inner boot without tin case	04	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.6	P		Inner boot without tin case	10	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.8	P			04	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.8	P			10	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.8	P			04	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.8	P			10	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.9	D			06	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.9	D			10	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.9	D			06	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.9	D			10	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.9	D Turbo			07	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	1.9	D Turbo			10	1993	04	1997	DBSR200
PEUGEOT	306	Mk1	2.0	P Inj			01	1994	04	1997	DBSR200
PEUGEOT	306	Mk1	2.0	P Inj			01	1994	04	1997	DBSR200
PEUGEOT	306	Mk2	1.4	P Inj		Trilobal inner joint	04	1997	05	2002	DBSR200

Sheet1

PEUGEOT	306	Mk2	1.4	P Inj	Trilobal inner joint	04	1997	05	2002	DBSR200
PEUGEOT	306	Mk2	1.6	P Inj	Trilobal inner joint	04	1997	09	2002	DBSR200
PEUGEOT	306	Mk2	1.6	P Inj	Trilobal inner joint	04	1997	09	2002	DBSR200
PEUGEOT	306	Mk2	1.8	P Inj		04	1997	09	2002	DBSR200
PEUGEOT	306	Mk2	1.8	P Inj		04	1997	09	2002	DBSR200
PEUGEOT	306	Mk2	1.9	D		04	1997	05	2002	DBSR200
PEUGEOT	306	Mk2	1.9	D		04	1997	05	2002	DBSR200
PEUGEOT	306	Mk2	1.9	D Turbo		04	1997	05	2002	DBSR200
PEUGEOT	306	Mk2	1.9	D Turbo		04	1997	05	2002	DBSR200
PEUGEOT	306	Mk2	2.0	P Inj		04	1997	12	2000	DBSR200
PEUGEOT	306	Mk2	2.0	P Inj		04	1997	12	2000	DBSR200
PEUGEOT	306	Mk2	2.0	D Turbo Hdi		05	1999	05	2002	DBSR200
PEUGEOT	306	Mk2	2.0	D Turbo Hdi		05	1999	05	2002	DBSR200
PEUGEOT	309		1.1	P	Outer boot with 1 locating ring	02	1986	12	1991	DBSR200
PEUGEOT	309		1.1	P	Outer boot with 1 locating ring	02	1986	05	1989	DBSR500
PEUGEOT	309		1.1	P	Outer boot with 2 locating rings	02	1986	12	1991	DBSR200
PEUGEOT	309		1.1	P	Outer boot with 2 locating rings	02	1986	05	1989	DBSR500
PEUGEOT	309		1.1	P	Inner boot for 70mm joint	02	1986	12	1991	DBSR200
PEUGEOT	309		1.1	P	Inner boot for 70mm joint	02	1986	05	1989	DBSR500
PEUGEOT	309		1.1	P	Inner boot for 76mm joint	02	1986	12	1991	DBSR200
PEUGEOT	309		1.1	P	Inner boot for 76mm joint	02	1986	05	1989	DBSR500
PEUGEOT	309		1.1	P	Inner boot with tin case	06	1989	12	1991	DBSR200
PEUGEOT	309		1.1	P	Inner boot with tin case	06	1989	08	1992	DBSR500
PEUGEOT	309		1.1	P	Inner boot without tin case	06	1989	12	1991	DBSR200
PEUGEOT	309		1.1	P	Inner boot without tin case	06	1989	08	1992	DBSR500
PEUGEOT	309		1.3	P	Outer boot with 1 locating ring	02	1986	10	1991	DBSR200
PEUGEOT	309		1.3	P	Outer boot with 1 locating ring	02	1986	10	1991	DBSR500
PEUGEOT	309		1.3	P	Outer boot with 2 locating rings	02	1986	10	1991	DBSR200
PEUGEOT	309		1.3	P	Outer boot with 2 locating rings	02	1986	10	1991	DBSR500
PEUGEOT	309		1.3	P	Inner boot for 70mm joint	02	1986	10	1991	DBSR200
PEUGEOT	309		1.3	P	Inner boot for 70mm joint	02	1986	10	1991	DBSR500
PEUGEOT	309		1.3	P	Inner boot for 76mm joint	02	1986	10	1991	DBSR200
PEUGEOT	309		1.3	P	Inner boot for 76mm joint	02	1986	10	1991	DBSR500
PEUGEOT	309		1.4	P Inj	Inner boot with tin case	06	1991	12	1991	DBSR200
PEUGEOT	309		1.4	P Inj	Inner boot with tin case	06	1991	06	1993	DBSR500
PEUGEOT	309		1.4	P Inj	Inner boot without tin case	06	1991	12	1991	DBSR200

Sheet1

PEUGEOT	309	1.4	P Inj		Inner boot without tin case	06	1991	06	1993	DBSR500
PEUGEOT	309	1.6	P Inj		Outer boot with 1 locating ring	02	1986	12	1990	DBSR200
PEUGEOT	309	1.6	P Inj		Outer boot with 1 locating ring	02	1986	12	1991	DBSR200
PEUGEOT	309	1.6	P Inj		Outer boot with 1 locating ring	01	1987	12	1990	DBSR500
PEUGEOT	309	1.6	P Inj		Outer boot with 1 locating ring	02	1986	06	1993	DBSR500
PEUGEOT	309	1.6	P Inj		Outer boot with 2 locating rings	02	1986	12	1990	DBSR200
PEUGEOT	309	1.6	P Inj		Outer boot with 2 locating rings	02	1986	12	1991	DBSR200
PEUGEOT	309	1.6	P Inj		Outer boot with 2 locating rings	02	1986	06	1993	DBSR500
PEUGEOT	309	1.6	P Inj		Outer boot with 2 locating rings	01	1987	12	1990	DBSR500
PEUGEOT	309	1.8	D Turbo			09	1989	12	1991	DBSR200
PEUGEOT	309	1.8	D Turbo			09	1989	06	1993	DBSR200
PEUGEOT	309	1.8	D Turbo			09	1989	06	1993	DBSR500
PEUGEOT	309	1.9	D			09	1986	06	1993	DBSR200
PEUGEOT	309	1.9	D			09	1986	12	1991	DBSR200
PEUGEOT	309	1.9	D			01	1989	12	1990	DBSR200
PEUGEOT	309	1.9	D			09	1986	06	1993	DBSR500
PEUGEOT	309	1.9	P			04	1987	12	1991	DBSR200
PEUGEOT	309	1.9	P			01	1989	12	1990	DBSR200
PEUGEOT	309	1.9	P			04	1987	10	1992	DBSR200
PEUGEOT	309	1.9	P			04	1987	10	1992	DBSR500
PEUGEOT	309	1.9	P Inj	Gti		04	1987	12	1990	DBSR200
PEUGEOT	309	1.9	P Inj	Gti		04	1987	10	1992	DBSR500
PEUGEOT	405	1.4	P Inj		Inner boot with tin case	10	1992	08	1993	DBSR600
PEUGEOT	405	1.4	P Inj		Inner boot without tin case	10	1992	08	1993	DBSR600
PEUGEOT	405	1.6	P Inj			01	1988	09	1995	DBSR100
PEUGEOT	405	1.6	P Inj			01	1989	09	1995	DBSR200
PEUGEOT	405	1.6	P Inj			02	1991	09	1995	DBSR100
PEUGEOT	405	1.6	P Inj			01	1989	09	1995	DBSR200
PEUGEOT	405	1.8	D Turbo			08	1988	02	1997	DBSR200
PEUGEOT	405	1.8	P			01	1992	02	1997	DBSR200
PEUGEOT	405	1.9	P Carb	Fwd		01	1988	10	1992	DBSR200
PEUGEOT	405	1.9	P inj	4wd	Front	05	1989	10	1992	DBSR600
PEUGEOT	405	1.9	P inj	4wd	Rear	05	1989	10	1992	DBSR600
PEUGEOT	405	1.9	P inj	Fwd		01	1988	06	1992	DBSR600
PEUGEOT	405	1.9	P inj	Fwd		01	1988	10	1992	DBSR600
PEUGEOT	405	1.9	D Turbo			10	1992	02	1997	DBSR100

Sheet1

PEUGEOT	405		2.0	P Inj	4wd	Front	04	1993	03	1994	DBSR200
PEUGEOT	405		2.0	P Inj	4wd	Rear	04	1993	03	1994	DBSR200
PEUGEOT	405		2.0	P Inj	Fwd		10	1992	02	1997	DBSR200
PEUGEOT	406	Mk1	1.8	P Inj		24mm shaft	02	1996	03	1999	DBSR100
PEUGEOT	406	Mk1	1.8	P Inj		35mm shaft	02	1996	03	1999	DBSR100
PEUGEOT	406	Mk1	1.9	D Turbo		24mm shaft	02	1996	03	1999	DBSR100
PEUGEOT	406	Mk1	1.9	D Turbo		35mm shaft	02	1996	03	1999	DBSR100
PEUGEOT	406	Mk1	2.0	P Inj	Auto		11	1996	03	1999	DBSR100
PEUGEOT	406	Mk1	2.0	P Inj	Manual	24mm shaft	02	1996	06	1999	DBSR100
PEUGEOT	406	Mk1	2.0	P Inj	Manual	35mm shaft	02	1996	06	1999	DBSR100
PEUGEOT	406	Mk1	2.0	P Turbo			07	1996	03	1999	DBSR100
PEUGEOT	406	Mk1	2.1	D Turbo			07	1996	11	1998	DBSR100
PEUGEOT	406	Mk1	3.0	P Inj	V6		01	1997	06	1999	DBSR100
PEUGEOT	406	Mk2	1.8	P Inj		24mm shaft	03	1999			DBSR100
PEUGEOT	406	Mk2	1.8	P Inj		35mm shaft	03	1999			DBSR100
PEUGEOT	406	Mk2	2.0	P Inj	Auto		03	1999			DBSR100
PEUGEOT	406	Mk2	2.0	P Inj	Manual	24mm shaft	03	1999			DBSR100
PEUGEOT	406	Mk2	2.0	P Inj	Manual	35mm shaft	03	1999			DBSR100
PEUGEOT	406	Mk2	2.0	D Turbo			10	2000			DBSR100
PEUGEOT	406	Mk2	2.2	P Inj			07	2000			DBSR100
PEUGEOT	406	Mk2	2.2	D Turbo			10	2000			DBSR100
PEUGEOT	406	Mk2	3.0	P Inj			03	1999			DBSR100
PEUGEOT	504		1.8	P		Rear, Outer boot with tin case	01	1975	07	1979	DBSR200
PEUGEOT	504		1.8	P		Rear, Outer boot with tin case	01	1979	06	1982	DBSR200
PEUGEOT	504		1.8	P		Rear, Outer boot without tin case	01	1979	06	1982	DBSR200
PEUGEOT	504		1.8	P		Rear, Outer boot without tin case	01	1975	07	1979	DBSR200
PEUGEOT	504		1.8	P		Rear, Inner boot with tin case	01	1975	07	1979	DBSR200
PEUGEOT	504		1.8	P		Rear, Inner boot with tin case	01	1979	06	1982	DBSR200
PEUGEOT	504		1.8	P		Rear, Inner boot without tin case	01	1979	06	1982	DBSR200
PEUGEOT	504		1.8	P		Rear, Inner boot without tin case	01	1975	07	1979	DBSR200
PEUGEOT	504		1.8	P		Rear	01	1979	06	1982	DBSR200
PEUGEOT	504		1.8	P		Rear	01	1975	07	1979	DBSR200
PEUGEOT	504		2.0	P		Rear, Outer boot with tin case	01	1975	07	1979	DBSR200
PEUGEOT	504		2.0	P		Rear, Outer boot with tin case	01	1979	06	1982	DBSR200
PEUGEOT	504		2.0	P		Rear, Outer boot without tin case	01	1975	07	1979	DBSR200
PEUGEOT	504		2.0	P		Rear, Outer boot without tin case	01	1979	06	1982	DBSR200

Sheet1

PEUGEOT	504	2.0	P	Rear, Inner boot with tin case	01	1979	06	1982	DBSR200
PEUGEOT	504	2.0	P	Rear, Inner boot with tin case	01	1975	07	1979	DBSR200
PEUGEOT	504	2.0	P	Rear, Inner boot without tin case	01	1979	06	1982	DBSR200
PEUGEOT	504	2.0	P	Rear, Inner boot without tin case	01	1975	07	1979	DBSR200
PEUGEOT	504	2.0	P	Rear	01	1979	06	1982	DBSR200
PEUGEOT	504	2.0	P	Rear	01	1975	07	1979	DBSR200
PEUGEOT	504	2.1	D	Rear, Outer boot with tin case	01	1975	07	1979	DBSR200
PEUGEOT	504	2.1	D	Rear, Outer boot with tin case	01	1979	06	1982	DBSR200
PEUGEOT	504	2.1	D	Rear, Outer boot without tin case	01	1975	07	1979	DBSR200
PEUGEOT	504	2.1	D	Rear, Outer boot without tin case	01	1979	06	1982	DBSR200
PEUGEOT	504	2.1	D	Rear, Inner boot with tin case	01	1975	07	1979	DBSR200
PEUGEOT	504	2.1	D	Rear, Inner boot with tin case	01	1979	06	1982	DBSR200
PEUGEOT	504	2.1	D	Rear, Inner boot without tin case	01	1975	07	1979	DBSR200
PEUGEOT	504	2.1	D	Rear, Inner boot without tin case	01	1979	06	1982	DBSR200
PEUGEOT	504	2.1	D	Rear	01	1979	06	1982	DBSR200
PEUGEOT	504	2.1	D	Rear	01	1975	07	1979	DBSR200
PEUGEOT	504	2.3	D	Rear, Outer boot with tin case	01	1975	07	1979	DBSR200
PEUGEOT	504	2.3	D	Rear, Outer boot with tin case	01	1979	06	1982	DBSR200
PEUGEOT	504	2.3	D	Rear, Outer boot without tin case	01	1975	07	1979	DBSR200
PEUGEOT	504	2.3	D	Rear, Outer boot without tin case	01	1979	06	1982	DBSR200
PEUGEOT	504	2.3	D	Rear, Inner boot with tin case	01	1979	06	1982	DBSR200
PEUGEOT	504	2.3	D	Rear, Inner boot with tin case	01	1975	07	1979	DBSR200
PEUGEOT	504	2.3	D	Rear, Inner boot without tin case	01	1975	07	1979	DBSR200
PEUGEOT	504	2.3	D	Rear, Inner boot without tin case	01	1979	06	1982	DBSR200
PEUGEOT	504	2.3	D	Rear	01	1979	06	1982	DBSR200
PEUGEOT	504	2.3	D	Rear	01	1975	07	1979	DBSR200
PEUGEOT	505	1.6	P		01	1985	12	1986	DBSR200
PEUGEOT	505	1.6	P		01	1986	12	1988	DBSR200
PEUGEOT	505	2.0	P		01	1979	12	1988	DBSR200
PEUGEOT	505	2.0	P Inj		01	1979	12	1988	DBSR200
PEUGEOT	505	2.2	P		01	1985	12	1992	DBSR200
PEUGEOT	505	2.3	P		01	1979	12	1988	DBSR200
PEUGEOT	505	2.5	D		01	1979	12	1988	DBSR200
PEUGEOT	505	2.5	D		01	1985	12	1992	DBSR200
PEUGEOT	605	2.0	P Inj		09	1990	01	1995	DBSR600
PEUGEOT	605	2.0	P		03	1993	12	1998	DBSR600

Sheet1

PEUGEOT	605	2.0	P Turbo		03	1993	12	1998	DBSR600
PEUGEOT	605	2.1	D Turbo		10	1990	12	1998	DBSR600
PEUGEOT	605	3.0	P Inj		09	1990	01	1997	DBSR600
PEUGEOT	806	1.9	D Turbo		10	1995	08	1999	DBSR300
PEUGEOT	806	2.0	P Inj		10	1995	05	2000	DBSR300
PEUGEOT	806	2.0	D Turbo		08	1999	07	2002	DBSR300
PEUGEOT	806	2.0	P Inj		05	2000	07	2002	DBSR300
PEUGEOT	Partner	1.4	P Inj		06	2001			DBSR500
PEUGEOT	Partner	1.4	P Inj		06	2001			DBSR500
PEUGEOT	Partner	1.9	D	24mm shaft	06	2001			DBSR500
PEUGEOT	Partner	1.9	D	35mm shaft	06	2001			DBSR500
PEUGEOT	Partner	2.0	D Turbo Hdi	24mm shaft	10	2002			DBSR500
PEUGEOT	Partner	2.0	D Turbo Hdi	35mm shaft	10	2002			DBSR500
PEUGEOT LCV	Boxer	1.9	D Turbo		06	1994	12	1997	DBSR300
PEUGEOT LCV	Boxer	1.9	D Turbo		06	1994	03	2002	DBSR300
PEUGEOT LCV	Boxer	2.0	P Inj		06	1994	12	1997	DBSR300
PEUGEOT LCV	Boxer	2.0	P Inj		06	1994	03	2002	DBSR300
PEUGEOT LCV	Boxer	2.0	P Inj		06	1994	12	1997	DBSR300
PEUGEOT LCV	Boxer	2.0	P Inj		06	1994	03	2002	DBSR300
PEUGEOT LCV	Expert	1.9	D		09	1996			DBSR300
PEUGEOT LCV	Expert	1.9	D Turbo		09	1996			DBSR300
PEUGEOT LCV	Expert	2.0	D Turbo Hdi		09	1996			DBSR300
PEUGEOT LCV	Partner Van	1.4	P Inj		06	2001			DBSR500
PEUGEOT LCV	Partner Van	1.4	P Inj		06	2001			DBSR500
PEUGEOT LCV	Partner Van	1.8	D	24mm shaft	10	2002			DBSR500
PEUGEOT LCV	Partner Van	1.8	D	24mm shaft	10	2002			DBSR500
PEUGEOT LCV	Partner Van	1.8	D	35mm shaft	10	2002			DBSR500
PEUGEOT LCV	Partner Van	1.8	D	35mm shaft	10	2002			DBSR500
PEUGEOT LCV	Partner Van	1.9	D	24mm shaft	06	2001			DBSR500
PEUGEOT LCV	Partner Van	1.9	D	35mm shaft	06	2001			DBSR500
PEUGEOT LCV	Partner Van	2.0	D Turbo Hdi	24mm shaft	01	2000			DBSR500
PEUGEOT LCV	Partner Van	2.0	D Turbo Hdi	35mm shaft	01	2000			DBSR500
PROTON	Persona	1.3	P Inj	C96A	10	1995	03	2000	DBSR200
PROTON	Persona	1.5	P	C97A	11	1993	03	2000	DBSR200
PROTON	Persona	1.6	P	C98A	11	1993	03	2000	DBSR200
PROTON	Persona	1.8	P Inj	DOHC C99A	07	1996	03	2000	DBSR200

Sheet1

PROTON	Persona	1.8	P Inj	SOHC C99A		04	1996	03	2000	DBSR200
PROTON	Persona	2.0	D	C95A		04	1996	04	1997	DBSR200
PROTON	Persona	2.0	D Turbo	C95A		04	1997	03	2000	DBSR200
RENAULT	4	0.85	P			11	1968	12	1979	DBSR100
RENAULT	4	0.85	P			11	1968	06	1979	DBSR100
RENAULT	4	1.1	P			01	1979	07	1986	DBSR100
RENAULT	5	Mk1	0.85	P		01	1976	03	1985	DBSR100
RENAULT	5	Mk2	0.95	P Inj	LHS, Inner boot without bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	0.95	P Inj	LHS, Inner boot with 22.5mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	0.95	P Inj	LHS, Inner boot with 23.8mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	0.95	P Inj	LHS, Inner boot with 25.8mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	0.95	P Inj	Outer boot for 76mm joint x 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	0.95	P Inj	Outer boot for 86mm joint x 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	0.95	P Inj	Outer boot for 86mm joint x 35mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	0.95	P Inj	RHS, Inner boot for 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	0.95	P Inj	RHS, Inner boot for 35mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.1	P Inj	LHS, Inner boot without bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.1	P Inj	LHS, Inner boot without bearing	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.1	P Inj	LHS, Inner boot with 22.5mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.1	P Inj	LHS, Inner boot with 22.5mm bearing	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.1	P Inj	LHS, Inner boot with 23.8mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.1	P Inj	LHS, Inner boot with 23.8mm bearing	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.1	P Inj	LHS, Inner boot with 25.8mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.1	P Inj	LHS, Inner boot with 25.8mm bearing	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.1	P Inj	Outer boot for 76mm joint x 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.1	P Inj	Outer boot for 76mm joint x 25mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.1	P Inj	Outer boot for 86mm joint x 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.1	P Inj	Outer boot for 86mm joint x 25mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.1	P Inj	Outer boot for 86mm joint x 35mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.1	P Inj	Outer boot for 86mm joint x 35mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.1	P Inj	RHS, Inner boot for 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.1	P Inj	RHS, Inner boot for 25mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.1	P Inj	RHS, Inner boot for 35mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.1	P Inj	RHS, Inner boot for 35mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.2	P Inj	LHS, Inner boot without bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.2	P Inj	LHS, Inner boot with 22.5mm bearing	01	1985	12	1990	DBSR100

Sheet1

RENAULT	5	Mk2	1.2	P Inj	LHS, Inner boot with 23.8mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.2	P Inj	LHS, Inner boot with 25.8mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.2	P Inj	Outer boot for 76mm joint x 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.2	P Inj	Outer boot for 86mm joint x 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.2	P Inj	Outer boot for 86mm joint x 35mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.2	P Inj	RHS, Inner boot for 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.2	P Inj	RHS, Inner boot for 35mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.4	P Inj	LHS, Inner boot without bearing	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.4	P Inj	LHS, Inner boot with 22.5mm bearing	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.4	P Inj	LHS, Inner boot with 23.8mm bearing	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.4	P Inj	LHS, Inner boot with 25.8mm bearing	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.4	P Inj	Outer boot for 76mm joint x 25mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.4	P Inj	Outer boot for 86mm joint x 25mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.4	P Inj	Outer boot for 86mm joint x 35mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.4	P Inj	RHS, Inner boot for 25mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.4	P Inj	RHS, Inner boot for 35mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.6	D	LHS, Inner boot without bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.6	D	LHS, Inner boot without bearing	01	1985	12	1990	DBSR200
RENAULT	5	Mk2	1.6	D	LHS, Inner boot without bearing	01	1986	12	1990	DBSRPS200
RENAULT	5	Mk2	1.6	D	LHS, Inner boot without bearing	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.6	D	LHS, Inner boot with 22.5mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.6	D	LHS, Inner boot with 22.5mm bearing	01	1985	12	1990	DBSR200
RENAULT	5	Mk2	1.6	D	LHS, Inner boot with 22.5mm bearing	01	1986	12	1990	DBSRPS200
RENAULT	5	Mk2	1.6	D	LHS, Inner boot with 22.5mm bearing	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.6	D	LHS, Inner boot with 23.8mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.6	D	LHS, Inner boot with 23.8mm bearing	01	1985	12	1990	DBSR200
RENAULT	5	Mk2	1.6	D	LHS, Inner boot with 23.8mm bearing	01	1986	12	1990	DBSRPS200
RENAULT	5	Mk2	1.6	D	LHS, Inner boot with 23.8mm bearing	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.6	D	LHS, Inner boot with 25.8mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.6	D	LHS, Inner boot with 25.8mm bearing	01	1985	12	1990	DBSR200
RENAULT	5	Mk2	1.6	D	LHS, Inner boot with 25.8mm bearing	01	1986	12	1990	DBSRPS200
RENAULT	5	Mk2	1.6	D	LHS, Inner boot with 25.8mm bearing	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.6	D	Outer boot for 76mm joint x 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.6	D	Outer boot for 76mm joint x 25mm shaft	01	1985	12	1990	DBSR200
RENAULT	5	Mk2	1.6	D	Outer boot for 76mm joint x 25mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.6	D	Outer boot for 76mm joint x 25mm shaft	01	1986	12	1990	DBSRPS200

Sheet1

RENAULT	5	Mk2	1.6	D	Outer boot for 86mm joint x 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.6	D	Outer boot for 86mm joint x 25mm shaft	01	1985	12	1990	DBSR200
RENAULT	5	Mk2	1.6	D	Outer boot for 86mm joint x 25mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.6	D	Outer boot for 86mm joint x 25mm shaft	01	1986	12	1990	DBSRPS200
RENAULT	5	Mk2	1.6	D	Outer boot for 86mm joint x 35mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.6	D	Outer boot for 86mm joint x 35mm shaft	01	1985	12	1990	DBSR200
RENAULT	5	Mk2	1.6	D	Outer boot for 86mm joint x 35mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.6	D	Outer boot for 86mm joint x 35mm shaft	01	1986	12	1990	DBSRPS200
RENAULT	5	Mk2	1.6	D	RHS, Inner boot for 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.6	D	RHS, Inner boot for 25mm shaft	01	1985	12	1990	DBSR200
RENAULT	5	Mk2	1.6	D	RHS, Inner boot for 25mm shaft	01	1986	12	1990	DBSRPS200
RENAULT	5	Mk2	1.6	D	RHS, Inner boot for 25mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.6	D	RHS, Inner boot for 35mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.6	D	RHS, Inner boot for 35mm shaft	01	1985	12	1990	DBSR200
RENAULT	5	Mk2	1.6	D	RHS, Inner boot for 35mm shaft	01	1986	03	1996	DBSRPS200
RENAULT	5	Mk2	1.6	D	RHS, Inner boot for 35mm shaft	01	1986	12	1990	DBSRPS200
RENAULT	5	Mk2	1.7	P Inj	LHS, Inner boot without bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.7	P Inj	LHS, Inner boot without bearing	01	1985	12	1990	DBSRPS200
RENAULT	5	Mk2	1.7	P Inj	LHS, Inner boot with 22.5mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.7	P Inj	LHS, Inner boot with 22.5mm bearing	01	1985	12	1990	DBSRPS200
RENAULT	5	Mk2	1.7	P Inj	LHS, Inner boot with 23.8mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.7	P Inj	LHS, Inner boot with 23.8mm bearing	01	1985	12	1990	DBSRPS200
RENAULT	5	Mk2	1.7	P Inj	LHS, Inner boot with 25.8mm bearing	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.7	P Inj	LHS, Inner boot with 25.8mm bearing	01	1985	12	1990	DBSRPS200
RENAULT	5	Mk2	1.7	P Inj	Outer boot for 76mm joint x 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.7	P Inj	Outer boot for 76mm joint x 25mm shaft	01	1985	12	1990	DBSRPS200
RENAULT	5	Mk2	1.7	P Inj	Outer boot for 86mm joint x 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.7	P Inj	Outer boot for 86mm joint x 25mm shaft	01	1985	12	1990	DBSRPS200
RENAULT	5	Mk2	1.7	P Inj	Outer boot for 86mm joint x 35mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.7	P Inj	Outer boot for 86mm joint x 35mm shaft	01	1985	12	1990	DBSRPS200
RENAULT	5	Mk2	1.7	P Inj	RHS, Inner boot for 25mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.7	P Inj	RHS, Inner boot for 25mm shaft	01	1985	12	1990	DBSRPS200
RENAULT	5	Mk2	1.7	P Inj	RHS, Inner boot for 35mm shaft	01	1985	12	1990	DBSR100
RENAULT	5	Mk2	1.7	P Inj	RHS, Inner boot for 35mm shaft	01	1985	12	1990	DBSRPS200
RENAULT	6		0.8	P		01	1973	12	1979	DBSR100
RENAULT	6		1.1	P		01	1973	12	1979	DBSR100

Sheet1

RENAULT	9	1.1	P	LHS, Inner boot without bearing	01	1985	12	1987	DBSR100
RENAULT	9	1.1	P	LHS, Inner boot with 22.5mm bearing	01	1985	12	1987	DBSR100
RENAULT	9	1.1	P	LHS, Inner boot with 25.8mm bearing	01	1985	12	1987	DBSR100
RENAULT	9	1.1	P	Outer boot for 86mm joint with 1 locating lip	01	1985	12	1987	DBSR100
RENAULT	9	1.1	P	Outer boot for 86mm joint with 2 locating lips	01	1985	12	1987	DBSR100
RENAULT	9	1.1	P	Outer boot for 76mm joint	01	1985	12	1987	DBSR100
RENAULT	9	1.1	P	RHS	01	1985	12	1987	DBSR100
RENAULT	9	1.4	P	LHS, Inner boot without bearing	01	1985	12	1987	DBSR100
RENAULT	9	1.4	P	LHS, Inner boot with 22.5mm bearing	01	1985	12	1987	DBSR100
RENAULT	9	1.4	P	LHS, Inner boot with 25.8mm bearing	01	1985	12	1987	DBSR100
RENAULT	9	1.4	P	Outer boot for 86mm joint with 1 locating lip	01	1985	12	1987	DBSR100
RENAULT	9	1.4	P	Outer boot for 86mm joint with 2 locating lips	01	1985	12	1987	DBSR100
RENAULT	9	1.4	P	Outer boot for 76mm joint	01	1985	12	1987	DBSR100
RENAULT	9	1.4	P	RHS	01	1985	12	1987	DBSR100
RENAULT	9	1.6	D	LHS, Inner boot without bearing	01	1985	12	1987	DBSR100
RENAULT	9	1.6	D	LHS, Inner boot without bearing	01	1985	12	1987	DBSRPS200
RENAULT	9	1.6	D	LHS, Inner boot with 22.5mm bearing	01	1985	12	1987	DBSR100
RENAULT	9	1.6	D	LHS, Inner boot with 22.5mm bearing	01	1985	12	1987	DBSRPS200
RENAULT	9	1.6	D	LHS, Inner boot with 25.8mm bearing	01	1985	12	1987	DBSR100
RENAULT	9	1.6	D	LHS, Inner boot with 25.8mm bearing	01	1985	12	1987	DBSRPS200
RENAULT	9	1.6	D	Outer boot for 86mm joint with 1 locating lip	01	1985	12	1987	DBSR100
RENAULT	9	1.6	D	Outer boot for 86mm joint with 1 locating lip	01	1985	12	1987	DBSRPS200
RENAULT	9	1.6	D	Outer boot for 86mm joint with 2 locating lips	01	1985	12	1987	DBSR100
RENAULT	9	1.6	D	Outer boot for 86mm joint with 2 locating lips	01	1985	12	1987	DBSRPS200
RENAULT	9	1.6	D	Outer boot for 76mm joint	01	1985	12	1987	DBSR100
RENAULT	9	1.6	D	Outer boot for 76mm joint	01	1985	12	1987	DBSRPS200
RENAULT	9	1.6	D	RHS	01	1985	12	1987	DBSR100
RENAULT	9	1.6	D	RHS	01	1985	12	1987	DBSRPS200
RENAULT	9	1.7	P	LHS, Inner boot without bearing	01	1985	12	1987	DBSR100
RENAULT	9	1.7	P	LHS, Inner boot without bearing	01	1985	12	1987	DBSRPS200
RENAULT	9	1.7	P	LHS, Inner boot with 22.5mm bearing	01	1985	12	1987	DBSR100
RENAULT	9	1.7	P	LHS, Inner boot with 22.5mm bearing	01	1985	12	1987	DBSRPS200
RENAULT	9	1.7	P	LHS, Inner boot with 25.8mm bearing	01	1985	12	1987	DBSR100
RENAULT	9	1.7	P	LHS, Inner boot with 25.8mm bearing	01	1985	12	1987	DBSRPS200
RENAULT	9	1.7	P	Outer boot for 86mm joint with 1 locating lip	01	1985	12	1987	DBSR100
RENAULT	9	1.7	P	Outer boot for 86mm joint with 1 locating lip	01	1985	12	1987	DBSRPS200

Sheet1

RENAULT	9	1.7	P	Outer boot for 86mm joint with 2 locating lips	01	1985	12	1987	DBSR100
RENAULT	9	1.7	P	Outer boot for 86mm joint with 2 locating lips	01	1985	12	1987	DBSRPS200
RENAULT	9	1.7	P	Outer boot for 76mm joint	01	1985	12	1987	DBSR100
RENAULT	9	1.7	P	Outer boot for 76mm joint	01	1985	12	1987	DBSRPS200
RENAULT	9	1.7	P	RHS	01	1985	12	1987	DBSR100
RENAULT	9	1.7	P	RHS	01	1985	12	1987	DBSRPS200
RENAULT	11	1.1	P	LHS, Inner boot without bearing	09	1983	06	1989	DBSR100
RENAULT	11	1.1	P	LHS, Inner boot with 22.5mm bearing	09	1983	06	1989	DBSR100
RENAULT	11	1.1	P	LHS, Inner boot with 25.8mm bearing	09	1983	06	1989	DBSR100
RENAULT	11	1.1	P	Outer boot for 86mm joint with 1 locating lip	09	1983	06	1989	DBSR100
RENAULT	11	1.1	P	Outer boot for 86mm joint with 2 locating lips	09	1983	06	1989	DBSR100
RENAULT	11	1.1	P	Outer boot for 76mm joint	09	1983	06	1989	DBSR100
RENAULT	11	1.1	P	RHS	09	1983	06	1989	DBSR100
RENAULT	11	1.4	P	LHS, Inner boot without bearing	09	1983	06	1989	DBSR100
RENAULT	11	1.4	P	LHS, Inner boot with 22.5mm bearing	09	1983	06	1989	DBSR100
RENAULT	11	1.4	P	LHS, Inner boot with 25.8mm bearing	09	1983	06	1989	DBSR100
RENAULT	11	1.4	P	Outer boot for 86mm joint with 1 locating lip	09	1983	06	1989	DBSR100
RENAULT	11	1.4	P	Outer boot for 86mm joint with 2 locating lips	09	1983	06	1989	DBSR100
RENAULT	11	1.4	P	Outer boot for 76mm joint	09	1983	06	1989	DBSR100
RENAULT	11	1.4	P	RHS	09	1983	06	1989	DBSR100
RENAULT	11	1.6	D	LHS, Inner boot without bearing	09	1983	06	1989	DBSR100
RENAULT	11	1.6	D	LHS, Inner boot without bearing	09	1983	06	1989	DBSRPS200
RENAULT	11	1.6	D	LHS, Inner boot with 22.5mm bearing	09	1983	06	1989	DBSR100
RENAULT	11	1.6	D	LHS, Inner boot with 22.5mm bearing	09	1983	06	1989	DBSRPS200
RENAULT	11	1.6	D	LHS, Inner boot with 25.8mm bearing	09	1983	06	1989	DBSR100
RENAULT	11	1.6	D	LHS, Inner boot with 25.8mm bearing	09	1983	06	1989	DBSRPS200
RENAULT	11	1.6	D	Outer boot for 86mm joint with 1 locating lip	09	1983	06	1989	DBSR100
RENAULT	11	1.6	D	Outer boot for 86mm joint with 1 locating lip	09	1983	06	1989	DBSRPS200
RENAULT	11	1.6	D	Outer boot for 86mm joint with 2 locating lips	09	1983	06	1989	DBSR100
RENAULT	11	1.6	D	Outer boot for 86mm joint with 2 locating lips	09	1983	06	1989	DBSRPS200
RENAULT	11	1.6	D	Outer boot for 76mm joint	09	1983	06	1989	DBSR100
RENAULT	11	1.6	D	Outer boot for 76mm joint	09	1983	06	1989	DBSRPS200
RENAULT	11	1.6	D	RHS	09	1983	06	1989	DBSR100
RENAULT	11	1.6	D	RHS	09	1983	06	1989	DBSRPS200
RENAULT	11	1.7	P	LHS, Inner boot without bearing	09	1983	06	1989	DBSR100
RENAULT	11	1.7	P	LHS, Inner boot without bearing	09	1983	06	1989	DBSRPS200

Sheet1

RENAULT	11	1.7	P		LHS, Inner boot with 22.5mm bearing	09	1983	06	1989	DBSR100
RENAULT	11	1.7	P		LHS, Inner boot with 22.5mm bearing	09	1983	06	1989	DBSRPS200
RENAULT	11	1.7	P		LHS, Inner boot with 25.8mm bearing	09	1983	06	1989	DBSR100
RENAULT	11	1.7	P		LHS, Inner boot with 25.8mm bearing	09	1983	06	1989	DBSRPS200
RENAULT	11	1.7	P		Outer boot for 86mm joint with 1 locating lip	09	1983	06	1989	DBSR100
RENAULT	11	1.7	P		Outer boot for 86mm joint with 1 locating lip	09	1983	06	1989	DBSRPS200
RENAULT	11	1.7	P		Outer boot for 86mm joint with 2 locating lips	09	1983	06	1989	DBSR100
RENAULT	11	1.7	P		Outer boot for 86mm joint with 2 locating lips	09	1983	06	1989	DBSRPS200
RENAULT	11	1.7	P		Outer boot for 76mm joint	09	1983	06	1989	DBSR100
RENAULT	11	1.7	P		Outer boot for 76mm joint	09	1983	06	1989	DBSRPS200
RENAULT	11	1.7	P		RHS	09	1983	06	1989	DBSR100
RENAULT	11	1.7	P		RHS	09	1983	06	1989	DBSRPS200
RENAULT	14	1.2	P		Inner boot with tin case	07	1979	12	1982	DBSR100
RENAULT	14	1.2	P		Inner boot with tin case	01	1977	07	1979	DBSR100
RENAULT	14	1.2	P		Inner boot without tin case	07	1979	12	1982	DBSR100
RENAULT	14	1.2	P		Inner boot without tin case	01	1977	07	1979	DBSR100
RENAULT	14	1.4	P		Inner boot with tin case	07	1979	12	1982	DBSR100
RENAULT	14	1.4	P		Inner boot with tin case	01	1977	07	1979	DBSR100
RENAULT	14	1.4	P		Inner boot without tin case	07	1979	12	1982	DBSR100
RENAULT	14	1.4	P		Inner boot without tin case	01	1977	07	1979	DBSR100
RENAULT	18	1.4	P			12	1978	04	1984	DBSR100
RENAULT	18	1.4	P			01	1979	04	1984	DBSRPS200
RENAULT	18	1.6	P			12	1978	07	1986	DBSR100
RENAULT	18	1.6	P			01	1979	07	1986	DBSRPS200
RENAULT	18	1.6	P Turbo			11	1980	07	1985	DBSRPS200
RENAULT	18	2.0	P			11	1981	07	1985	DBSRPS200
RENAULT	18	2.1	D			10	1980	07	1986	DBSR200
RENAULT	18	2.1	D			10	1980	07	1986	DBSRPS200
RENAULT	19	1.4	P Inj	Auto	LHS, Inner boot without bearing	02	1989	02	1996	DBSR100
RENAULT	19	1.4	P Inj	Auto	LHS, Inner boot with 23.8mm bearing	02	1989	02	1996	DBSR100
RENAULT	19	1.4	P Inj	Auto	LHS, Inner boot with 25.8mm bearing	02	1989	02	1996	DBSR100
RENAULT	19	1.4	P Inj	Auto	RHS	02	1989	02	1996	DBSR100
RENAULT	19	1.4	P Inj	Manual	LHS, Inner boot without bearing	02	1989	02	1996	DBSR100
RENAULT	19	1.4	P Inj	Manual	LHS, Inner boot without bearing	02	1989	02	1996	DBSR100
RENAULT	19	1.4	P Inj	Manual	LHS, Inner boot with 23.8mm bearing	02	1989	02	1996	DBSR100
RENAULT	19	1.4	P Inj	Manual	LHS, Inner boot with 23.8mm bearing	02	1989	02	1996	DBSR100

Sheet1

RENAULT	19	1.4	P Inj	Manual	LHS, Inner boot with 25.8mm bearing	02	1989	02	1996	DBSR100
RENAULT	19	1.4	P Inj	Manual	LHS, Inner boot with 25.8mm bearing	02	1989	02	1996	DBSR100
RENAULT	19	1.4	P Inj	Manual	RHS	02	1989	02	1996	DBSR100
RENAULT	19	1.4	P Inj	Manual	RHS	02	1989	02	1996	DBSR100
RENAULT	19	1.7	P Inj	Manual	LHS, Inner boot without bearing	02	1989	05	1992	DBSR100
RENAULT	19	1.7	P Inj	Manual	LHS, Inner boot without bearing	02	1989	05	1992	DBSRPS200
RENAULT	19	1.7	P Inj	Manual	LHS, Inner boot with 23.8mm bearing	02	1989	05	1992	DBSR100
RENAULT	19	1.7	P Inj	Manual	LHS, Inner boot with 23.8mm bearing	02	1989	05	1992	DBSRPS200
RENAULT	19	1.7	P Inj	Manual	LHS, Inner boot with 25.8mm bearing	02	1989	05	1992	DBSR100
RENAULT	19	1.7	P Inj	Manual	LHS, Inner boot with 25.8mm bearing	02	1989	05	1992	DBSRPS200
RENAULT	19	1.7	P Inj	Manual	RHS	02	1989	05	1992	DBSR100
RENAULT	19	1.7	P Inj	Manual	RHS	02	1989	05	1992	DBSRPS200
RENAULT	19	1.8	P Inj	Auto	LHS, Inner boot without bearing	05	1992	02	1996	DBSR100
RENAULT	19	1.8	P Inj	Auto	LHS, Inner boot without bearing	05	1992	02	1996	DBSRPS200
RENAULT	19	1.8	P Inj	Auto	LHS, Inner boot with 23.8mm bearing	05	1992	02	1996	DBSR100
RENAULT	19	1.8	P Inj	Auto	LHS, Inner boot with 23.8mm bearing	05	1992	02	1996	DBSRPS200
RENAULT	19	1.8	P Inj	Auto	LHS, Inner boot with 25.8mm bearing	05	1992	02	1996	DBSR100
RENAULT	19	1.8	P Inj	Auto	LHS, Inner boot with 25.8mm bearing	05	1992	02	1996	DBSRPS200
RENAULT	19	1.8	P Inj	Auto	RHS	05	1992	02	1996	DBSR100
RENAULT	19	1.8	P Inj	Auto	RHS	05	1992	02	1996	DBSRPS200
RENAULT	19	1.8	P Inj	Manual	LHS, Inner boot without bearing	03	1991	02	1996	DBSR100
RENAULT	19	1.8	P Inj	Manual	LHS, Inner boot without bearing	03	1991	02	1996	DBSRPS200
RENAULT	19	1.8	P Inj	Manual	LHS, Inner boot with 23.8mm bearing	03	1991	02	1996	DBSR100
RENAULT	19	1.8	P Inj	Manual	LHS, Inner boot with 23.8mm bearing	03	1991	02	1996	DBSRPS200
RENAULT	19	1.8	P Inj	Manual	LHS, Inner boot with 25.8mm bearing	03	1991	02	1996	DBSR100
RENAULT	19	1.8	P Inj	Manual	LHS, Inner boot with 25.8mm bearing	03	1991	02	1996	DBSRPS200
RENAULT	19	1.8	P Inj	Manual	RHS	03	1991	02	1996	DBSR100
RENAULT	19	1.8	P Inj	Manual	RHS	03	1991	02	1996	DBSRPS200
RENAULT	19	1.9	D		LHS, Inner boot without bearing	02	1989	10	1995	DBSRPS200
RENAULT	19	1.9	D		LHS, Inner boot with 23.8mm bearing	02	1989	10	1995	DBSRPS200
RENAULT	19	1.9	D		LHS, Inner boot with 25.8mm bearing	02	1989	10	1995	DBSRPS200
RENAULT	19	1.9	D		RHS	02	1989	10	1995	DBSRPS200
RENAULT	19	1.9	D Turbo		LHS, Inner boot without bearing	10	1991	02	1996	DBSRPS200
RENAULT	19	1.9	D Turbo		LHS, Inner boot with 23.8mm bearing	10	1991	02	1996	DBSRPS200
RENAULT	19	1.9	D Turbo		LHS, Inner boot with 25.8mm bearing	10	1991	02	1996	DBSRPS200
RENAULT	19	1.9	D Turbo		RHS	10	1991	02	1996	DBSRPS200

Sheet1

RENAULT	20	1.6	P			10	1976	06	1980	DBSR200
RENAULT	20	1.6	P			01	1980	06	1980	DBSRPS200
RENAULT	20	2.0	P			07	1977	12	1981	DBSR200
RENAULT	20	2.0	P			01	1980	07	1980	DBSRPS200
RENAULT	20	2.0	P			08	1980	12	1981	DBSR200
RENAULT	20	2.0	P			01	1980	11	1983	DBSRPS200
RENAULT	20	2.1	D			08	1980	12	1983	DBSR200
RENAULT	20	2.1	D			08	1980	12	1983	DBSRPS200
RENAULT	20	2.2	P	Auto		10	1980	12	1981	DBSR200
RENAULT	20	2.2	P	Auto		10	1980	11	1983	DBSRPS200
RENAULT	20	2.2	P	Manual		10	1980	12	1981	DBSR200
RENAULT	20	2.2	P	Manual		10	1980	11	1983	DBSRPS200
RENAULT	21	1.7	P Inj	Auto		02	1991	10	1995	DBSR100
RENAULT	21	1.7	P Inj	Auto		02	1991	10	1995	DBSRPS200
RENAULT	21	1.7	P Inj	Auto		02	1991	10	1995	DBSR100
RENAULT	21	1.7	P Inj	Auto		02	1991	10	1995	DBSRPS200
RENAULT	21	1.7	P Inj	Manual	LHS, Inner boot without bearing	06	1986	10	1995	DBSR100
RENAULT	21	1.7	P Inj	Manual	LHS, Inner boot without bearing	06	1986	10	1995	DBSRPS200
RENAULT	21	1.7	P Inj	Manual	LHS, Inner boot with 25.8mm bearing	06	1986	10	1995	DBSR100
RENAULT	21	1.7	P Inj	Manual	LHS, Inner boot with 25.8mm bearing	06	1986	10	1995	DBSRPS200
RENAULT	21	1.7	P Inj	Manual	RHS	06	1986	10	1995	DBSR100
RENAULT	21	1.7	P Inj	Manual	RHS	06	1986	10	1995	DBSRPS200
RENAULT	21	2.0	P Inj	Auto		04	1987	10	1995	DBSR100
RENAULT	21	2.0	P Inj	Auto		04	1987	10	1995	DBSRPS200
RENAULT	21	2.0	P Inj	Auto		04	1987	10	1995	DBSR100
RENAULT	21	2.0	P Inj	Auto		04	1987	10	1995	DBSRPS200
RENAULT	21	2.0	P Inj	Manual		06	1986	10	1995	DBSR100
RENAULT	21	2.0	P Inj	Manual		06	1986	10	1995	DBSRPS200
RENAULT	25	2.0	P Inj			07	1984	12	1986	DBSR200
RENAULT	25	2.0	P Inj			07	1984	10	1992	DBSRPS200
RENAULT	25	2.0	P Inj			07	1984	12	1990	DBSRPS200
RENAULT	25	2.0	P Inj		Ball bearing type outer joint	07	1984	12	1986	DBSR200
RENAULT	25	2.0	P Inj		Ball bearing type outer joint	07	1984	10	1992	DBSRPS200
RENAULT	25	2.0	P Inj		Ball bearing type outer joint	07	1984	12	1990	DBSRPS200
RENAULT	25	2.0	P Inj		Claw type outer joint	07	1984	12	1986	DBSR200
RENAULT	25	2.0	P Inj		Claw type outer joint	07	1984	10	1992	DBSRPS200

Sheet1

RENAULT	25		2.0	P Inj		Claw type outer joint	07	1984	12	1990	DBSRPS200
RENAULT	25		2.2	P		Ball bearing type outer joint	07	1984	01	1990	DBSRPS200
RENAULT	25		2.2	P		Claw type outer joint	07	1984	01	1990	DBSRPS200
RENAULT	25		2.5	P Turbo			07	1985	05	1990	DBSRPS200
RENAULT	25		2.7	P			07	1984	07	1989	DBSRPS200
RENAULT	25		2.7	P		Ball bearing type outer joint	07	1984	07	1989	DBSRPS200
RENAULT	25		2.7	P		Claw type outer joint	07	1984	07	1989	DBSRPS200
RENAULT	25		2.8	P Inj	Auto		07	1989	03	1992	DBSRPS200
RENAULT	30		2.7	P	V6		01	1981	12	1980	DBSRPS200
RENAULT	30		2.7	P	V6		01	1981	12	1980	DBSR200
RENAULT	Clio	Mk1	1.1	P Inj		LHS, Inner boot without bearing	04	1992	08	1992	DBSR100
RENAULT	Clio	Mk1	1.1	P Inj		LHS, Inner boot with 23.8mm bearing	04	1992	08	1992	DBSR100
RENAULT	Clio	Mk1	1.1	P Inj		LHS, Inner boot with 25.8mm bearing	04	1992	08	1992	DBSR100
RENAULT	Clio	Mk1	1.1	P Inj		Outer boot for 76mm joint	04	1992	08	1992	DBSR100
RENAULT	Clio	Mk1	1.1	P Inj		Outer boot for 86mm joint	04	1992	08	1992	DBSR100
RENAULT	Clio	Mk1	1.1	P Inj		RHS, Inner	04	1992	08	1992	DBSR100
RENAULT	Clio	Mk1	1.1	P Inj		LHS, Inner boot without bearing	04	1992	08	1992	DBSR100
RENAULT	Clio	Mk1	1.1	P Inj		LHS, Inner boot with 23.8mm bearing	04	1992	08	1992	DBSR100
RENAULT	Clio	Mk1	1.1	P Inj		LHS, Inner boot with 25.8mm bearing	04	1992	08	1992	DBSR100
RENAULT	Clio	Mk1	1.1	P Inj		RHS	04	1992	08	1992	DBSR100
RENAULT	Clio	Mk1	1.2	P Inj		LHS, Inner boot without bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.2	P Inj		LHS, Inner boot without bearing	01	1994	12	1995	DBSRPS200
RENAULT	Clio	Mk1	1.2	P Inj		LHS, Inner boot without bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.2	P Inj		LHS, Inner boot without bearing	01	1994	12	1995	DBSRPS200
RENAULT	Clio	Mk1	1.2	P Inj		LHS, Inner boot with 23.8mm bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.2	P Inj		LHS, Inner boot with 23.8mm bearing	01	1994	12	1995	DBSRPS200
RENAULT	Clio	Mk1	1.2	P Inj		LHS, Inner boot with 23.8mm bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.2	P Inj		LHS, Inner boot with 23.8mm bearing	01	1994	12	1995	DBSRPS200
RENAULT	Clio	Mk1	1.2	P Inj		LHS, Inner boot with 25.8mm bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.2	P Inj		LHS, Inner boot with 25.8mm bearing	01	1994	12	1995	DBSRPS200
RENAULT	Clio	Mk1	1.2	P Inj		LHS, Inner boot with 25.8mm bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.2	P Inj		LHS, Inner boot with 25.8mm bearing	01	1994	12	1995	DBSRPS200
RENAULT	Clio	Mk1	1.2	P Inj		Outer boot for 76mm joint	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.2	P Inj		Outer boot for 76mm joint	01	1994	12	1995	DBSRPS200
RENAULT	Clio	Mk1	1.2	P Inj		Outer boot for 86mm joint	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.2	P Inj		Outer boot for 86mm joint	01	1994	12	1995	DBSRPS200

Sheet1

RENAULT	Clio	Mk1	1.2	P Inj		RHS	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.2	P Inj		RHS	01	1994	12	1995	DBSRPS200
RENAULT	Clio	Mk1	1.2	P Inj		RHS	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.2	P Inj		RHS	01	1994	12	1995	DBSRPS200
RENAULT	Clio	Mk1	1.4	P Inj	Auto		03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.4	P Inj	Auto		03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.4	P Inj	Auto	LHS, Inner boot without bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.4	P Inj	Auto	LHS, Inner boot without bearing	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.4	P Inj	Auto	LHS, Inner boot without bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.4	P Inj	Auto	LHS, Inner boot without bearing	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.4	P Inj	Auto	LHS, Inner boot with bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.4	P Inj	Auto	LHS, Inner boot with bearing	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.4	P Inj	Auto	LHS, Inner boot with bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.4	P Inj	Auto	LHS, Inner boot with bearing	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.4	P Inj	Auto	RHS	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.4	P Inj	Auto	RHS	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.4	P Inj	Auto	RHS	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.4	P Inj	Auto	RHS	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.4	P Inj	Manual	LHS, Inner boot without bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.4	P Inj	Manual	LHS, Inner boot without bearing	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.4	P Inj	Manual	LHS, Inner boot without bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.4	P Inj	Manual	LHS, Inner boot without bearing	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.4	P Inj	Manual	LHS, Inner boot with bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.4	P Inj	Manual	LHS, Inner boot with bearing	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.4	P Inj	Manual	LHS, Inner boot with bearing	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.4	P Inj	Manual	LHS, Inner boot with bearing	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.4	P Inj	Manual	RHS	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.4	P Inj	Manual	RHS	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.4	P Inj	Manual	RHS	03	1991	04	1998	DBSR100
RENAULT	Clio	Mk1	1.4	P Inj	Manual	RHS	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.8	P Inj		LHS, Inner boot without bearing	03	1991	10	1997	DBSR100
RENAULT	Clio	Mk1	1.8	P Inj		LHS, Inner boot without bearing	03	1991	10	1997	DBSRPS200
RENAULT	Clio	Mk1	1.8	P Inj		LHS, Inner boot without bearing	03	1991	09	1991	DBSRPS200
RENAULT	Clio	Mk1	1.8	P Inj		LHS, Inner boot with bearing	03	1991	10	1997	DBSR100
RENAULT	Clio	Mk1	1.8	P Inj		LHS, Inner boot with bearing	03	1991	09	1991	DBSRPS200
RENAULT	Clio	Mk1	1.8	P Inj		LHS, Inner boot with bearing	03	1991	10	1997	DBSRPS200

Sheet1

RENAULT	Clio	Mk1	1.8	P Inj		RHS	03	1991	10	1997	DBSR100
RENAULT	Clio	Mk1	1.8	P Inj		RHS	03	1991	10	1997	DBSRPS200
RENAULT	Clio	Mk1	1.8	P Inj		RHS	03	1991	09	1991	DBSRPS200
RENAULT	Clio	Mk1	1.8	P Inj		LHS, Inner boot without bearing	03	1991	10	1997	DBSR100
RENAULT	Clio	Mk1	1.8	P Inj		LHS, Inner boot without bearing	03	1991	09	1991	DBSRPS200
RENAULT	Clio	Mk1	1.8	P Inj		LHS, Inner boot without bearing	03	1991	10	1997	DBSRPS200
RENAULT	Clio	Mk1	1.8	P Inj		LHS, Inner boot with bearing	03	1991	10	1997	DBSR100
RENAULT	Clio	Mk1	1.8	P Inj		LHS, Inner boot with bearing	03	1991	09	1991	DBSRPS200
RENAULT	Clio	Mk1	1.8	P Inj		LHS, Inner boot with bearing	03	1991	10	1997	DBSRPS200
RENAULT	Clio	Mk1	1.8	P Inj		RHS	03	1991	10	1997	DBSR100
RENAULT	Clio	Mk1	1.8	P Inj		RHS	03	1991	09	1991	DBSRPS200
RENAULT	Clio	Mk1	1.8	P Inj		RHS	03	1991	10	1997	DBSRPS200
RENAULT	Clio	Mk1	1.9	D		LHS, Inner boot without bearing	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.9	D		LHS, Inner boot without bearing	01	1994	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.9	D		LHS, Inner boot without bearing	01	1994	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.9	D		LHS, Inner boot without bearing	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.9	D		LHS, Inner boot with bearing	01	1994	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.9	D		LHS, Inner boot with bearing	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.9	D		LHS, Inner boot with bearing	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.9	D		RHS	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.9	D		RHS	01	1994	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.9	D		RHS	03	1991	04	1998	DBSRPS200
RENAULT	Clio	Mk1	1.9	D		RHS	01	1994	04	1998	DBSRPS200
RENAULT	Clio	Mk1	2.0	P		LHS, Inner boot without bearing	01	1994	12	1995	DBSRPS200
RENAULT	Clio	Mk1	2.0	P		LHS, Inner boot with bearing	01	1994	12	1995	DBSRPS200
RENAULT	Clio	Mk1	2.0	P		RHS	01	1994	12	1995	DBSRPS200
RENAULT	Clio	Mk2	1.2	P Inj	Auto	Trilobal inner joint	04	2000			DBSR100
RENAULT	Clio	Mk2	1.2	P Inj	Manual	LHS	05	1998			DBSR100
RENAULT	Clio	Mk2	1.2	P Inj	Manual	RHS, Inner boot for round joint	05	1998			DBSR100
RENAULT	Clio	Mk2	1.2	P Inj	Manual	RHS, Trilobal inner joint	05	1998			DBSR100
RENAULT	Clio	Mk2	1.4	P Inj	Auto	Trilobal inner joint	04	2000			DBSR100
RENAULT	Clio	Mk2	1.4	P Inj	Auto	Trilobal inner joint	04	2000			DBSRPS200
RENAULT	Clio	Mk2	1.4	P Inj	Manual	LHS	05	1998			DBSR100
RENAULT	Clio	Mk2	1.4	P Inj	Manual	LHS	05	1998			DBSRPS200
RENAULT	Clio	Mk2	1.4	P Inj	Manual	RHS, Inner boot for round joint	05	1998			DBSR100

Sheet1

RENAULT	Clio	Mk2	1.4	P Inj	Manual	RHS, Inner boot for round joint	05	1998				DBSRPS200
RENAULT	Clio	Mk2	1.4	P Inj	Manual	RHS, Trilobal inner joint	05	1998				DBSR100
RENAULT	Clio	Mk2	1.4	P Inj	Manual	RHS, Trilobal inner joint	05	1998				DBSRPS200
RENAULT	Clio	Mk2	1.5	D Turbo		LHS	04	2001				DBSRPS200
RENAULT	Clio	Mk2	1.5	D Turbo		RHS, Inner boot for round joint	04	2001				DBSRPS200
RENAULT	Clio	Mk2	1.5	D Turbo		RHS, Trilobal inner joint	04	2001				DBSRPS200
RENAULT	Clio	Mk2	1.9	D		LHS	05	1998	04	2001		DBSRPS200
RENAULT	Clio	Mk2	1.9	D		RHS	05	1998	04	2001		DBSRPS200
RENAULT	Clio	Mk2	1.9	D Turbo		LHS	05	1998	04	2001		DBSRPS200
RENAULT	Clio	Mk2	1.9	D Turbo		RHS	05	1998	04	2001		DBSRPS200
RENAULT	Clio	Mk2	2.0	P Inj		LHS	01	2000	12	1993		DBSRPS200
RENAULT	Clio	Mk2	2.0	P Inj		RHS, Trilobal inner joint	01	2000	12	1993		DBSRPS200
RENAULT	Espace	Mk1	2.0	P			01	1988	06	1991		DBSRPS200
RENAULT	Espace	Mk1	2.0	P			07	1985	06	1991		DBSRPS200
RENAULT	Espace	Mk3	2.0	P Inj			06	1998	12	2002		DBSR200
RENAULT	Espace	Mk3	2.2	D Turbo			04	1997	12	2002		DBSR200
RENAULT	Espace	Mk3	3.0	P Inj	Auto		04	1997	12	2002		DBSR200
RENAULT	Fuego		1.4	P			09	1980	04	1984		DBSR200
RENAULT	Fuego		1.4	P			09	1980	04	1984		DBSRPS200
RENAULT	Fuego		1.6	P			09	1980	12	1984		DBSR200
RENAULT	Fuego		1.6	P			09	1980	12	1984		DBSRPS200
RENAULT	Grand Espace		2.0	P Inj			01	1998				DBSR200
RENAULT	Grand Espace		2.2	D Turbo			01	1998				DBSR200
RENAULT	Grand Espace		2.9	P Inj			01	1998				DBSR200
RENAULT	Laguna	Mk1	1.8	P Inj		LHS	04	1994	04	1998		DBSR100
RENAULT	Laguna	Mk1	1.8	P Inj		RHS	04	1994	04	1998		DBSR100
RENAULT	Laguna	Mk1	2.0	P Inj	Auto		04	1994	04	1998		DBSR100
RENAULT	Laguna	Mk1	2.0	P Inj	Manual	LHS	04	1994	04	1998		DBSR100
RENAULT	Laguna	Mk1	2.0	P Inj	Manual	RHS	04	1994	04	1998		DBSR100
RENAULT	Laguna	Mk1	2.2	D		LHS	04	1994	04	1998		DBSR100
RENAULT	Laguna	Mk1	2.2	D		RHS	04	1994	04	1998		DBSR100
RENAULT	Laguna	Mk1	2.2	D Turbo		LHS	04	1994	04	1998		DBSR100
RENAULT	Laguna	Mk1	2.2	D Turbo		RHS	04	1994	04	1998		DBSR100
RENAULT	Laguna	Mk1	3.0	P Inj	Auto	LHS	04	1994	04	1998		DBSR100
RENAULT	Laguna	Mk1	3.0	P Inj	Auto	RHS	04	1994	04	1998		DBSR100
RENAULT	Laguna	Mk2	1.6	P Inj		LHS	05	1998	01	2001		DBSR100

Sheet1

RENAULT	Laguna	Mk2	1.6	P Inj		RHS, Trilobal inner joint	05	1998	01	2001	DBSR100
RENAULT	Laguna	Mk2	1.8	P Inj		LHS	05	1998	01	2001	DBSR100
RENAULT	Laguna	Mk2	1.8	P Inj		RHS, Trilobal inner joint	05	1998	01	2001	DBSR100
RENAULT	Laguna	Mk2	1.9	D Turbo		LHS	05	1998	01	2001	DBSR100
RENAULT	Laguna	Mk2	1.9	D Turbo		RHS, Trilobal inner joint	05	1998	01	2001	DBSR100
RENAULT	Laguna	Mk2	2.0	P Inj	Auto		05	1998	01	2001	DBSR100
RENAULT	Laguna	Mk2	2.0	P Inj	Manual	LHS	05	1998	01	2001	DBSR100
RENAULT	Laguna	Mk2	2.0	P Inj	Manual	RHS, Trilobal inner joint	05	1998	01	2001	DBSR100
RENAULT	Laguna	Mk2	2.2	D Turbo			05	1998	01	2000	DBSR100
RENAULT	Laguna	Mk2	3.0	P Inj	Auto		05	1998	01	2001	DBSR100
RENAULT	Laguna	Mk2	3.0	P Inj	Manual		05	1998	01	2001	DBSR100
RENAULT	Megane	Mk1	1.4	P Inj		LHS, Inner boot without bearing	04	1996	04	1999	DBSR200
RENAULT	Megane	Mk1	1.4	P Inj		LHS, Inner boot with 23.8mm bearing	04	1996	04	1999	DBSR200
RENAULT	Megane	Mk1	1.4	P Inj		LHS, Inner boot with 25.8mm bearing	04	1996	04	1999	DBSR200
RENAULT	Megane	Mk1	1.4	P Inj		RHS, Inner boot for round joint secured by metal	04	1996	04	1999	DBSR200
RENAULT	Megane	Mk1	1.4	P Inj		RHS, Inner boot for round joint secured by spring	04	1996	04	1999	DBSR200
RENAULT	Megane	Mk1	1.4	P Inj		RHS, Trilobal inner joint	04	1996	04	1999	DBSR200
RENAULT	Megane	Mk1	1.6	P Inj	Auto		04	1996	06	1999	DBSR200
RENAULT	Megane	Mk1	1.6	P Inj	Manual	LHS, Inner boot without bearing	04	1996	06	1999	DBSR200
RENAULT	Megane	Mk1	1.6	P Inj	Manual	LHS, Inner boot with bearing	04	1996	06	1999	DBSR200
RENAULT	Megane	Mk1	1.6	P Inj	Manual	RHS, Inner boot for round joint secured by metal	04	1996	06	1999	DBSR200
RENAULT	Megane	Mk1	1.6	P Inj	Manual	RHS, Inner boot for round joint secured by spring	04	1996	06	1999	DBSR200
RENAULT	Megane	Mk1	1.6	P Inj	Manual	RHS, Trilobal inner joint	04	1996	06	1999	DBSR200
RENAULT	Megane	Mk1	1.9	D Turbo		LHS	04	1996	01	1998	DBSR200
RENAULT	Megane	Mk1	1.9	D Turbo		RHS, Inner boot for round joint	04	1996	01	1998	DBSR200
RENAULT	Megane	Mk1	1.9	D Turbo		RHS, Trilobal inner joint	04	1996	01	1998	DBSR200
RENAULT	Megane	Mk1	1.9	D		LHS	04	1996	04	1999	DBSR200
RENAULT	Megane	Mk1	1.9	D		RHS, Inner boot for round joint secured by metal	04	1996	04	1999	DBSR200
RENAULT	Megane	Mk1	1.9	D		RHS, Inner boot for round joint secured by spring	04	1996	04	1999	DBSR200
RENAULT	Megane	Mk1	1.9	D		RHS, Trilobal inner joint	04	1996	04	1999	DBSR200
RENAULT	Megane	Mk1	2.0	P Inj		LHS	04	1996	06	1999	DBSR200
RENAULT	Megane	Mk1	2.0	P Inj		RHS, Inner boot for round joint	04	1996	06	1999	DBSR200
RENAULT	Megane	Mk1	2.0	P Inj		RHS, Trilobal inner joint	04	1996	06	1999	DBSR200
RENAULT	Safrane	Mk1	2.0	P Inj		LHS, Inner boot with bearing	11	1992	11	1995	DBSRPS200
RENAULT	Safrane	Mk1	2.0	P Inj		LHS, Inner boot without bearing	11	1992	11	1995	DBSRPS200
RENAULT	Safrane	Mk1	2.0	P Inj		RHS	11	1992	11	1995	DBSRPS200

Sheet1

RENAULT	Safrane	Mk1	2.2	P Inj		LHS, Inner boot with bearing	11	1992	11	1995	DBSRPS200
RENAULT	Safrane	Mk1	2.2	P Inj		LHS, Inner boot without bearing	11	1992	11	1995	DBSRPS200
RENAULT	Safrane	Mk1	2.2	P Inj		RHS	11	1992	11	1995	DBSRPS200
RENAULT	Safrane	Mk1	2.5	D Turbo	Auto	LHS, Inner boot with bearing	11	1995	11	1996	DBSRPS200
RENAULT	Safrane	Mk1	2.5	D Turbo	Auto	LHS, Inner boot without bearing	11	1995	11	1996	DBSRPS200
RENAULT	Safrane	Mk1	2.5	D Turbo	Auto	RHS	11	1995	11	1996	DBSRPS200
RENAULT	Safrane	Mk1	3.0	P Inj		LHS, Inner boot with bearing	11	1995	11	1996	DBSRPS200
RENAULT	Safrane	Mk1	3.0	P Inj		LHS, Inner boot with bearing	11	1992	11	1995	DBSRPS200
RENAULT	Safrane	Mk1	3.0	P Inj		LHS, Inner boot without bearing	11	1992	11	1995	DBSRPS200
RENAULT	Safrane	Mk1	3.0	P Inj		LHS, Inner boot without bearing	11	1995	11	1996	DBSRPS200
RENAULT	Safrane	Mk1	3.0	P Inj		RHS	11	1992	11	1995	DBSRPS200
RENAULT	Safrane	Mk1	3.0	P Inj		RHS	11	1995	11	1996	DBSRPS200
RENAULT	Safrane	Mk2	2.0	P Inj	Auto		11	1996	01	2001	DBSRPS200
RENAULT	Safrane	Mk2	2.0	P Inj	Manual		11	1996	01	2001	DBSRPS200
RENAULT	Safrane	Mk2	2.5	P Inj	Auto		11	1996	02	2001	DBSRPS200
RENAULT	Scenic	Mk1	1.6	P Inj	Auto		05	1997	06	1999	DBSR200
RENAULT	Scenic	Mk1	1.6	P Inj	Manual	LHS, Inner boot with bearing	05	1997	06	1999	DBSR200
RENAULT	Scenic	Mk1	1.6	P Inj	Manual	LHS, Inner boot without bearing	05	1997	06	1999	DBSR200
RENAULT	Scenic	Mk1	1.6	P Inj	Manual	RHS, Inner boot for round joint	05	1997	06	1999	DBSR200
RENAULT	Scenic	Mk1	1.6	P Inj	Manual	RHS, Trilobal inner joint	05	1997	06	1999	DBSR200
RENAULT	Scenic	Mk1	1.9	D Turbo		LHS	05	1997	01	1998	DBSR200
RENAULT	Scenic	Mk1	1.9	D Turbo		RHS	05	1997	01	1998	DBSR200
RENAULT	Scenic	Mk1	1.9	D Turbo	Di		02	1998	06	1999	DBSR200
RENAULT	Scenic	Mk1	2.0	P Inj	Auto		05	1997	06	1999	DBSR200
RENAULT	Scenic	Mk1	2.0	P Inj	Manual	LHS	05	1997	06	1999	DBSR200
RENAULT	Scenic	Mk1	2.0	P Inj	Manual	RHS	05	1997	06	1999	DBSR200
RENAULT LCV	Clio Van	Mk1	1.2	P Inj		LHS, Inner boot without bearing	01	1994	04	1995	DBSR100
RENAULT LCV	Clio Van	Mk1	1.2	P Inj		LHS, Inner boot without bearing	01	1994	04	1995	DBSR100
RENAULT LCV	Clio Van	Mk1	1.2	P Inj		LHS, Inner boot with 23.8mm bearing	01	1994	04	1995	DBSR100
RENAULT LCV	Clio Van	Mk1	1.2	P Inj		LHS, Inner boot with 23.8mm bearing	01	1994	04	1995	DBSR100
RENAULT LCV	Clio Van	Mk1	1.2	P Inj		LHS, Inner boot with 25.8mm bearing	01	1994	04	1995	DBSR100
RENAULT LCV	Clio Van	Mk1	1.2	P Inj		LHS, Inner boot with 25.8mm bearing	01	1994	04	1995	DBSR100
RENAULT LCV	Clio Van	Mk1	1.2	P Inj		Outer boot for 76mm joint	01	1994	04	1995	DBSR100
RENAULT LCV	Clio Van	Mk1	1.2	P Inj		Outer boot for 86mm joint	01	1994	04	1995	DBSR100
RENAULT LCV	Clio Van	Mk1	1.2	P Inj		RHS	01	1994	04	1995	DBSR100
RENAULT LCV	Clio Van	Mk1	1.2	P Inj		RHS	01	1994	04	1995	DBSR100

Sheet1

RENAULT LCV	Clio Van	Mk1	1.9	D		LHS, Inner boot without bearing	01	1994	12	1998	DBSR100
RENAULT LCV	Clio Van	Mk1	1.9	D		LHS, Inner boot without bearing	01	1994	12	1998	DBSR100
RENAULT LCV	Clio Van	Mk1	1.9	D		LHS, Inner boot with bearing	01	1994	12	1998	DBSR100
RENAULT LCV	Clio Van	Mk1	1.9	D		LHS, Inner boot with bearing	01	1994	12	1998	DBSR100
RENAULT LCV	Clio Van	Mk1	1.9	D		RHS	01	1994	12	1998	DBSR100
RENAULT LCV	Clio Van	Mk1	1.9	D		RHS	01	1994	12	1998	DBSR100
RENAULT LCV	Trafic	Mk1	1.4	P Inj	Fwd	Outer boot with 1 locating lip	02	1981	03	1998	DBSR200
RENAULT LCV	Trafic	Mk1	1.4	P Inj	Fwd	Outer boot without locating lip	02	1981	03	1998	DBSR200
RENAULT LCV	Trafic	Mk1	1.7	P Inj	Fwd	Outer boot with 1 locating lip	02	1981	03	1998	DBSR200
RENAULT LCV	Trafic	Mk1	1.7	P Inj	Fwd	Outer boot without locating lip	02	1981	03	1998	DBSR200
RENAULT LCV	Trafic	Mk1	1.9	D	Fwd	Outer boot with 1 locating lip	09	1994	03	1998	DBSRPS200
RENAULT LCV	Trafic	Mk1	1.9	D	Fwd	Outer boot with 1 locating lip	02	1981	03	1998	DBSR200
RENAULT LCV	Trafic	Mk1	1.9	D	Fwd	Outer boot without locating lip	09	1994	03	1998	DBSRPS200
RENAULT LCV	Trafic	Mk1	1.9	D	Fwd	Outer boot without locating lip	02	1981	03	1998	DBSR200
RENAULT LCV	Trafic	Mk1	2.0	P Inj	Fwd	Outer boot with 1 locating lip	02	1981	03	1998	DBSR200
RENAULT LCV	Trafic	Mk1	2.0	P Inj	Fwd	Outer boot without locating lip	02	1981	03	1998	DBSR200
RENAULT LCV	Trafic	Mk1	2.1	D	Fwd	Outer boot with 1 locating lip	09	1994	03	1998	DBSRPS200
RENAULT LCV	Trafic	Mk1	2.1	D	Fwd	Outer boot with 1 locating lip	02	1981	03	1998	DBSR200
RENAULT LCV	Trafic	Mk1	2.1	D	Fwd	Outer boot without locating lip	09	1994	03	1998	DBSRPS200
RENAULT LCV	Trafic	Mk1	2.1	D	Fwd	Outer boot without locating lip	02	1981	03	1998	DBSR200
RENAULT LCV	Trafic	Mk1	2.2	P Inj	Fwd	Outer boot with 1 locating lip	09	1994	03	1998	DBSRPS200
RENAULT LCV	Trafic	Mk1	2.2	P Inj	Fwd	Outer boot with 1 locating lip	02	1981	03	1998	DBSR200
RENAULT LCV	Trafic	Mk1	2.2	P Inj	Fwd	Outer boot without locating lip	09	1994	03	1998	DBSRPS200
RENAULT LCV	Trafic	Mk1	2.2	P Inj	Fwd	Outer boot without locating lip	02	1981	03	1998	DBSR200
RENAULT LCV	Trafic	Mk1	2.5	D	Fwd	Outer boot with 1 locating lip	09	1994	03	1998	DBSRPS200
RENAULT LCV	Trafic	Mk1	2.5	D	Fwd	Outer boot with 1 locating lip	02	1981	03	1998	DBSR200
RENAULT LCV	Trafic	Mk1	2.5	D	Fwd	Outer boot without locating lip	09	1994	03	1998	DBSRPS200
RENAULT LCV	Trafic	Mk1	2.5	D	Fwd	Outer boot without locating lip	02	1981	03	1998	DBSR200
ROVER GROUP	25		1.1	P Inj			11	1999			DBSR300
ROVER GROUP	25		1.4	P Inj			11	1999			DBSR300
ROVER GROUP	25		1.6	P Inj	Auto		05	2001			DBSR300
ROVER GROUP	25		1.6	P Inj	Manual		11	1999			DBSR300
ROVER GROUP	25		1.8	P Inj	Auto		11	1999	05	2001	DBSR300
ROVER GROUP	25		1.8	P Inj	Manual		11	1999	05	2001	DBSR300
ROVER GROUP	25		2.0	D Turbo			11	1999			DBSR300
ROVER GROUP	45		1.4	P Inj			01	2000			DBSR100

Sheet1

ROVER GROUP 45		1.6	P Inj			01	2000		DBSR100
ROVER GROUP 45		1.8	P Inj	Auto		01	2000		DBSR100
ROVER GROUP 45		1.8	P Inj	Manual		01	2000		DBSR100
ROVER GROUP 45		2.0	D Turbo			01	2000		DBSR100
ROVER GROUP 45		2.0	P Inj	Auto		01	2000		DBSR100
ROVER GROUP 75		1.8	P Inj	Auto		03	1999		DBSR300
ROVER GROUP 75		1.8	P Inj	Manual	Trilobal inner joint	03	1999		DBSR300
ROVER GROUP 75		2.0	D turbo	Auto		03	1999		DBSR300
ROVER GROUP 75		2.0	D turbo	Manual	Trilobal inner joint	03	1999		DBSR300
ROVER GROUP 75		2.0	P Inj	Auto		03	1999		DBSR300
ROVER GROUP 75		2.0	P Inj	Manual	Trilobal inner joint	03	1999		DBSR300
ROVER GROUP 75		2.5	P Inj	Auto		03	1999	12	1995 DBSR300
ROVER GROUP 75		2.5	P Inj	Manual	Trilobal inner joint	03	1999	12	1995 DBSR300
ROVER GROUP 100		1.1	P Inj	111		01	1995	12	1997 DBSR100
ROVER GROUP 100		1.4	P Inj	114		01	1995	12	1997 DBSR100
ROVER GROUP 100		1.5	D	115		01	1995	12	1997 DBSR100
ROVER GROUP 200	Mk1	1.3	P	213		10	1989	09	1990 DBSR100
ROVER GROUP 200	Mk1	1.3	P	213		01	1989	09	1990 DBSR300
ROVER GROUP 200	Mk1	1.3	P	213		06	1984	12	1989 DBSR200
ROVER GROUP 200	Mk1	1.6	P	216 Auto		10	1989	10	1989 DBSR100
ROVER GROUP 200	Mk1	1.6	P	216 Auto		01	1989	10	1989 DBSR300
ROVER GROUP 200	Mk1	1.6	P	216 Manual		10	1989	09	1990 DBSR100
ROVER GROUP 200	Mk1	1.6	P	216 Manual		01	1989	09	1990 DBSR300
ROVER GROUP 200	Mk2	1.4	P Inj	214		10	1989	03	1996 DBSR100
ROVER GROUP 200	Mk2	1.4	P Inj	214		03	1990	12	1995 DBSR100
ROVER GROUP 200	Mk2	1.4	P Inj	214		10	1989	12	1995 DBSR300
ROVER GROUP 200	Mk2	1.6	P Inj	216		11	1989	04	1999 DBSR100
ROVER GROUP 200	Mk2	1.6	P Inj	216		03	1990	12	1995 DBSR100
ROVER GROUP 200	Mk2	1.6	P Inj	216		11	1989	12	1995 DBSR300
ROVER GROUP 200	Mk2	1.8	D Turbo	218		03	1991	09	1996 DBSR100
ROVER GROUP 200	Mk2	1.8	D Turbo	218		03	1991	12	1995 DBSR100
ROVER GROUP 200	Mk2	1.8	D Turbo	218		03	1991	12	1995 DBSR300
ROVER GROUP 200	Mk2	1.9	D	218		03	1991	03	1996 DBSR100
ROVER GROUP 200	Mk2	1.9	D	218		03	1991	12	1995 DBSR100
ROVER GROUP 200	Mk2	1.9	D	218		03	1991	12	1995 DBSR300
ROVER GROUP 200	Mk2	2.0	P Inj	220		06	1991	03	1996 DBSR100

Sheet1

ROVER GROUP 200	Mk2	2.0	P Inj	220	06	1991	12	1995	DBSR100
ROVER GROUP 200	Mk2	2.0	P Inj	220	06	1991	12	1995	DBSR300
ROVER GROUP 200	Mk3	1.1	P Inj	211	01	1998	04	1999	DBSR100
ROVER GROUP 200	Mk3	1.4	P Inj	214	11	1995	04	1999	DBSR100
ROVER GROUP 200	Mk3	1.6	P Inj	216 Auto	11	1995	04	1999	DBSR100
ROVER GROUP 200	Mk3	1.6	P Inj	216 Manual	11	1995	04	1999	DBSR100
ROVER GROUP 200	Mk3	1.8	P Inj	218	10	1996	04	1999	DBSR100
ROVER GROUP 200	Mk3	2.0	D Turbo	220	11	1995	04	1999	DBSR100
ROVER GROUP 400	Mk1	1.4	P Inj	414	03	1990	10	1995	DBSR100
ROVER GROUP 400	Mk1	1.4	P Inj	414	03	1990	10	1995	DBSR100
ROVER GROUP 400	Mk1	1.6	P Inj	416	03	1990	12	1995	DBSR100
ROVER GROUP 400	Mk1	1.6	P Inj	416	03	1990	12	1995	DBSR100
ROVER GROUP 400	Mk1	1.6	P Inj	416	11	1989	04	1999	DBSR100
ROVER GROUP 400	Mk1	1.8	D Turbo	418	03	1991	12	1995	DBSR100
ROVER GROUP 400	Mk1	1.8	D Turbo	418	03	1991	12	1996	DBSR100
ROVER GROUP 400	Mk1	1.8	D Turbo	418	03	1991	12	1995	DBSR100
ROVER GROUP 400	Mk1	1.9	D	418	10	1992	10	1995	DBSR100
ROVER GROUP 400	Mk1	1.9	D	418	10	1992	10	1995	DBSR100
ROVER GROUP 400	Mk1	2.0	P Inj	420	11	1991	12	1995	DBSR100
ROVER GROUP 400	Mk1	2.0	P Inj	420	11	1991	12	1995	DBSR100
ROVER GROUP 400	Mk1	2.0	P Inj	420	11	1991	03	1996	DBSR100
ROVER GROUP 400	Mk2	1.4	P Inj	414	05	1995	04	1999	DBSR100
ROVER GROUP 400	Mk2	1.6	P Inj	416 Auto	05	1995	04	1999	DBSR100
ROVER GROUP 400	Mk2	1.6	P Inj	416 Manual	05	1995	04	1999	DBSR100
ROVER GROUP 400	Mk2	2.0	D Turbo	420	11	1995	04	1999	DBSR100
ROVER GROUP 400	Mk2	2.0	P Inj	420	10	1996	04	1999	DBSR100
ROVER GROUP 600		1.8	P Inj	618	02	1996	10	1999	DBSR200
ROVER GROUP 600		2.0	P	620	05	1994	08	1998	DBSR200
ROVER GROUP 600		2.0	P	620	04	1993	04	1994	DBSR200
ROVER GROUP 600		2.0	P Turbo	620Ti	07	1994	08	1998	DBSR200
ROVER GROUP 600		2.0	D Turbo	620	12	1994	08	1998	DBSR200
ROVER GROUP 600		2.3	P	623	05	1994	08	1998	DBSR200
ROVER GROUP 600		2.3	P	623	10	1993	04	1994	DBSR200
ROVER GROUP 800	Mk1	2.0	P	820	07	1986	08	1991	DBSR300
ROVER GROUP 800	Mk1	2.5	P	825	07	1986	08	1991	DBSR300
ROVER GROUP 800	Mk1	2.7	P	827	07	1986	08	1991	DBSR300

Sheet1

ROVER GROUP 800	Mk2	2.0	P Inj	820		01	1992	04	1999	DBSR300
ROVER GROUP 800	Mk2	2.5	P Inj	825		01	1992	04	1999	DBSR300
ROVER GROUP 800	Mk2	2.7	P Inj	827		01	1992	04	1999	DBSR300
ROVER GROUP Allegro		1.1	P			01	1977	12	1983	DBSR200
ROVER GROUP Allegro		1.3	P			01	1977	12	1983	DBSR200
ROVER GROUP Allegro		1.5	P			05	1973	12	1983	DBSR200
ROVER GROUP Allegro		1.75	P			05	1973	12	1983	DBSR200
ROVER GROUP Maestro		1.3	P Inj		Trilobal inner joint	03	1983	12	1994	DBSR200
ROVER GROUP Maestro		1.6	P Inj			11	1988	04	1992	DBSR200
ROVER GROUP Maestro		1.6	P Inj		Trilobal inner joint	03	1983	10	1988	DBSR200
ROVER GROUP Maestro		2.0	D			03	1990	09	1992	DBSR300
ROVER GROUP Maestro		2.0	D			10	1984	09	1992	DBSR200
ROVER GROUP Maestro		2.0	D Turbo			03	1990	12	1994	DBSR300
ROVER GROUP Maestro		2.0	D Turbo			01	1989	12	1994	DBSR200
ROVER GROUP Metro	Mk1	1.3	P			05	1982	09	1990	DBSR200
ROVER GROUP Metro	Mk2	1.4	D			05	1990	01	1995	DBSR200
ROVER GROUP Metro	Mk2	1.4	P Inj			05	1990	01	1995	DBSR200
ROVER GROUP MGF		1.8	P Inj			09	1995	05	1999	DBSR200
ROVER GROUP MGF		1.8	P Inj	VVC		09	1995	05	1999	DBSR200
ROVER GROUP Mini		0.85	P			01	1959	12	1971	DBSR100
ROVER GROUP Mini		0.85	P			01	1972	08	1980	DBSR100
ROVER GROUP Mini		1.0	P			01	1964	12	1965	DBSR100
ROVER GROUP Mini		1.0	P			01	1967	12	1971	DBSR100
ROVER GROUP Mini		1.0	P			01	1964	12	1969	DBSR100
ROVER GROUP Mini		1.0	P			01	1967	05	1984	DBSR100
ROVER GROUP Mini		1.0	P			01	1964	12	1969	DBSR100
ROVER GROUP Mini		1.0	P			01	1964	12	1965	DBSR100
ROVER GROUP Mini		1.0	P			01	1964	12	1965	DBSR100
ROVER GROUP Mini		1.0	P			01	1967	06	1992	DBSR100
ROVER GROUP Mini		1.0	P			01	1964	12	1969	DBSR100
ROVER GROUP Mini		1.1	P			01	1978	12	1971	DBSR100
ROVER GROUP Mini		1.1	P			01	1964	12	1965	DBSR100
ROVER GROUP Mini		1.1	P			01	1978	08	1980	DBSR100
ROVER GROUP Mini		1.1	P			01	1964	12	1965	DBSR100
ROVER GROUP Mini		1.3	P	Cooper S		01	1965	12	1971	DBSR100
ROVER GROUP Mini		1.3	P	1275GT		10	1969	12	1971	DBSR100

Sheet1

ROVER GROUP Mini	1.3	P	1275GT		01	1972	08	1980	DBSR100
ROVER GROUP Mini	1.3	P Inj	Cooper		09	1990	10	2000	DBSR100
ROVER GROUP Mini	1.3	P Inj	Cooper Cooper, Mayfair, Sprite		09	1990	10	2000	DBSR100
ROVER GROUP Mini	1.3	P Inj	Mayfair		09	1990	10	2000	DBSR100
ROVER GROUP Mini	1.3	P Inj	Mayfair Cooper, Mayfair, Sprite		09	1990	10	2000	DBSR100
ROVER GROUP Mini	1.3	P Inj	Sprite		09	1990	10	2000	DBSR100
ROVER GROUP Mini	1.3	P Inj	Sprite Cooper, Mayfair, Sprite		09	1990	10	2000	DBSR100
ROVER GROUP Montego	1.3	P		Trilobal inner joint	04	1984	10	1988	DBSR200
ROVER GROUP Montego	1.6	P			11	1988	09	1992	DBSR300
ROVER GROUP Montego	1.6	P			11	1988	09	1992	DBSR200
ROVER GROUP Montego	1.6	P		Trilobal inner joint	04	1984	10	1988	DBSR300
ROVER GROUP Montego	1.6	P		Trilobal inner joint	04	1984	10	1988	DBSR200
ROVER GROUP Montego	2.0	P Inj	Auto		04	1984	12	1994	DBSR300
ROVER GROUP Montego	2.0	P Inj	Auto		04	1984	12	1994	DBSR200
ROVER GROUP Montego	2.0	P Inj	Manual		04	1984	12	1994	DBSR300
ROVER GROUP Montego	2.0	P Inj	Manual		04	1984	12	1994	DBSR200
ROVER GROUP Montego	2.0	D Turbo			04	1985	11	1994	DBSR300
ROVER GROUP Montego	2.0	D Turbo			04	1985	11	1994	DBSR200
ROVER GROUP Montego	2.0	P Turbo			04	1985	11	1994	DBSR300
ROVER GROUP Montego	2.0	P Turbo			04	1985	11	1994	DBSR200
ROVER GROUP Princess	Mk1	1.8	P		09	1975	07	1978	DBSR200
ROVER GROUP Princess	Mk1	1.8	P		09	1975	07	1978	DBSR200
ROVER GROUP Princess	Mk1	2.2	P		09	1975	07	1978	DBSR200
ROVER GROUP Princess	Mk1	2.2	P		09	1975	07	1978	DBSR200
ROVER GROUP Princess	Mk2	1.7	P		07	1978	11	1981	DBSR200
ROVER GROUP Princess	Mk2	1.7	P		07	1978	11	1981	DBSR200
ROVER GROUP Princess	Mk2	2.0	P		07	1978	11	1981	DBSR200
ROVER GROUP Princess	Mk2	2.0	P		07	1978	11	1981	DBSR200
ROVER GROUP Princess	Mk2	2.2	P		07	1978	11	1981	DBSR200
ROVER GROUP Princess	Mk2	2.2	P		07	1978	11	1981	DBSR200
ROVER GROUP SD1		2.0	P		01	1982	12	1987	DBSR500
ROVER GROUP SD1		2.3	P		01	1977	12	1987	DBSR500
ROVER GROUP SD1		2.6	P		01	1977	12	1987	DBSR500
ROVER GROUP Triumph TR7		2.0	P		01	1975	12	1982	DBSR200
SAAB	90	2.0	P		08	1984	10	1985	DBSR200
SAAB	99	2.0	P		08	1974	08	1984	DBSR200

Sheet1

SAAB	900	Mk1	2.0	P		01	1979	12	1986	DBSR500
SAAB	900	Mk1	2.0	P Inj		10	1988	12	1986	DBSR500
SAAB	900	Mk1	2.0	P Inj		01	1986	12	1986	DBSR500
SAAB	9000		2.0	P Inj		10	1985	10	1998	DBSR400
SAAB	9000		2.3	P Inj		10	1989	12	1993	DBSR400
SAAB	9000		3.0	P Inj		10	1994	08	1996	DBSR400
SEAT	Alhambra		1.8	P Turbo	Manual	05	1998			DBSR200
SEAT	Alhambra		1.8	P Turbo	Semi-Auto	05	1998			DBSR200
SEAT	Alhambra		1.9	D Turbo	Auto, Semi-Auto	05	1998			DBSR200
SEAT	Alhambra		1.9	D Turbo	Manual	05	1996			DBSR200
SEAT	Alhambra		2.0	P Inj	Auto	12	1996	01	2000	DBSR200
SEAT	Alhambra		2.0	P Inj	Manual	05	1996			DBSR200
SEAT	Alhambra		2.8	P Inj		08	2000			DBSR200
SEAT	Arosa		1.0	P Inj		08	1997			DBSR200
SEAT	Arosa		1.4	P Inj		08	1997			DBSR200
SEAT	Arosa		1.4	P Inj		01	2000			DBSR200
SEAT	Arosa		1.7	D		02	1998	12	1999	DBSR200
SEAT	Cordoba	Mk1	1.4	P Inj		04	1995	08	2001	DBSR100
SEAT	Cordoba	Mk1	1.4	P Inj		04	1995	08	2001	DBSR300
SEAT	Cordoba	Mk1	1.6	P Inj		01	1998	10	2000	DBSR100
SEAT	Cordoba	Mk1	1.6	P Inj		01	1998	10	2000	DBSR300
SEAT	Cordoba	Mk1	1.6	P Inj		05	1994	10	2000	DBSR100
SEAT	Cordoba	Mk1	1.6	P Inj		05	1994	10	2000	DBSR300
SEAT	Cordoba	Mk1	1.8	P Inj	LHS	05	1994	03	1995	DBSR100
SEAT	Cordoba	Mk1	1.8	P Inj	LHS	05	1994	03	1995	DBSR300
SEAT	Cordoba	Mk1	1.8	P Inj	RHS	05	1994	03	1995	DBSR100
SEAT	Cordoba	Mk1	1.8	P Inj	RHS	05	1994	03	1995	DBSR300
SEAT	Cordoba	Mk1	1.9	D		05	1994	01	1999	DBSR100
SEAT	Cordoba	Mk1	1.9	D		05	1994	01	1999	DBSR300
SEAT	Cordoba	Mk1	1.9	D Turbo	LHS	05	1994	08	2001	DBSR100
SEAT	Cordoba	Mk1	1.9	D Turbo	LHS	05	1994	08	2001	DBSR300
SEAT	Cordoba	Mk1	1.9	D Turbo	RHS	05	1994	08	2001	DBSR100
SEAT	Cordoba	Mk1	1.9	D Turbo	RHS	05	1994	08	2001	DBSR300
SEAT	Cordoba	Mk1	2.0	P Inj	LHS	05	1994	09	1999	DBSR100
SEAT	Cordoba	Mk1	2.0	P Inj	LHS	05	1994	09	1999	DBSR300
SEAT	Cordoba	Mk1	2.0	P Inj	RHS	05	1994	09	1999	DBSR100

Sheet1

SEAT	Cordoba	Mk1	2.0	P Inj	RHS	05	1994	09	1999	DBSR300
SEAT	Ibiza	Mk1	0.9	P		02	1987	06	1991	DBSR100
SEAT	Ibiza	Mk1	1.2	P		10	1985	06	1991	DBSR100
SEAT	Ibiza	Mk1	1.5	P		10	1985	06	1991	DBSR100
SEAT	Ibiza	Mk1	1.5	P		01	1989	06	1991	DBSR100
SEAT	Ibiza	Mk1	1.7	D		04	1990	06	1991	DBSR100
SEAT	Ibiza	Mk2	0.9	P Inj		06	1991	11	1992	DBSR100
SEAT	Ibiza	Mk2	1.2	P Inj		06	1991	09	1993	DBSR100
SEAT	Ibiza	Mk2	1.5	P Inj		06	1991	09	1993	DBSR100
SEAT	Ibiza	Mk2	1.7	D		06	1991	09	1993	DBSR100
SEAT	Ibiza	Mk3	1.0	P		10	1993	06	1994	DBSR200
SEAT	Ibiza	Mk3	1.3	P		10	1993	06	1994	DBSR200
SEAT	Ibiza	Mk3	1.4	P Inj		01	1994	12	1998	DBSR200
SEAT	Ibiza	Mk3	1.6	P		10	1993	12	1998	DBSR200
SEAT	Ibiza	Mk3	1.8	P	LHS	10	1993	10	1996	DBSR200
SEAT	Ibiza	Mk3	1.8	P	RHS	10	1993	10	1996	DBSR200
SEAT	Ibiza	Mk3	1.8	P	LHS	10	1993	10	1996	DBSR200
SEAT	Ibiza	Mk3	1.8	P	RHS	10	1993	10	1996	DBSR200
SEAT	Ibiza	Mk3	1.8	P Turbo		06	2000	04	2002	DBSR200
SEAT	Ibiza	Mk3	1.9	D		10	1993	01	2001	DBSR200
SEAT	Ibiza	Mk3	1.9	D Turbo	LHS	12	1996	04	2002	DBSR200
SEAT	Ibiza	Mk3	1.9	D Turbo	RHS	12	1996	04	2002	DBSR200
SEAT	Ibiza	Mk3	2.0	P	LHS	10	1993	09	1999	DBSR200
SEAT	Ibiza	Mk3	2.0	P	RHS	10	1993	09	1999	DBSR200
SEAT	Malaga		1.2	P	Inner boot with bush	10	1985	03	1992	DBSR100
SEAT	Malaga		1.2	P	Inner boot without bush	10	1985	03	1992	DBSR100
SEAT	Malaga		1.5	P	Inner boot with bush	10	1985	03	1992	DBSR100
SEAT	Malaga		1.5	P	Inner boot without bush	10	1985	03	1992	DBSR100
SEAT	Malaga		1.7	D	Inner boot with bush	10	1985	03	1992	DBSR100
SEAT	Malaga		1.7	D	Inner boot without bush	10	1985	03	1992	DBSR100
SEAT	Marbella		0.85	P Inj	Inner boot with bush	05	1988	03	1995	DBSR100
SEAT	Marbella		0.85	P Inj	Inner boot without bush	05	1988	03	1995	DBSR100
SEAT	Marbella		0.9	P Inj	Inner boot with bush	05	1988	03	1995	DBSR100
SEAT	Marbella		0.9	P Inj	Inner boot without bush	05	1988	03	1995	DBSR100
SEAT	Toledo	Mk1	1.6	P Inj		12	1993	03	1999	DBSR200
SEAT	Toledo	Mk1	1.6	P Inj	LHS	10	1991	12	1993	DBSR200

Sheet1

SEAT	Toledo	Mk1	1.6	P Inj		RHS	10	1991	12	1993	DBSR200
SEAT	Toledo	Mk1	1.8	P Inj		LHS	10	1991	12	1996	DBSR200
SEAT	Toledo	Mk1	1.8	P Inj		RHS	10	1991	12	1996	DBSR200
SEAT	Toledo	Mk1	1.9	D Turbo		LHS	06	1992	03	1999	DBSR200
SEAT	Toledo	Mk1	1.9	D Turbo		RHS	06	1992	03	1999	DBSR200
SEAT	Toledo	Mk1	1.9	D			12	1995	03	1999	DBSR200
SEAT	Toledo	Mk1	1.9	D			01	1995	11	1995	DBSR200
SEAT	Toledo	Mk1	2.0	P Inj	Auto		11	1992	03	1999	DBSR200
SEAT	Toledo	Mk1	2.0	P Inj	Manual	LHS	10	1991	03	1999	DBSR200
SEAT	Toledo	Mk1	2.0	P Inj	Manual	RHS	10	1991	03	1999	DBSR200
SEAT LCV	Inca		1.4	P Inj			07	1997	09	1999	DBSR300
SEAT LCV	Inca		1.9	D			04	1996			DBSR300
SEAT LCV	Terra		0.9	P Inj		Inner boot with bush	05	1988	01	1993	DBSR100
SEAT LCV	Terra		0.9	P Inj		Inner boot without bush	05	1988	01	1993	DBSR100
SEAT LCV	Terra		1.3	D			06	1990	02	1991	DBSR100
SEAT LCV	Terra		1.4	D			02	1991	07	1994	DBSR100
SKODA	Estelle	Mk1	1.2	P			01	1982	12	1984	DBSR100
SKODA	Estelle	Mk2	1.2	P			01	1984	03	1990	DBSR100
SKODA	Estelle	Mk2	1.3	P			01	1984	03	1990	DBSR100
SKODA	Favorit		1.3	P Inj			06	1989	03	1996	DBSR200
SKODA	Felicia		1.3	P Inj			05	1995	06	2000	DBSR100
SKODA	Felicia		1.6	P Inj			05	1995	06	2000	DBSR100
SKODA	Felicia		1.9	D			05	1995	06	2000	DBSR100
SKODA	Octavia		1.6	P Inj	Auto		09	1998	09	2000	DBSR200
SKODA	Octavia		1.6	P Inj	Manual		06	1998			DBSR200
SKODA	Octavia		1.8	P Inj	Auto		09	1998			DBSR200
SKODA	Octavia		1.8	P Inj	Manual		06	1998			DBSR200
SKODA	Octavia		1.8	P Turbo	Auto		09	1999			DBSR200
SKODA	Octavia		1.8	P Turbo	Manual		09	1999			DBSR200
SKODA	Octavia		1.9	D Turbo	Auto		03	2001			DBSR200
SUBARU	L Series		1.6	P Inj	4wd	Front	07	1985	12	1992	DBSR200
SUBARU	L Series		1.6	P Inj	4wd	Front	07	1985	12	1992	DBSR200
SUBARU	L Series		1.6	P Inj	4wd	Rear	07	1985	12	1992	DBSR200
SUBARU	L Series		1.6	P Inj	4wd	Rear	07	1985	12	1992	DBSR200
SUBARU	L Series		1.6	P Inj	Fwd		03	1985	12	1992	DBSR200
SUBARU	L Series		1.6	P Inj	Fwd		03	1985	12	1992	DBSR200

Sheet1

SUBARU	L Series		1.8	P	4wd	Front	03	1985	04	1991	DBSR200
SUBARU	L Series		1.8	P	4wd	Front	11	1984	04	1991	DBSR200
SUBARU	L Series		1.8	P	4wd	Rear	03	1985	04	1991	DBSR200
SUBARU	L Series		1.8	P	4wd	Rear	11	1984	04	1991	DBSR200
SUBARU	L Series		1.8	P	Fwd		03	1985	10	1989	DBSR200
SUBARU	L Series		1.8	P	Fwd		11	1984	10	1989	DBSR200
SUBARU	L Series		1.8	P Turbo	4wd	Front	03	1985	04	1991	DBSR200
SUBARU	L Series		1.8	P Turbo	4wd	Front	11	1984	04	1991	DBSR200
SUBARU	L Series		1.8	P Turbo	4wd	Rear	03	1985	04	1991	DBSR200
SUBARU	L Series		1.8	P Turbo	4wd	Rear	11	1984	04	1991	DBSR200
SUBARU	Series 2		1.6	P	4wd	Front	03	1980	11	1984	DBSR200
SUBARU	Series 2		1.6	P	4wd	Rear	03	1980	11	1984	DBSR200
SUBARU	Series 2		1.6	P	Fwd		11	1979	09	1984	DBSR200
SUBARU	Series 2		1.8	P	4wd	Front	04	1981	11	1984	DBSR200
SUBARU	Series 2		1.8	P	4wd	Rear	04	1981	11	1984	DBSR200
SUBARU	Series 2		1.8	P	Fwd		04	1981	11	1984	DBSR200
SUBARU	XT		1.8	P Inj			06	1986	09	1990	DBSR200
SUBARU LCV	MV Pick-Up		1.8	P Inj	4wd	Front	05	1988	12	1994	DBSR200
SUZUKI	Alto	Mk2	0.8	P	CB91		01	1986	11	1992	DBSR200
SUZUKI	Alto	Mk2	0.8	P	CB91		04	1986	11	1992	DBSR200
SUZUKI	Alto	Mk2	0.8	P	SS80		01	1986	12	1985	DBSR200
SUZUKI	Alto	Mk2	0.8	P	SS80		07	1981	12	1985	DBSR200
SUZUKI	SJ		1.0	P	410 4wd	Front	09	1982	04	1990	DBSR100
SUZUKI	SJ		1.3	P Inj	413 4wd	Front	03	1985	05	1996	DBSR200
SUZUKI	Swift	Mk1	1.0	P	SA310,AA41	Trilobal inner joint	03	1984	12	1985	DBSR200
SUZUKI LCV	Super Carry		1.0	P Inj	SK410-DA21		03	1986	12	1993	DBSR100
TALBOT	Horizon		1.1	P			10	1978	09	1985	DBSR200
TALBOT	Horizon		1.3	P			10	1978	09	1985	DBSR200
TALBOT	Rancho		1.4	P			01	1980	07	1973	DBSR200
TALBOT	Rancho		1.4	P			01	1980	12	1979	DBSR200
TALBOT	Samba		1.0	P		Inner boot with tin case	03	1982	05	1986	DBSR200
TALBOT	Samba		1.0	P		Inner boot without tin case	03	1982	05	1986	DBSR200
TALBOT	Samba		1.1	P		Inner boot with tin case	03	1982	05	1986	DBSR200
TALBOT	Samba		1.1	P		Inner boot without tin case	03	1982	05	1986	DBSR200
TALBOT	Samba		1.4	P		Inner boot with tin case	03	1982	05	1986	DBSR200
TALBOT	Samba		1.4	P		Inner boot without tin case	03	1982	05	1986	DBSR200

Sheet1

TALBOT LCV	Express	1.8	P Inj			10	1982	06	1994	DBSR500
TALBOT LCV	Express	1.8	P Inj			10	1982	06	1994	DBSR300
TALBOT LCV	Express	1.9	D			10	1982	06	1994	DBSR500
TALBOT LCV	Express	1.9	D			10	1982	06	1994	DBSR300
TALBOT LCV	Express	2.0	P Inj			10	1982	06	1994	DBSR500
TALBOT LCV	Express	2.0	P Inj			10	1982	06	1994	DBSR300
TALBOT LCV	Express	2.5	D			10	1982	06	1994	DBSR500
TALBOT LCV	Express	2.5	D			10	1982	06	1994	DBSR300
TOYOTA	Camry	Mk2	2.0	D Turbo	CV20	01	1987	01	1988	DBSR100
TOYOTA	Camry	Mk2	2.0	P	4wd SV25	03	1988	03	1989	DBSR100
TOYOTA	Camry	Mk2	2.0	P	Fwd, Auto, SV21	01	1990	09	1991	DBSR100
TOYOTA	Camry	Mk2	2.0	P	Fwd, Auto, SV21	01	1987	12	1989	DBSR100
TOYOTA	Camry	Mk2	2.0	P	Fwd, Manual, SV21	01	1987	12	1989	DBSR100
TOYOTA	Camry	Mk2	2.0	P	Fwd, Manual, SV21	01	1990	09	1991	DBSR100
TOYOTA	Camry	Mk2	2.5	P	Auto VZV21	03	1989	09	1991	DBSR100
TOYOTA	Carina	Mk5	1.6	P	AT171	03	1988	05	1992	DBSR100
TOYOTA	Carina	Mk5	2.0	P	ST171	03	1988	05	1992	DBSR100
TOYOTA	Carina	Mk5	2.0	D	CT170	11	1990	05	1992	DBSR100
TOYOTA	Carina E	Mk6	1.6	P Inj	AT190	02	1992	12	1997	DBSR300
TOYOTA	Carina E	Mk6	1.8	P Inj	AT191	03	1995	12	1997	DBSR300
TOYOTA	Carina E	Mk6	2.0	D	CT190	05	1992	03	1996	DBSR300
TOYOTA	Carina E	Mk6	2.0	D	CT190	05	1992	03	1996	DBSR300
TOYOTA	Carina E	Mk6	2.0	P inj	Gti, ST191	05	1992	11	1997	DBSR300
TOYOTA	Carina E	Mk6	2.0	P Inj	ST191	05	1992	03	1996	DBSR300
TOYOTA	Carina E	Mk6	2.0	P Inj	ST191	05	1992	03	1996	DBSR300
TOYOTA	Carina E	Mk6	2.0	D Turbo	CT190	02	1996	11	1997	DBSR300
TOYOTA	Celica	Mk4	2.0	P	Fwd ST162	11	1985	01	1990	DBSR100
TOYOTA	Celica	Mk4	2.0	P Turbo	GT-4 4wd ST165	03	1988	01	1990	DBSR100
TOYOTA	Celica	Mk5	2.0	P Inj	Fwd ST182	02	1990	10	1993	DBSR100
TOYOTA	Celica	Mk5	2.0	P Turbo	GT-4 4wd ST185	02	1990	03	1994	DBSR100
TOYOTA	Corolla	Mk5	1.3	P	AE80,EE80	09	1983	04	1986	DBSR200
TOYOTA	Corolla	Mk5	1.3	P	AE80,EE80	05	1986	03	1987	DBSR200
TOYOTA	Corolla	Mk5	1.3	P	AE80,EE80	09	1983	04	1986	DBSR200
TOYOTA	Corolla	Mk5	1.3	P	AE80,EE80	05	1986	03	1987	DBSR200
TOYOTA	Corolla	Mk5	1.6	P	AE82	03	1985	04	1986	DBSR200
TOYOTA	Corolla	Mk5	1.6	P	AE82	05	1986	08	1987	DBSR200

Sheet1

TOYOTA	Corolla	Mk5	1.6	P	AE82	Trilobal inner joint	03	1985	04	1986	DBSR200
TOYOTA	Corolla	Mk5	1.6	P	AE82	Trilobal inner joint	05	1986	08	1987	DBSR200
TOYOTA	Corolla	Mk6	1.3	P	EE90	Trilobal inner joint	09	1990	08	1992	DBSR200
TOYOTA	Corolla	Mk6	1.3	P	EE90	Trilobal inner joint	08	1987	09	1990	DBSR200
TOYOTA	Corolla	Mk6	1.3	P	EE90	Trilobal inner joint	09	1990	08	1992	DBSR200
TOYOTA	Corolla	Mk6	1.3	P	EE90	Trilobal inner joint	08	1987	09	1990	DBSR200
TOYOTA	Corolla	Mk6	1.6	P	4wd AE95	Front	09	1990	04	1991	DBSR200
TOYOTA	Corolla	Mk6	1.6	P	4wd AE95	Front	03	1988	09	1990	DBSR200
TOYOTA	Corolla	Mk6	1.6	P	4wd AE95	Front	09	1990	04	1991	DBSR200
TOYOTA	Corolla	Mk6	1.6	P	4wd AE95	Front	03	1988	09	1990	DBSR200
TOYOTA	Corolla	Mk6	1.6	P	Fwd AE92	Trilobal inner joint	09	1990	08	1992	DBSR200
TOYOTA	Corolla	Mk6	1.6	P	Fwd AE92	Trilobal inner joint	08	1987	09	1990	DBSR200
TOYOTA	Corolla	Mk6	1.6	P	Fwd AE92	Trilobal inner joint	08	1987	09	1990	DBSR200
TOYOTA	Corolla	Mk6	1.6	P	Fwd AE92	Trilobal inner joint	09	1990	08	1992	DBSR200
TOYOTA	Corolla	Mk7	1.3	P Inj	EE101	Trilobal inner joint	08	1992	06	1997	DBSR200
TOYOTA	Corolla	Mk7	1.3	P Inj	EE101	Trilobal inner joint	08	1992	06	1997	DBSR200
TOYOTA	Corolla	Mk7	1.6	P Inj	AE101	Trilobal inner joint	08	1992	06	1997	DBSR200
TOYOTA	Corolla	Mk7	1.6	P Inj	AE101	Trilobal inner joint	08	1992	06	1997	DBSR200
TOYOTA	Corolla	Mk7	1.8	P	AE102		03	1993	03	1995	DBSR200
TOYOTA	Corolla	Mk7	1.8	P	AE102		03	1993	03	1995	DBSR200
TOYOTA	Corolla	Mk7	2.0	D	CE100	Trilobal inner joint	03	1993	06	1997	DBSR200
TOYOTA	Corolla	Mk7	2.0	D	CE100	Trilobal inner joint	03	1993	06	1997	DBSR200
TOYOTA	MR2	Mk1	1.6	P	AW11	Trilobal inner joint	01	1985	03	1990	DBSR500
TOYOTA	Space Cruiser		1.8	P			01	1983	12	1990	DBSR100
TOYOTA	Space Cruiser		2.0	P			01	1983	12	1990	DBSR100
TOYOTA	Starlet		1.0	P Inj	EP70	Trilobal inner joint	02	1985	03	1990	DBSR100
TOYOTA	Starlet		1.0	P Inj	EP80	Trilobal inner joint	04	1990	01	1993	DBSR100
TOYOTA	Starlet		1.3	P	EP81	Trilobal inner joint	01	1993	12	1996	DBSR100
TOYOTA	Starlet		1.3	P	EP91		04	1996	12	1996	DBSR100
TOYOTA	Supra		2.8	P inj			01	1982	12	1985	DBSR300
VAUXHALL	Astra	Mk1	1.2	P			04	1980	10	1984	DBSR300
VAUXHALL	Astra	Mk1	1.3	P	Auto		02	1982	10	1984	DBSR300
VAUXHALL	Astra	Mk1	1.3	P	Manual		02	1980	10	1984	DBSR300
VAUXHALL	Astra	Mk1	1.6	D			01	1982	12	1983	DBSR300
VAUXHALL	Astra	Mk1	1.6	D			01	1983	10	1984	DBSR300
VAUXHALL	Astra	Mk1	1.6	P	Auto		12	1981	10	1984	DBSR300

Sheet1

VAUXHALL	Astra	Mk1	1.6	P	Manual	12	1981	10	1984	DBSR300
VAUXHALL	Astra	Mk1	1.8	P		01	1984	10	1984	DBSR300
VAUXHALL	Astra	Mk2	1.2	P	Auto	09	1986	10	1991	DBSR300
VAUXHALL	Astra	Mk2	1.2	P	Manual	10	1984	10	1991	DBSR300
VAUXHALL	Astra	Mk2	1.3	P	Auto	10	1984	10	1989	DBSR300
VAUXHALL	Astra	Mk2	1.3	P	Manual	10	1984	10	1989	DBSR300
VAUXHALL	Astra	Mk2	1.4	P		10	1989	10	1991	DBSR300
VAUXHALL	Astra	Mk2	1.6	D		01	1985	12	1989	DBSR300
VAUXHALL	Astra	Mk2	1.6	P	Auto	10	1984	10	1991	DBSR300
VAUXHALL	Astra	Mk2	1.6	P	Manual	10	1984	10	1991	DBSR300
VAUXHALL	Astra	Mk2	1.7	D		01	1989	10	1991	DBSR300
VAUXHALL	Astra	Mk2	1.8	P	Auto	01	1989	10	1991	DBSR300
VAUXHALL	Astra	Mk2	1.8	P	Manual	10	1984	10	1991	DBSR300
VAUXHALL	Astra	Mk2	1.8	P	Manual	09	1990	10	1991	DBSR300
VAUXHALL	Astra	Mk2	2.0	P Inj	GTE	03	1987	10	1991	DBSR300
VAUXHALL	Astra	Mk3	1.4	P Inj	Auto	04	1992	03	1998	DBSR300
VAUXHALL	Astra	Mk3	1.4	P Inj	Manual	10	1991	03	1998	DBSR300
VAUXHALL	Astra	Mk3	1.6	P Inj	Auto	11	1992	03	1998	DBSR300
VAUXHALL	Astra	Mk3	1.6	P Inj	Manual	10	1991	03	1998	DBSR300
VAUXHALL	Astra	Mk3	1.7	D		08	1994	12	1995	DBSR300
VAUXHALL	Astra	Mk3	1.7	D		10	1991	08	1994	DBSR300
VAUXHALL	Astra	Mk3	1.7	D Turbo		04	1992	03	1998	DBSR300
VAUXHALL	Astra	Mk3	1.8	P	Auto	08	1997	03	1998	DBSR300
VAUXHALL	Astra	Mk3	1.8	P	Manual	06	1993	03	1998	DBSR300
VAUXHALL	Astra	Mk3	2.0	P	Auto	08	1997	03	1998	DBSR300
VAUXHALL	Astra	Mk3	2.0	P	Manual	06	1993	03	1998	DBSR300
VAUXHALL	Astra	Mk4	1.4	P Inj		04	1998			DBSR300
VAUXHALL	Astra	Mk4	1.6	P Inj	Auto	04	1998			DBSR300
VAUXHALL	Astra	Mk4	1.6	P Inj	Manual	04	1998			DBSR300
VAUXHALL	Astra	Mk4	1.7	D Turbo		04	1998			DBSR300
VAUXHALL	Astra	Mk4	1.8	P Inj	Auto	04	1998			DBSR300
VAUXHALL	Astra	Mk4	1.8	P Inj	Manual	04	1998			DBSR300
VAUXHALL	Astra	Mk4	2.0	D Turbo	Auto	04	1998	09	2000	DBSR300
VAUXHALL	Astra	Mk4	2.0	D Turbo	Manual	04	1998			DBSR300
VAUXHALL	Astra	Mk4	2.0	P Inj		08	1998	10	2000	DBSR300
VAUXHALL	Astra	Mk4	2.0	P turbo		11	2000			DBSR300

Sheet1

VAUXHALL	Astra	Mk4	2.2	P Inj	Auto		10	2000				DBSR300
VAUXHALL	Astra	Mk4	2.2	P Inj	Manual		10	2000				DBSR300
VAUXHALL	Belmont		1.3	P	Auto		01	1989	10	1989		DBSR300
VAUXHALL	Belmont		1.3	P	Manual		01	1989	10	1989		DBSR300
VAUXHALL	Belmont		1.4	P			10	1989	10	1991		DBSR300
VAUXHALL	Belmont		1.6	P	Auto		01	1989	10	1991		DBSR300
VAUXHALL	Belmont		1.6	P	Manual		01	1989	10	1991		DBSR300
VAUXHALL	Belmont		1.8	P	Auto		01	1989	10	1991		DBSR300
VAUXHALL	Belmont		1.8	P	Manual		01	1989	10	1991		DBSR300
VAUXHALL	Belmont		1.8	P	Manual		01	1989	10	1991		DBSR300
VAUXHALL	Calibra		2.0	P Inj	4wd	Front	09	1990	12	1990		DBSR200
VAUXHALL	Calibra		2.0	P Inj	4wd	Front	01	1991	12	1996		DBSR300
VAUXHALL	Calibra		2.0	P Inj	Fwd		06	1990	12	1990		DBSR200
VAUXHALL	Calibra		2.0	P Inj	Fwd		01	1991	08	1998		DBSR300
VAUXHALL	Calibra		2.0	P Inj	Fwd		06	1990	12	1990		DBSR200
VAUXHALL	Calibra		2.0	P Inj	Fwd		01	1991	08	1998		DBSR300
VAUXHALL	Calibra		2.5	P			08	1993	08	1998		DBSR300
VAUXHALL	Cavalier	Mk2	1.3	P	Auto		08	1981	12	1986		DBSR300
VAUXHALL	Cavalier	Mk2	1.3	P	Manual		08	1981	12	1986		DBSR300
VAUXHALL	Cavalier	Mk2	1.6	D	Manual		01	1982	12	1986		DBSR300
VAUXHALL	Cavalier	Mk2	1.6	D	Manual		01	1982	12	1986		DBSR300
VAUXHALL	Cavalier	Mk2	1.6	P	Auto		08	1981	12	1986		DBSR300
VAUXHALL	Cavalier	Mk2	1.6	P	Manual		01	1984	12	1986		DBSR300
VAUXHALL	Cavalier	Mk2	1.6	P	Manual		08	1981	12	1986		DBSR300
VAUXHALL	Cavalier	Mk2	1.8	P	Auto		10	1982	08	1988		DBSR300
VAUXHALL	Cavalier	Mk2	1.8	P	Manual		01	1984	10	1988		DBSR300
VAUXHALL	Cavalier	Mk2	1.8	P	Manual		10	1982	12	1983		DBSR300
VAUXHALL	Cavalier	Mk3	1.4	P			01	1989	08	1992		DBSR300
VAUXHALL	Cavalier	Mk3	1.6	P Inj	Auto		01	1989	08	1992		DBSR300
VAUXHALL	Cavalier	Mk3	1.6	P Inj	Manual		01	1989	10	1995		DBSR300
VAUXHALL	Cavalier	Mk3	1.7	D			01	1989	10	1995		DBSR300
VAUXHALL	Cavalier	Mk3	1.7	D Turbo			03	1992	10	1995		DBSR300
VAUXHALL	Cavalier	Mk3	1.8	P Inj	Auto		08	1989	12	1992		DBSR300
VAUXHALL	Cavalier	Mk3	1.8	P Inj	Auto		08	1989	10	1995		DBSR300
VAUXHALL	Cavalier	Mk3	1.8	P Inj	Manual		08	1989	10	1995		DBSR300
VAUXHALL	Cavalier	Mk3	1.8	P Inj	Manual		08	1989	12	1992		DBSR300

Sheet1

VAUXHALL	Cavalier	Mk3	2.0	P Inj	Auto	01	1989	08	1994	DBSR300
VAUXHALL	Cavalier	Mk3	2.0	P Inj	Manual	01	1989	08	1994	DBSR300
VAUXHALL	Cavalier	Mk3	2.0	P Inj		10	1989	10	1995	DBSR300
VAUXHALL	Corsa	Mk1	1.0	P Inj		04	1997	09	2000	DBSRPS200
VAUXHALL	Corsa	Mk1	1.2	P	Auto	08	1998	09	2000	DBSRPS200
VAUXHALL	Corsa	Mk1	1.2	P	Manual	04	1993	09	2000	DBSRPS200
VAUXHALL	Corsa	Mk1	1.4	P	Auto	05	1993	09	2000	DBSRPS200
VAUXHALL	Corsa	Mk1	1.4	P	Manual	04	1993	09	2000	DBSRPS200
VAUXHALL	Corsa	Mk1	1.5	D		04	1993	09	2000	DBSRPS200
VAUXHALL	Corsa	Mk1	1.5	D Turbo		04	1993	09	2000	DBSRPS200
VAUXHALL	Corsa	Mk1	1.6	P		08	1993	09	2000	DBSRPS200
VAUXHALL	Corsa	Mk1	1.7	D		02	1996	09	2000	DBSRPS200
VAUXHALL	Frontera						10	1998		DBSR100
VAUXHALL	Monteray		3.1	D Turbo		01	1994			DBSR300
VAUXHALL	Monteray		3.2	P Inj		01	1994			DBSR300
VAUXHALL	Nova		1.0	P Inj		04	1983	12	1992	DBSR200
VAUXHALL	Nova		1.2	P Inj		04	1983	03	1993	DBSR200
VAUXHALL	Nova		1.2	P Inj		04	1983	12	1989	DBSR200
VAUXHALL	Nova		1.3	P Inj		04	1983	03	1993	DBSR200
VAUXHALL	Nova		1.3	P Inj		04	1983	12	1989	DBSR200
VAUXHALL	Nova		1.4	P Inj		01	1990	03	1993	DBSR200
VAUXHALL	Nova		1.5	D Turbo		09	1989	03	1993	DBSR200
VAUXHALL	Nova		1.5	D		09	1991	03	1993	DBSR200
VAUXHALL	Nova		1.6	P		05	1988	03	1993	DBSR200
VAUXHALL	Nova		1.6	P Inj		05	1988	03	1993	DBSR200
VAUXHALL	Sintra		2.2	D Turbo		01	1997			DBSR200
VAUXHALL	Sintra		2.2	P Inj		01	1997			DBSR200
VAUXHALL	Sintra		3.0	P Inj		01	1997			DBSR200
VAUXHALL	Tigra		1.4	P Inj	Auto	02	1995	06	2000	DBSRPS200
VAUXHALL	Tigra		1.4	P Inj	Manual	11	1994	06	2000	DBSRPS200
VAUXHALL	Tigra		1.6	P Inj		11	1994	06	2000	DBSRPS200
VAUXHALL	Vectra	Mk1	1.6	P Inj		10	1995	03	1999	DBSR200
VAUXHALL	Vectra	Mk1	1.6	P Inj	Auto	10	1995	03	1999	DBSR200
VAUXHALL	Vectra	Mk1	1.6	P Inj	Manual	10	1995	03	1999	DBSR200
VAUXHALL	Vectra	Mk1	1.7	D Turbo		10	1995	08	1996	DBSR200
VAUXHALL	Vectra	Mk1	1.8	P Inj	Auto	02	1996	03	1999	DBSR200

Sheet1

VAUXHALL	Vectra	Mk1	1.8	P Inj	Manual	10	1995	03	1999	DBSR200
VAUXHALL	Vectra	Mk1	2.0	P Inj	Auto	10	1995	03	1999	DBSR200
VAUXHALL	Vectra	Mk1	2.0	P Inj	Manual	10	1995	03	1999	DBSR200
VAUXHALL	Vectra	Mk1	2.0	D Turbo		08	1996	03	1999	DBSR200
VAUXHALL	Vectra	Mk1	2.5	P Inj	Auto	10	1995	03	1999	DBSR200
VAUXHALL	Vectra	Mk1	2.5	P Inj	Manual	10	1995	03	1999	DBSR200
VAUXHALL	Vectra	Mk2	1.6	P Inj		03	1999	09	2000	DBSR200
VAUXHALL	Vectra	Mk2	1.6	P Inj	Auto	03	1999	05	2002	DBSR200
VAUXHALL	Vectra	Mk2	1.6	P Inj	Manual	03	1999	05	2002	DBSR200
VAUXHALL	Vectra	Mk2	1.8	P Inj	Auto	03	1999	05	2002	DBSR200
VAUXHALL	Vectra	Mk2	1.8	P Inj	Manual	03	1999	05	2002	DBSR200
VAUXHALL	Vectra	Mk2	2.0	P Inj	Auto	03	1999	09	2000	DBSR200
VAUXHALL	Vectra	Mk2	2.0	P Inj	Manual	03	1999	09	2000	DBSR200
VAUXHALL	Vectra	Mk2	2.0	D Turbo		03	1999	05	2002	DBSR200
VAUXHALL	Vectra	Mk2	2.2	D Turbo		09	2000	05	2002	DBSR200
VAUXHALL	Vectra	Mk2	2.2	P Inj	Auto	09	2000	05	2002	DBSR200
VAUXHALL	Vectra	Mk2	2.2	P Inj	Manual	09	2000	05	2002	DBSR200
VAUXHALL	Vectra	Mk2	2.5	P Inj	Auto	03	1999	10	2000	DBSR200
VAUXHALL	Vectra	Mk2	2.5	P Inj	Manual	03	1999	10	2000	DBSR200
VAUXHALL	Vectra	Mk2	2.6	P Inj	Auto	09	2000	05	2002	DBSR200
VAUXHALL	Vectra	Mk2	2.6	P Inj	Manual	09	2000	05	2002	DBSR200
VAUXHALL	Zafira		1.6	P Inj		05	1999			DBSR300
VAUXHALL	Zafira		1.8	P Inj	Auto	05	1999			DBSR300
VAUXHALL	Zafira		1.8	P Inj	Manual	05	1999			DBSR300
VAUXHALL	Zafira		2.0	D Turbo		10	1999			DBSR300
VAUXHALL	Zafira		2.2	P Inj	Auto	10	2000			DBSR300
VAUXHALL	Zafira		2.2	P Inj	Manual	10	2000			DBSR300
VAUXHALL LCV	Combo	Mk1	1.4	P		10	1993	02	2001	DBSR300
VAUXHALL LCV	Combo	Mk1	1.4	P		10	1993	02	2001	DBSR200
VAUXHALL LCV	Combo	Mk1	1.7	D		10	1993	09	2001	DBSR300
VAUXHALL LCV	Combo	Mk1	1.7	D		10	1993	09	2001	DBSR200
VAUXHALL LCV	Corsa Van	Mk1	1.4	P Inj		02	1994	02	2001	DBSRPS300
VAUXHALL LCV	Corsa Van	Mk1	1.4	P Inj		02	1994	02	2001	DBSR200
VAUXHALL LCV	Corsa Van	Mk1	1.7	D		02	1994	09	2001	DBSRPS300
VAUXHALL LCV	Corsa Van	Mk1	1.7	D		02	1994	09	2001	DBSR200
VAUXHALL LCV	Nova Van		1.0	P Inj		01	1991	02	1993	DBSR200

Sheet1

VAUXHALL LCV	Nova Van	1.2	P Inj			01	1991	02	1993	DBSR200
VAUXHALL LCV	Nova Van	1.5	D			01	1991	02	1993	DBSR200
VAUXHALL LCV	Rascal	1.0	P			01	1986	12	1994	DBSR100
VOLKSWAGEN	Bora	1.6	P Inj	Auto		04	1999			DBSR200
VOLKSWAGEN	Bora	1.6	P Inj	Manual		04	1999			DBSR200
VOLKSWAGEN	Bora	1.9	D Turbo			04	1999			DBSR200
VOLKSWAGEN	Bora	1.9	D Turbo			04	1999			DBSR200
VOLKSWAGEN	Bora	2.0	P Inj			04	1999			DBSR200
VOLKSWAGEN	Bora	2.3	P Inj			06	2001			DBSR200
VOLKSWAGEN	Corrado	1.8	P Inj		LHS	05	1989	06	1995	DBSR300
VOLKSWAGEN	Corrado	1.8	P Inj		RHS	05	1989	06	1995	DBSR300
VOLKSWAGEN	Derby	1.1	P			01	1981	07	1981	DBSR100
VOLKSWAGEN	Derby	1.1	P			01	1978	07	1981	DBSR100
VOLKSWAGEN	Derby	1.3	P			01	1981	07	1981	DBSR100
VOLKSWAGEN	Derby	1.3	P			01	1978	07	1981	DBSR100
VOLKSWAGEN	Golf	Mk1	1.1	P		10	1974	10	1983	DBSR100
VOLKSWAGEN	Golf	Mk1	1.3	P		10	1974	10	1983	DBSR100
VOLKSWAGEN	Golf	Mk1	1.5	P		10	1974	10	1983	DBSR100
VOLKSWAGEN	Golf	Mk1	1.6	D		04	1974	07	1983	DBSR100
VOLKSWAGEN	Golf	Mk1	1.6	P		04	1974	07	1983	DBSR100
VOLKSWAGEN	Golf	Mk1	1.6	P inj	Gli	04	1974	07	1983	DBSR100
VOLKSWAGEN	Golf	Mk1	1.6	P inj	Gti	04	1974	07	1983	DBSR100
VOLKSWAGEN	Golf	Mk1	1.8	P Inj	Gti	09	1982	07	1983	DBSR100
VOLKSWAGEN	Golf	Mk2	1.05	P		01	1984	12	1991	DBSR100
VOLKSWAGEN	Golf	Mk2	1.05	P		11	1983	12	1991	DBSR100
VOLKSWAGEN	Golf	Mk2	1.05	P		08	1989	12	1991	DBSRPS300
VOLKSWAGEN	Golf	Mk2	1.3	P		01	1984	12	1991	DBSR100
VOLKSWAGEN	Golf	Mk2	1.3	P		11	1983	12	1991	DBSR100
VOLKSWAGEN	Golf	Mk2	1.3	P		08	1989	12	1991	DBSRPS300
VOLKSWAGEN	Golf	Mk2	1.6	D		11	1983	02	1992	DBSR100
VOLKSWAGEN	Golf	Mk2	1.6	D		01	1984	02	1992	DBSR100
VOLKSWAGEN	Golf	Mk2	1.6	D		08	1989	02	1992	DBSRPS300
VOLKSWAGEN	Golf	Mk2	1.6	D Turbo		11	1983	02	1992	DBSR100
VOLKSWAGEN	Golf	Mk2	1.6	D Turbo		01	1984	02	1992	DBSR100
VOLKSWAGEN	Golf	Mk2	1.6	D Turbo		08	1989	02	1992	DBSRPS300
VOLKSWAGEN	Golf	Mk2	1.6	P Inj		11	1983	02	1992	DBSR100

Sheet1

VOLKSWAGEN	Golf	Mk2	1.6	P Inj			01	1984	02	1992	DBSR100
VOLKSWAGEN	Golf	Mk2	1.6	P Inj			08	1989	02	1992	DBSRPS300
VOLKSWAGEN	Golf	Mk2	1.8	P Carb			11	1983	07	1992	DBSR100
VOLKSWAGEN	Golf	Mk2	1.8	P Carb			01	1984	07	1992	DBSR100
VOLKSWAGEN	Golf	Mk2	1.8	P Carb			08	1989	05	1992	DBSRPS300
VOLKSWAGEN	Golf	Mk2	1.8	P Carb	Fwd		11	1983	10	1991	DBSR100
VOLKSWAGEN	Golf	Mk2	1.8	P Carb	Fwd		01	1984	10	1991	DBSR100
VOLKSWAGEN	Golf	Mk2	1.8	P Carb	Fwd		08	1989	05	1992	DBSRPS300
VOLKSWAGEN	Golf	Mk2	1.8	P Inj	Gti	LHS	05	1984	07	1992	DBSR100
VOLKSWAGEN	Golf	Mk2	1.8	P Inj	Gti	LHS	08	1989	05	1992	DBSRPS300
VOLKSWAGEN	Golf	Mk2	1.8	P Inj	Gti	RHS	05	1984	07	1992	DBSR100
VOLKSWAGEN	Golf	Mk2	1.8	P Inj	Gti	RHS	08	1989	05	1992	DBSRPS300
VOLKSWAGEN	Golf	Mk2	1.8	P Inj	Gti Fwd	LHS	01	1984	10	1991	DBSR100
VOLKSWAGEN	Golf	Mk2	1.8	P Inj	Gti Fwd	LHS	08	1989	05	1992	DBSRPS300
VOLKSWAGEN	Golf	Mk2	1.8	P Inj	Gti Fwd	RHS	01	1984	10	1991	DBSR100
VOLKSWAGEN	Golf	Mk2	1.8	P Inj	Gti Fwd	RHS	08	1989	05	1992	DBSRPS300
VOLKSWAGEN	Golf	Mk2	1.8	P	4wd Syncro	Front, LHS	08	1988	10	1991	DBSR100
VOLKSWAGEN	Golf	Mk2	1.8	P	4wd Syncro	Front, LHS	08	1989	10	1991	DBSRPS300
VOLKSWAGEN	Golf	Mk2	1.8	P	4wd Syncro	Front, RHS	08	1988	10	1991	DBSR100
VOLKSWAGEN	Golf	Mk2	1.8	P	4wd Syncro	Front, RHS	08	1989	10	1991	DBSRPS300
VOLKSWAGEN	Golf	Mk2	1.8	P	4wd Syncro	Rear	08	1988	10	1991	DBSR100
VOLKSWAGEN	Golf	Mk2	1.8	P	4wd Syncro	Rear	08	1989	10	1991	DBSRPS300
VOLKSWAGEN	Golf	Mk3	1.4	P Inj			02	1992	08	1997	DBSR100
VOLKSWAGEN	Golf	Mk3	1.4	P Inj			02	1992	03	1998	DBSR100
VOLKSWAGEN	Golf	Mk3	1.4	P Inj			02	1992	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk3	1.6	P	Auto		12	1996	03	1998	DBSR100
VOLKSWAGEN	Golf	Mk3	1.6	P	Auto		12	1996	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk3	1.6	P	Manual		09	1993	03	1998	DBSR100
VOLKSWAGEN	Golf	Mk3	1.6	P	Manual		09	1993	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk3	1.8	P Inj	Auto		04	1992	07	1999	DBSR100
VOLKSWAGEN	Golf	Mk3	1.8	P Inj	Auto		04	1992	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk3	1.8	P Inj	Manual	LHS	02	1992	07	1999	DBSR100
VOLKSWAGEN	Golf	Mk3	1.8	P Inj	Manual	LHS	02	1992	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk3	1.8	P Inj	Manual	RHS	02	1992	07	1999	DBSR100
VOLKSWAGEN	Golf	Mk3	1.8	P Inj	Manual	RHS	02	1992	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk3	1.9	D	Auto	LHS	07	1994	06	1995	DBSR100

Sheet1

VOLKSWAGEN	Golf	Mk3	1.9	D	Auto	LHS	07	1994	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk3	1.9	D	Auto	RHS	07	1994	06	1995	DBSR100
VOLKSWAGEN	Golf	Mk3	1.9	D	Auto	RHS	07	1994	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk3	1.9	D	Manual		02	1992	07	1999	DBSR100
VOLKSWAGEN	Golf	Mk3	1.9	D	Manual		02	1992	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk3	1.9	D Turbo		LHS	02	1992	07	1999	DBSR100
VOLKSWAGEN	Golf	Mk3	1.9	D Turbo		LHS	02	1992	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk3	1.9	D Turbo		RHS	02	1992	07	1999	DBSR100
VOLKSWAGEN	Golf	Mk3	1.9	D Turbo		RHS	02	1992	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk3	2.0	P Inj	Auto		01	1994	07	1999	DBSR100
VOLKSWAGEN	Golf	Mk3	2.0	P Inj	Manual	LHS	02	1992	07	1999	DBSR100
VOLKSWAGEN	Golf	Mk3	2.0	P Inj	Manual	RHS	02	1992	07	1999	DBSR100
VOLKSWAGEN	Golf	Mk3	2.8	P Inj	VR6 Auto		02	1993	03	1998	DBSR100
VOLKSWAGEN	Golf	Mk3	2.8	P Inj	VR6 Auto		02	1993	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk3	2.8	P Inj	VR6 Manual	LHS	02	1992	03	1998	DBSR100
VOLKSWAGEN	Golf	Mk3	2.8	P Inj	VR6 Manual	LHS	02	1992	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk3	2.8	P Inj	VR6 Manual	RHS	02	1992	03	1998	DBSR100
VOLKSWAGEN	Golf	Mk3	2.8	P Inj	VR6 Manual	RHS	02	1992	08	1997	DBSRPS300
VOLKSWAGEN	Golf	Mk4	1.4	P Inj			01	1998			DBSR200
VOLKSWAGEN	Golf	Mk4	1.6	P Inj	Auto		01	1998			DBSR200
VOLKSWAGEN	Golf	Mk4	1.6	P Inj	Manual		01	1998			DBSR200
VOLKSWAGEN	Golf	Mk4	1.8	P Inj			01	1998			DBSR200
VOLKSWAGEN	Golf	Mk4	1.8	P Turbo			01	1998			DBSR200
VOLKSWAGEN	Golf	Mk4	1.9	D			01	1998			DBSR200
VOLKSWAGEN	Golf	Mk4	1.9	D Turbo	Auto		01	1998			DBSR200
VOLKSWAGEN	Golf	Mk4	1.9	D Turbo	Manual 5 speed		01	1998			DBSR200
VOLKSWAGEN	Golf	Mk4	1.9	D Turbo	Manual 6 speed		01	1998			DBSR200
VOLKSWAGEN	Golf	Mk4	2.0	P Inj	Auto		05	1998	06	2002	DBSR200
VOLKSWAGEN	Golf	Mk4	2.0	P Inj	Manual		05	1998			DBSR200
VOLKSWAGEN	Golf	Mk4	2.3	P Inj	V5 Auto		01	1998			DBSR200
VOLKSWAGEN	Golf	Mk4	2.3	P Inj	V5 Manual		01	1998			DBSR200
VOLKSWAGEN	Golf	Mk4	2.8	P Inj	4wd		04	1998			DBSR200
VOLKSWAGEN	Jetta	Mk2	1.3	P			09	1984	10	1991	DBSR100
VOLKSWAGEN	Jetta	Mk2	1.6	D			09	1984	11	1992	DBSR100
VOLKSWAGEN	Jetta	Mk2	1.6	D Turbo			09	1984	11	1992	DBSR100
VOLKSWAGEN	Jetta	Mk2	1.6	P			09	1984	11	1992	DBSR100

Sheet1

VOLKSWAGEN	Jetta	Mk2	1.6	P			09	1984	11	1992	DBSRPS300
VOLKSWAGEN	Jetta	Mk2	1.8	P Carb			09	1984	11	1992	DBSR100
VOLKSWAGEN	Jetta	Mk2	1.8	P Carb			09	1984	11	1992	DBSRPS300
VOLKSWAGEN	Jetta	Mk2	1.8	P Inj		LHS	11	1985	10	1991	DBSR100
VOLKSWAGEN	Jetta	Mk2	1.8	P Inj		LHS	11	1985	10	1991	DBSRPS300
VOLKSWAGEN	Jetta	Mk2	1.8	P Inj		RHS	11	1985	10	1991	DBSR100
VOLKSWAGEN	Jetta	Mk2	1.8	P Inj		RHS	11	1985	10	1991	DBSRPS300
VOLKSWAGEN	Lupo		1.0	P Inj			04	1999			DBSR200
VOLKSWAGEN	Lupo		1.0	P Inj			04	1999			DBSR100
VOLKSWAGEN	Lupo		1.4	P Inj	Auto		04	1999			DBSR200
VOLKSWAGEN	Lupo		1.4	P Inj	Manual		04	1999			DBSR200
VOLKSWAGEN	Lupo		1.6	P Inj			12	2000			DBSR200
VOLKSWAGEN	Lupo		1.7	D			04	1999			DBSR200
VOLKSWAGEN	Passat	Mk1	1.3	P			08	1973	09	1977	DBSR200
VOLKSWAGEN	Passat	Mk1	1.5	P			07	1973	09	1975	DBSR200
VOLKSWAGEN	Passat	Mk1	1.6	P			01	1981	10	1980	DBSR200
VOLKSWAGEN	Passat	Mk1	1.6	P			09	1975	10	1980	DBSR200
VOLKSWAGEN	Passat	Mk2	1.6	P Inj			08	1981	04	1988	DBSR200
VOLKSWAGEN	Passat	Mk2	1.8	P			01	1983	12	1988	DBSR200
VOLKSWAGEN	Passat	Mk2	2.0	P	Auto	LHS	01	1985	02	1988	DBSR200
VOLKSWAGEN	Passat	Mk2	2.0	P	Auto	LHS	08	1983	02	1988	DBSR200
VOLKSWAGEN	Passat	Mk2	2.0	P	Auto	RHS	08	1983	02	1988	DBSR200
VOLKSWAGEN	Passat	Mk2	2.0	P	Auto	RHS	01	1985	02	1988	DBSR200
VOLKSWAGEN	Passat	Mk2	2.0	P	Manual		01	1985	02	1988	DBSR200
VOLKSWAGEN	Passat	Mk2	2.0	P	Manual		08	1983	02	1988	DBSR200
VOLKSWAGEN	Passat	Mk3	1.6	D Turbo			09	1988	07	1990	DBSRPS300
VOLKSWAGEN	Passat	Mk3	1.6	D Turbo		LHS	08	1990	12	1993	DBSRPS300
VOLKSWAGEN	Passat	Mk3	1.6	D Turbo		RHS	08	1990	12	1993	DBSRPS300
VOLKSWAGEN	Passat	Mk3	1.8	P Inj		LHS	04	1988	07	1994	DBSR100
VOLKSWAGEN	Passat	Mk3	1.8	P Inj		LHS	09	1992	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	1.8	P Inj		LHS	04	1988	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	1.8	P Inj		RHS	04	1988	07	1994	DBSR100
VOLKSWAGEN	Passat	Mk3	1.8	P Inj		RHS	09	1992	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	1.8	P Inj		RHS	04	1988	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	1.9	D Turbo			03	1996	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	1.9	D Turbo		LHS	09	1992	09	1996	DBSRPS300

Sheet1

VOLKSWAGEN	Passat	Mk3	1.9	D Turbo	RHS	09	1992	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	2.0	P Inj	LHS	09	1992	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	2.0	P Inj	LHS	08	1989	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	2.0	P Inj	RHS	08	1989	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	2.0	P Inj	RHS	09	1992	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	2.0	P Inj	LHS	09	1992	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	2.0	P Inj	LHS	08	1989	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	2.0	P Inj	RHS	09	1992	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	2.0	P Inj	RHS	08	1989	09	1996	DBSRPS300
VOLKSWAGEN	Passat	Mk3	2.8	P		01	1993	12	1995	DBSRPS300
VOLKSWAGEN	Passat	Mk4	1.6	P Inj		02	1997	05	1999	DBSR300
VOLKSWAGEN	Passat	Mk4	1.8	P Inj		02	1997			DBSR300
VOLKSWAGEN	Passat	Mk4	1.9	D Turbo		02	1997	12	2000	DBSR300
VOLKSWAGEN	Passat	Mk4	1.9	D Turbo		02	1997	12	2000	DBSR300
VOLKSWAGEN	Polo	Mk1	0.9	P		01	1976	12	1978	DBSR100
VOLKSWAGEN	Polo	Mk1	1.1	P		01	1976	08	1981	DBSR100
VOLKSWAGEN	Polo	Mk2	1.05	P		11	1981	10	1983	DBSR100
VOLKSWAGEN	Polo	Mk2	1.05	P		07	1981	12	1981	DBSR100
VOLKSWAGEN	Polo	Mk2	1.05	P		11	1981	12	1990	DBSR100
VOLKSWAGEN	Polo	Mk2	1.05	P		11	1983	12	1981	DBSR100
VOLKSWAGEN	Polo	Mk2	1.1	P		11	1981	10	1983	DBSR100
VOLKSWAGEN	Polo	Mk2	1.1	P		07	1981	10	1983	DBSR100
VOLKSWAGEN	Polo	Mk2	1.1	P		11	1981	12	1990	DBSR100
VOLKSWAGEN	Polo	Mk2	1.1	P		11	1983	12	1990	DBSR100
VOLKSWAGEN	Polo	Mk2	1.3	P		11	1981	10	1983	DBSR100
VOLKSWAGEN	Polo	Mk2	1.3	P		07	1981	12	1981	DBSR100
VOLKSWAGEN	Polo	Mk2	1.3	P		11	1981	12	1990	DBSR100
VOLKSWAGEN	Polo	Mk2	1.3	P		11	1983	12	1981	DBSR100
VOLKSWAGEN	Polo	Mk3	1.05	P Inj		11	1990	08	1994	DBSR100
VOLKSWAGEN	Polo	Mk3	1.05	P Inj		11	1990	08	1994	DBSR100
VOLKSWAGEN	Polo	Mk3	1.3	P Inj		11	1990	08	1994	DBSR100
VOLKSWAGEN	Polo	Mk3	1.3	P Inj		11	1990	08	1994	DBSR100
VOLKSWAGEN	Polo	Mk4	1.0	P Inj		09	1994	01	2000	DBSR200
VOLKSWAGEN	Polo	Mk4	1.0	P Inj		09	1994	01	2000	DBSR100
VOLKSWAGEN	Polo	Mk4	1.3	P Inj		09	1994	01	2000	DBSR200
VOLKSWAGEN	Polo	Mk4	1.3	P Inj		09	1994	01	2000	DBSR100

Sheet1

VOLKSWAGEN Polo	Mk4	1.4	P Inj	Auto		04	1996	01	2000	DBSR200
VOLKSWAGEN Polo	Mk4	1.4	P Inj	Auto		04	1996	01	2000	DBSR100
VOLKSWAGEN Polo	Mk4	1.4	P Inj	Auto		04	1996	01	2000	DBSR200
VOLKSWAGEN Polo	Mk4	1.4	P Inj	Auto		04	1996	01	2000	DBSR100
VOLKSWAGEN Polo	Mk4	1.4	P Inj	Manual		07	1995	01	2000	DBSR200
VOLKSWAGEN Polo	Mk4	1.4	P Inj	Manual		07	1995	01	2000	DBSR100
VOLKSWAGEN Polo	Mk4	1.4	P Inj	Manual		07	1995	01	2000	DBSR200
VOLKSWAGEN Polo	Mk4	1.4	P Inj	Manual		07	1995	01	2000	DBSR100
VOLKSWAGEN Polo	Mk4	1.6	P Inj	Auto		04	1996	01	2000	DBSR200
VOLKSWAGEN Polo	Mk4	1.6	P Inj	Auto		04	1996	01	2000	DBSR300
VOLKSWAGEN Polo	Mk4	1.6	P Inj	Manual		10	1994	01	2000	DBSR200
VOLKSWAGEN Polo	Mk4	1.6	P Inj	Manual		10	1994	01	2000	DBSR300
VOLKSWAGEN Polo	Mk4	1.9	D			02	1995	01	2000	DBSR200
VOLKSWAGEN Polo	Mk4	1.9	D Turbo			02	1995	01	2000	DBSR300
VOLKSWAGEN Santana		1.6	P			08	1983	01	1985	DBSR200
VOLKSWAGEN Santana		1.8	P			02	1983	01	1985	DBSR200
VOLKSWAGEN Scirocco	Mk1	1.5	P			01	1977	09	1975	DBSR100
VOLKSWAGEN Scirocco	Mk1	1.5	P			01	1979	09	1975	DBSR100
VOLKSWAGEN Scirocco	Mk1	1.6	P			01	1978	12	1979	DBSR100
VOLKSWAGEN Scirocco	Mk1	1.6	P			01	1980	03	1981	DBSR100
VOLKSWAGEN Scirocco	Mk2	1.6	P			01	1982	08	1988	DBSR100
VOLKSWAGEN Scirocco	Mk2	1.8	P inj		LHS	01	1985	10	1991	DBSR100
VOLKSWAGEN Scirocco	Mk2	1.8	P inj		LHS	10	1982	10	1991	DBSR100
VOLKSWAGEN Scirocco	Mk2	1.8	P inj		RHS	01	1985	10	1991	DBSR100
VOLKSWAGEN Scirocco	Mk2	1.8	P inj		RHS	10	1982	10	1991	DBSR100
VOLKSWAGEN Scirocco	Mk2	1.8	P Inj			08	1983	12	1991	DBSR100
VOLKSWAGEN Scirocco	Mk2	1.8	P Inj			01	1985	12	1991	DBSR100
VOLKSWAGEN Sharan	Mk1	1.8	P Turbo	Auto		04	1998	05	2000	DBSR200
VOLKSWAGEN Sharan	Mk1	1.8	P Turbo	Manual		11	1997	05	2000	DBSR200
VOLKSWAGEN Sharan	Mk1	1.9	D Turbo	Auto		03	1997	05	2000	DBSR200
VOLKSWAGEN Sharan	Mk1	1.9	D Turbo	Manual		08	1995	05	2000	DBSR200
VOLKSWAGEN Sharan	Mk1	2.0	P Inj	Auto		08	1995	05	2000	DBSR200
VOLKSWAGEN Sharan	Mk1	2.0	P Inj	Manual		08	1995	05	2000	DBSR200
VOLKSWAGEN Sharan	Mk1	2.8	P Inj	Auto		08	1995	05	2000	DBSR200
VOLKSWAGEN Sharan	Mk1	2.8	P Inj	Manual		08	1995	05	2000	DBSR200
VOLKSWAGEN Sharan	Mk2	1.8	P Turbo	Auto		05	2000			DBSR200

Sheet1

VOLKSWAGEN	Sharan	Mk2	1.8	P Turbo	Manual		05	2000		DBSR200	
VOLKSWAGEN	Sharan	Mk2	1.9	D Turbo	Auto		05	2000		DBSR200	
VOLKSWAGEN	Sharan	Mk2	1.9	D Turbo	Manual		05	2000		DBSR200	
VOLKSWAGEN	Sharan	Mk2	2.0	P Inj	Auto		05	2000		DBSR200	
VOLKSWAGEN	Sharan	Mk2	2.0	P Inj	Manual		05	2000		DBSR200	
VOLKSWAGEN	Sharan	Mk2	2.8	P Inj			05	2000		DBSR200	
VOLKSWAGEN	Vento		1.6	P Inj			01	1994	09	1994	DBSR300
VOLKSWAGEN	Vento		1.6	P Inj			10	1994	11	1995	DBSR300
VOLKSWAGEN	Vento		1.8	P Inj	Auto		08	1994	01	1998	DBSR100
VOLKSWAGEN	Vento		1.8	P Inj	Auto		08	1994	01	1998	DBSR300
VOLKSWAGEN	Vento		1.8	P Inj	Auto	LHS	10	1992	07	1994	DBSR100
VOLKSWAGEN	Vento		1.8	P Inj	Auto	LHS	10	1992	07	1994	DBSR300
VOLKSWAGEN	Vento		1.8	P Inj	Auto	RHS	10	1992	07	1994	DBSR100
VOLKSWAGEN	Vento		1.8	P Inj	Auto	RHS	10	1992	07	1994	DBSR300
VOLKSWAGEN	Vento		1.8	P Inj	Manual	LHS	10	1992	01	1998	DBSR100
VOLKSWAGEN	Vento		1.8	P Inj	Manual	LHS	10	1992	01	1998	DBSR300
VOLKSWAGEN	Vento		1.8	P Inj	Manual	RHS	10	1992	01	1998	DBSR100
VOLKSWAGEN	Vento		1.8	P Inj	Manual	RHS	10	1992	01	1998	DBSR300
VOLKSWAGEN	Vento		1.9	D Turbo		LHS	10	1992	01	1998	DBSR100
VOLKSWAGEN	Vento		1.9	D Turbo		RHS	10	1992	01	1998	DBSR100
VOLKSWAGEN	Vento		1.9	D			04	1994	11	1995	DBSR100
VOLKSWAGEN	Vento		2.0	P Inj	Auto		08	1994	01	1998	DBSR100
VOLKSWAGEN	Vento		2.0	P Inj	Auto		08	1994	01	1998	DBSR300
VOLKSWAGEN	Vento		2.0	P Inj	Auto	LHS	10	1992	07	1994	DBSR100
VOLKSWAGEN	Vento		2.0	P Inj	Auto	LHS	10	1992	07	1994	DBSR300
VOLKSWAGEN	Vento		2.0	P Inj	Auto	RHS	10	1992	07	1994	DBSR100
VOLKSWAGEN	Vento		2.0	P Inj	Auto	RHS	10	1992	07	1994	DBSR300
VOLKSWAGEN	Vento		2.0	P Inj	Manual	LHS	10	1992	01	1998	DBSR100
VOLKSWAGEN	Vento		2.0	P Inj	Manual	LHS	10	1992	01	1998	DBSR300
VOLKSWAGEN	Vento		2.0	P Inj	Manual	RHS	10	1992	01	1998	DBSR100
VOLKSWAGEN	Vento		2.0	P Inj	Manual	RHS	10	1992	01	1998	DBSR300
VOLKSWAGEN	Vento		2.8	P Inj	VR6	LHS	10	1992	01	1998	DBSR300
VOLKSWAGEN	Vento		2.8	P Inj	VR6	RHS	10	1992	01	1998	DBSR300
VOLKSWAGEN	ICaddy	Mk1	1.6	D			10	1984	11	1992	DBSR100
VOLKSWAGEN	ICaddy	Mk1	1.6	P Inj			10	1984	11	1992	DBSR100
VOLKSWAGEN	ICaddy	Mk2	1.4	P Inj			04	1996	05	1999	DBSR300

Sheet1

VOLKSWAGEN I Caddy	Mk2	1.4	P Inj			02	2001	12	1999	DBSR300
VOLKSWAGEN I Caddy	Mk2	1.6	P Inj			01	1998	12	1999	DBSR300
VOLKSWAGEN I Caddy	Mk2	1.9	D			04	1996	12	1999	DBSR300
VOLKSWAGEN I Caddy	Mk2	1.9	D	SDi		04	1996	12	1999	DBSR300
VOLKSWAGEN I Caravelle		1.9	D			01	1991	12	1998	DBSR100
VOLKSWAGEN I Caravelle		2.0	P			01	1991	12	1998	DBSR100
VOLKSWAGEN I Caravelle		2.4	D			01	1991	12	1998	DBSR100
VOLKSWAGEN I Caravelle		2.5	D Turbo			01	1991	12	1998	DBSR100
VOLKSWAGEN I Caravelle		2.5	P Inj			01	1991	12	1998	DBSR100
VOLKSWAGEN I Caravelle		2.8	P Inj			01	1991	12	1998	DBSR100
VOLKSWAGEN I LT		2.3	P Inj			01	1996			DBSR300
VOLKSWAGEN I LT		2.5	P			01	1996			DBSR300
VOLKSWAGEN I LT		2.8	D			01	1996			DBSR300
VOLKSWAGEN I LT		2.8	D Turbo			01	1996			DBSR300
VOLKSWAGEN I Polo Van	Mk1	1.05	P			02	1986	05	1991	DBSR100
VOLKSWAGEN I Polo Van	Mk2	1.05	P Inj			05	1991	07	1994	DBSR100
VOLKSWAGEN I Transporter	Mk3	1.6	D	With metal plate		11	1979	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	1.6	D	Without metal plate		11	1979	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	1.6	P Inj	With metal plate		11	1979	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	1.6	P Inj	Without metal plate		11	1979	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	1.6	P Turbo	With metal plate		11	1979	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	1.6	P Turbo	Without metal plate		11	1979	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	1.7	D	With metal plate		08	1987	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	1.7	D	Without metal plate		08	1987	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	1.9	P	4wd Front		01	1986	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	1.9	P	4wd Rear, Boot for models with 14in wheels		01	1986	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	1.9	P	4wd Rear, Boot for models with 16in wheels		01	1986	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	1.9	P	Rwd With metal plate		10	1982	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	1.9	P	Rwd Without metal plate		10	1982	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	2.0	P	With metal plate		11	1979	12	1982	DBSR200
VOLKSWAGEN I Transporter	Mk3	2.0	P	Without metal plate		11	1979	12	1982	DBSR200
VOLKSWAGEN I Transporter	Mk3	2.1	P	With metal plate		12	1987	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk3	2.1	P	Without metal plate		12	1987	01	1990	DBSR200
VOLKSWAGEN I Transporter	Mk4	1.8	P Inj	Inner boot with metal plate		02	1991	01	1993	DBSR100
VOLKSWAGEN I Transporter	Mk4	1.8	P Inj	Inner boot without metal plate		02	1991	01	1993	DBSR100
VOLKSWAGEN I Transporter	Mk4	1.9	D	Inner boot with metal plate		12	1994	03	2002	DBSR100

Sheet1

VOLKSWAGEN ITransporter	Mk4	1.9	D		Inner boot without metal plate	12	1994	03	2002	DBSR100
VOLKSWAGEN ITransporter	Mk4	1.9	D Turbo		Inner boot with metal plate	12	1994	03	2002	DBSR100
VOLKSWAGEN ITransporter	Mk4	1.9	D Turbo		Inner boot without metal plate	12	1994	03	2002	DBSR100
VOLKSWAGEN ITransporter	Mk4	2.0	P Inj		Inner boot with metal plate	01	1991	12	2001	DBSR100
VOLKSWAGEN ITransporter	Mk4	2.0	P Inj		Inner boot without metal plate	01	1991	12	2001	DBSR100
VOLKSWAGEN ITransporter	Mk4	2.4	D		Inner boot with metal plate	01	1991	10	1998	DBSR100
VOLKSWAGEN ITransporter	Mk4	2.4	D		Inner boot without metal plate	01	1991	10	1998	DBSR100
VOLKSWAGEN ITransporter	Mk4	2.5	P Inj		Inner boot with metal plate	01	1994			DBSR100
VOLKSWAGEN ITransporter	Mk4	2.5	P Inj		Inner boot without metal plate	01	1994			DBSR100
VOLVO	200 Series	2.0	P	240 Series		01	1974	12	1982	DBSR100
VOLVO	200 Series	2.0	P	240 Series		01	1980	07	1993	DBSR200
VOLVO	200 Series	2.0	P	240 Series		01	1982	07	1993	DBSR300
VOLVO	200 Series	2.0	P	240 Series		01	1974	12	1980	DBSR200
VOLVO	200 Series	2.3	P	260 Series		01	1974	05	1979	DBSR100
VOLVO	300 Series	1.4	P	340		09	1976	12	1991	DBSR100
VOLVO	300 Series	1.4	P	343		09	1976	12	1991	DBSR100
VOLVO	300 Series	1.4	P	345		09	1976	12	1991	DBSR100
VOLVO	300 Series	1.4	P	360		09	1982	05	1989	DBSR100
VOLVO	300 Series	1.7	P	340		09	1976	12	1991	DBSR100
VOLVO	300 Series	1.7	P	343		09	1976	12	1991	DBSR100
VOLVO	300 Series	1.7	P	345		09	1976	12	1991	DBSR100
VOLVO	300 Series	1.7	P	360		09	1982	05	1989	DBSR100
VOLVO	300 Series	2.0	P	360		09	1982	05	1989	DBSR100
VOLVO	300 Series	2.0	P	360		01	1985	05	1989	DBSR300
VOLVO	400 Series	1.7	P Inj		LHS, Inner boot with bearing	01	1988	10	1995	DBSR300
VOLVO	400 Series	1.7	P Inj		LHS, Inner boot with bearing	01	1988	10	1995	DBSR100
VOLVO	400 Series	1.7	P Inj		LHS, Inner boot with bearing	05	1987	12	1988	DBSR300
VOLVO	400 Series	1.7	P Inj		LHS, Inner boot without bearing	01	1988	10	1995	DBSR300
VOLVO	400 Series	1.7	P Inj		LHS, Inner boot without bearing	01	1988	10	1995	DBSR100
VOLVO	400 Series	1.7	P Inj		LHS, Inner boot without bearing	05	1987	12	1988	DBSR300
VOLVO	400 Series	1.7	P Inj		RHS	01	1988	10	1995	DBSR300
VOLVO	400 Series	1.7	P Inj		RHS	01	1988	10	1995	DBSR100
VOLVO	400 Series	1.7	P Inj		RHS	05	1987	12	1988	DBSR300
VOLVO	400 Series	1.7	P Turbo		LHS, Inner boot with bearing	12	1988	10	1995	DBSR300
VOLVO	400 Series	1.7	P Turbo		LHS, Inner boot with bearing	12	1988	10	1995	DBSR100
VOLVO	400 Series	1.7	P Turbo		LHS, Inner boot with bearing	12	1988	12	1991	DBSR300

Sheet1

VOLVO	400 Series	1.7	P Turbo	LHS, Inner boot with bearing	12	1988	12	1988	DBSR300
VOLVO	400 Series	1.7	P Turbo	LHS, Inner boot without bearing	12	1988	10	1995	DBSR300
VOLVO	400 Series	1.7	P Turbo	LHS, Inner boot without bearing	12	1988	10	1995	DBSR100
VOLVO	400 Series	1.7	P Turbo	LHS, Inner boot without bearing	12	1988	12	1991	DBSR300
VOLVO	400 Series	1.7	P Turbo	LHS, Inner boot without bearing	12	1988	12	1988	DBSR300
VOLVO	400 Series	1.7	P Turbo	RHS	12	1988	10	1995	DBSR300
VOLVO	400 Series	1.7	P Turbo	RHS	12	1988	10	1995	DBSR100
VOLVO	400 Series	1.7	P Turbo	RHS	12	1988	12	1988	DBSR300
VOLVO	400 Series	1.7	P Turbo	RHS	12	1988	12	1991	DBSR300
VOLVO	700 Series	2.0	P		07	1982	12	1990	DBSR200
VOLVO	700 Series	2.3	P		07	1982	12	1990	DBSR200
VOLVO	700 Series	2.4	P		07	1982	12	1990	DBSR200
VOLVO	700 Series	2.8	P		07	1982	12	1990	DBSR200
YUGO	45	0.9	P		03	1983	12	1988	DBSR100
YUGO	45	1.1	P		03	1983	12	1988	DBSR100
YUGO	45	1.3	P		03	1983	12	1988	DBSR100
YUGO	55	0.9	P		03	1983	04	1991	DBSR100
YUGO	55	1.1	P		03	1983	04	1991	DBSR100
YUGO	55	1.3	P		03	1983	04	1991	DBSR100
YUGO	65	0.9	P		03	1983	04	1991	DBSR100
YUGO	65	1.1	P		03	1983	04	1991	DBSR100
YUGO	65	1.3	P		03	1983	04	1991	DBSR100